

Hunter Series Network Video Recorder

User's Manual



Foreword

General

This manual introduces the functions and operations of the NVR device (hereinafter referred to as "the Device").

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
! CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
©TIPS	Provides methods to help you solve a problem or save you time.
NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

Version	Revision Content	Release Time
V4.4.9	Add Wi-Fi module and repeater. Dec	
V4.4.8 Add new models and security center. November, 2019		November, 2019
V4.4.7	Add new models.	September, 2019

Version	Revision Content	Release Time		
V4.4.6	New UI interfaces and menu tree.New AI functions.	July, 2019		
V4.4.5	Deletes specifications	June, 2019		
V4.4.4	Add models: Cooper 1U (S3), Cooper 1U (S3) with 4 PoE Ports, Compact 1U (S3) with 8 PoE Ports Series.	(S3) with 4 PoE Ports, Compact 1U (S3) August, 2018		
V4.4.3	 Add Compact 1U 4K(S2) with Wireless and Smart 1U 4K(S2) with Wireless. Add Wi-Fi AP and Repeater functions. 4K 1.5U (S2) with 24 PoE ports: Add altitude 5,000 meters. 			
V4.4.2	 Add GDPR information. Add FCC information. Update HDD installation. 			
V4.3.2	Add Privacy Protection Notice and update About the Manual. May, 2018			
V4.3.1	Add new models and update relevant information. April, 2018			
V4.3.0	Delete old models and add new models. Update relevant information. October, 2017			
V4.2.0	Add models.	September, 2017		
V4.1.0	 Update POS. Modify pictures with QR code and SN. September, 2017			
V4.0.0	 Add cloud update module. Baseline switch and update screen August, 2017 interfaces. 			
V3.0.0	 Add new modules. Baseline switch and update screen interfaces. Add new models. 	May, 2016		
V1.0.0	First release.			

About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related

- regions. For detailed information, see the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, please refer to our final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation.



Important Safeguards and Warnings

The following description is the correct application method of the device. Read the manual carefully before use to prevent danger and property loss. Strictly conform to the manual during application and keep it properly after reading.

Operating Requirement

- Install the PoE front-end device indoors.
- The device does not support wall mount.
- Do not place and install the device in an area exposed to direct sunlight or near heat generating device.
- Do not install the device in a humid, dusty or fuliginous area.
- Keep its horizontal installation, or install it at stable places, and prevent it from falling.
- Do not drip or splash liquids onto the device; do not put on the device anything filled with liquids, in order to prevent liquids from flowing into the device.
- Install the device at well-ventilated places; do not block its ventilation opening.
- Use the device only within rated input and output range.
- Do not dismantle the device arbitrarily.
- Transport, use and store the device within allowed humidity and temperature range.

Power Requirement

- Make sure to use the designated battery type. Otherwise there may be explosion risk.
- Make sure to use batteries according to requirements. Otherwise, it may result in fire, explosion or burning risks of batteries!
- To replace batteries, only the same type of batteries can be used.
- Make sure to dispose the exhausted batteries according to the instructions.
- The product shall use electric wires (power wires) recommended by this area, which shall be used within its rated specification.
- Make sure to use standard power adapter matched with this device. Otherwise, the user shall undertake resulting personnel injuries or device damages.

- Use power supply that meets SELV (safety extra low voltage) requirements, and supply
 power with rated voltage that conforms to Limited Power Source in IEC60950-1. For
 specific power supply requirements, please refer to device labels.
- Products with category I structure shall be connected to grid power output socket, which is equipped with protective grounding.
- Appliance coupler is a disconnecting device. During normal use, please keep an angle that facilitates operation.

Table of Contents

Fo	reword		l
Im	portant Safe	eguards and Warnings	.IV
Tak	ole of Conte	ents	.VI
1	Features		1
1	I.1 Over	view	1
1	1.2 Feat	ures	1
2	Front Par	nel and Rear Panel	3
2	2.1 Fron	t Panel	3
	2.1.1	Beneficio smart 1U/Beneficio smart 1U(S2)/ 4K smart 1U (S2)/ Beneficio 4K Smart 1U(S2)/ Beneficio 4K S	32)
	Series		3
	2.1.2	Beneficio Mini 1U Series	3
	2.1.3	Compact 1U Wireless Series	4
	2.1.4	Beneficio Smart 1U with 8 PoE port Series	5
	2.1.5	4K Smart 1U(S2) with 8 PoE port Series	5
	2.1.6	Beneficio 1U Series	6
	2.1.7	Compact 1U (S2)/4K compact 1U (S2)/Compact 1U 4K (S2) Series	8
	2.1.8	1U/1.5U/2U Series	9
	2.1.9	Beneficio 1.5U Series	.11
	2.1.10	Beneficio 2U Series	12
	2.1.11	Beneficio Vertical 1U Series	15
	2.1.12	Smart 1U 4K (S2) wih Wireless Series	16
	2.1.13	Compact 1U 4K (S2) wih Wireless Series	.17
	2.1.14	Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports / Compact 1U (S3) with 8 PoE Po	rts
	Series		18
	2.1.15	4/8ch Compact 1U Series	19
2	2.2 Rear	Panel	20
	2.2.1	Beneficio Smart 1U / Beneficio Smart 1U with 1 PoE port/ Beneficio Smart 1U with 8 P	οE
	ports/ Ber	neficio Smart 1U with wireless Series	.20
	2.2.2	Beneficio Smart 1U (S2)/ Beneficio 4K Smart 1U(S2) Series	.22
	2.2.3	Beneficio Mini 1U / Beneficio Mini 1U with 1 PoE port/ Beneficio Mini 1U with 8 PoE po	rts
	Series		23
	2.2.4	Compact 1U (S2) / Compact 1U 4K (S2) Series	.25
	2.2.5	Compact 1U Wireless Series	26
	2.2.6	Beneficio 1U (S2)/ Beneficio 4K 1U(S2) Series	.27
	2.2.7	Beneficio 1U / Beneficio Entry-level 1U/ Beneficio 1U with 1 PoE port/ Beneficio 1U with	า 8
	PoE ports	s/ Beneficio 1U with 16 PoE Ports Series	28
	2.2.8	Professional 4K 1U/ Professional 4K 1U with 8 PoE ports/ Professional 4K 1U with	16
	PoE ports	s/4K 1U (S2) with 24 PoE Ports/4K 1U (S2E) with 8 PoE ports/4K 1U (S2E) with 16 Po	οЕ
	ports Seri	ies	.31

	2.2.		Beneficio 1.5U / Beneficio 1.5U with 8 PoE ports/ Beneficio 1.5U with 1	•
	2.2.		Professional 4K 1.5U/ Professional 4K 1.5U with 16 PoE ports/ Professional 4K 1.5U/ Prof	
			nal 4K 2U with 16 PoE ports/4K 1.5U (S2) with 24 PoE ports/4K 1.5U (S2E)	
			2U (S2E) with 16 PoE ports Series	
	2.2.		4K Smart 1U (S2) Series	
	2.2.		Beneficio Vertical 1U Series	
	2.2.	_	4K Compact 1U (S2) Series	
	2.2.		4K 1U (S2) Series	
	2.2.	_	4K 1.5U (S2) Series	
	2.2.		Beneficio 2U/Beneficio 2U with 16 PoE ports Series	
	2.2.		4K 2U (S2) Series	
	2.2.	_	Smart 1U 4K (S2) wih Wireless Series	
	2.2.		Compact 1U 4K (S2) wih Wireless Series	
	2.2.		Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports / Compact 1U (S3) with	
			40.1.0	
	2.2.		4/8ch Compact 1U Series	
2	2.3		1 Connection	
	2.3.		Alarm Port	
	2.3.		Alarm input port	
	2.3.3		Alarm input and output port	
	2.3.		Alarm relay specifications	
2	2.4		ectional talk	
	2.4.		Device-end to PC-end	
	2.4.2		PC-end to the device-end	
	2.5		e Operation	
	2.6		ote Control	
3			stallation	
	3.1		e Installation Diagrams	
	3.2		k Unpacked NVR	
	3.3		t Front Panel and Rear Panel	
,	3.4		Installation	
	3.4.		Smart 1U Series	
	3.4.	.2	Mini 1U/Cooper 1U/Compact 1U Series	
	3.4.		1U Series	
	3.4.	.4	1.5U Series	66
	3.4.		General 2U Series	
	3.4.		Beneficio Vertical 1U Series	
,	3.5		OM Installation	
;	3.6		ection Sample	
	3.6.		Beneficio Smart 1U/Beneficio Smart 1U(S2)/ 4K Smart 1U (S2) Series	
	3.6.		Beneficio Mini 1U / Beneficio Mini 1U with 4 PoE Ports / Beneficio mini 1U	
			es	
	3.6.		Smart 1U / Compact 1U Wireless Series	
	3.6.		Compact 1U (S2) /4K Compact 1U (S2) / Cooper 1U (S3) / Cooper 1U (S3)	-
	Por	ts / Co	mpact 1U (S3) with 8 PoE Ports Series	71

	3.6.5	Beneficio 1U (S2) Series	72
	3.6.6	Beneficio Entry-level 1U Series	72
	3.6.7	Beneficio 1U/Professional 4K 1U/ Professional 4K 1U with 8 PoE ports/ Profe	ssional 4K
	1U with 16	6 PoE ports/4K 1U (S2) with 24 PoE Ports/4K 1U (S2E) with 8 PoE Ports/4K 1U	(S2E) with
	16 PoE Po	orts Series	73
	3.6.8	General 4K 1U (S2)/Beneficio 4K 1U with 8 PoE ports/4K 1U (S2) with 4 PoE po	orts/4K 1U
	(S2) with 8	PoE ports/4K 1U (S2) with 16 PoE ports Series	
	3.6.9	Professional 4K 1.5U/ Professional 4K 1.5U with 16 PoE ports/ Professional	
	Profession	nal 4K 2U with 16 PoE ports/4K 1.5U (S2E) with 16 PoE ports/4K 2U	ith 16 PoE
	Ports Serie	es	74
	3.6.10	Beneficio 1.5U / Beneficio 1.5U with 8 PoE ports / Beneficio 1.5U with 16 Pol	E ports/4K
	1.5U (S2)	Series	74
	3.6.11	4K 2U (S2) Series	75
	3.6.12	Beneficio Vertical 1U Series	75
4	Local Basi	ic Operation	77
4	.1 Gettir	ng Started	77
	4.1.1	Boot up	77
	4.1.2	Device Initialization	77
	4.1.3	Reset Password	81
	4.1.4	Quick Settings	88
4	.2 Came	era	113
	4.2.1.1	Connection	113
	4.2.2	Remote Device Initialization	118
	4.2.3	Short-Cut Menu to Register Camera	122
	4.2.4	Image	122
	4.2.5	Encode	125
	4.2.6	Channel Name	127
	4.2.7	Remote Upgrade	128
	4.2.8	Remote Device Info	129
4	.3 Live \	/iew	131
	4.3.1	Preview	131
	4.3.2	Navigation bar	132
	4.3.3	Preview Control Interface	134
	4.3.4	Wireless Pairing	140
	4.3.5	Sequence	141
	4.3.6	Fisheye (Optional)	144
	4.3.6.3	Test Temperature	146
	4.3.7	Al Preview Mode	147
4	.4 PTZ		149
	4.4.1	PTZ Settings	150
	4.4.2	PTZ Control	152
	4.4.3	Configuring PTZ Functions	153
	4.4.4	Calling PTZ Functions	155
4	.5 Recoi	rd File	
4	.6 Playb	ack and Search	157
	4.6.1		

4.6.2	Search Interface	157
4.6.3	Smart Search Playback	161
4.6.4	Mark Playback	162
4.6.5	Playback Image	163
4.6.6	Splice Playback	163
4.6.7	File List	164
4.6.8	Other Aux Functions	165
4.7 Al		166
4.7.1	Al Search	166
4.7.2	Parameters	180
4.7.3	Database	216
4.8 Ever	nt Manager	223
4.8.1	Alarm Info	223
4.8.2	Alarm Status	223
4.8.3	Alarm Input	224
4.8.4	Alarm Control	226
4.8.5	Video Detection	227
4.8.6	Audio Detect	235
4.8.7	Thermal Alarm	237
4.8.8	Abnormality	240
4.9 POS		242
4.9.1	Search	243
4.9.2	Settings	243
4.10 Oper	ration and Maintenance	246
4.10.1	Log	246
4.10.2	System	247
4.10.3	Network	251
4.10.4	Maintenance and Management	254
4.11 File l	Backup	261
4.12 Netw	vork	262
4.12.1	TCP/IP	262
4.12.2	Port	264
4.12.3	Wi-Fi AP	265
4.12.4	Repeater	267
4.12.5	PPPoE	269
4.12.6	DDNS	270
4.12.7	UPnP	271
4.12.8	Email	273
4.12.9	SNMP	275
4.12.10	Multicast	277
4.12.11	Alarm Center	
4.12.12	Register	
4.12.13	P2P	
4.13 Stora	age	
4.13.1	Basic	
4.13.2	Schedule	282

4.13.	3 HDD	282	
4.13.4	4 Record Control	283	
4.13.	5 Advance (HDD Group)	283	
4.13.0	6 HDD Detect	284	
4.13.	7 RAID	288	
4.13.	8 Record Estimate	293	
4.13.9	9 FTP	295	
4.14	SystemSystem	296	
4.14.	1 General	296	
4.14.	2 RS232	297	
4.15	Security	298	
4.15.	1 Security Status	298	
4.15.2	2 System Service	300	
4.15.	3 Attack Defense	303	
4.15.	4 CA Certificate	308	
4.15.	5 Audio/Video Encryption	310	
4.15.0	6 Security Warning	312	
4.16 A	Account	315	
4.16.	1 User	315	
4.16.2	2 Group	318	
4.16.	Reset Password	320	
4.16.	4 ONVIF User	321	
4.17	Dutput and Display	323	
4.17.	1 Display	323	
4.17.	2 Tour	324	
4.17.	3 Customized Display	326	
4.18 <i>A</i>	Audio	328	
4.18.	1 File Manage	328	
4.18.	2 Schedule	330	
4.18.	3 Broadcast	332	
4.19 l	JSB Device Auto Pop-up	334	
4.20	Shutdown	334	
5 Web	Operation	338	
5.1 N	Network Connection	338	
5.2 V	Veb Login	338	
5.3 F	Reset Password	339	
5.4 V	Veb Main Menu	341	
Appendix	1 Glossary	344	
Appendix	2 FAQ	345	
Appendix	Appendix 3 Cybersecurity Recommendations350		
Appendix	4 HDD Capacity Calculation	353	
Appendix	5 Compatible Network Camera List	354	

1.1 Overview

This series NVR is a high performance network video recorder. This series product support local preview, multiple-window display, recorded file local storage, remote control and mouse shortcut menu operation, and remote management and control function.

This series product supports center storage, front-end storage and client-end storage. The monitor zone in the front-end can be set in anywhere. Working with other front-end devices such as IPC, NVS, this series product can establish a strong surveillance network via the CMS. In the network system, there is only one network cable from the monitor center to the monitor zone in the whole network. There is no audio/video cable from the monitor center to the monitor zone. The whole project is featuring of simple connection, low-cost, low maintenance work.

This series NVR can be widely used in many areas such as public security, water conservancy, transportation and education.

1.2 Features

Cloud Upgrade	For the NVR connected with the Internet, it supports online upgrade to update applications.		
Real-time Surveillance	 VGA, HDMI port. Connect to monitor to realize real-time surveillance. Some series support TV/VGA/HDMI output at the same time. Short-cut menu when preview. Support popular PTZ decoder control protocols. Support preset, tour and pattern. 		
Support each channel real-time record independently, and a time it can support search, forward play, network monitor, record download and etc. Support various playback modes: slow play, fast play, back and frame by frame play. Support time title overlay so that you can view event accurate time Support specified zone enlargement.			
 User Management Each group has different management powers that can be exercised by the exercised by th			
Storage	 Via corresponding setup (such as alarm setup and schedule setup), you can backup related audio/video data in the network video recorder. Support Web record and record local video and storage the file in the client end. 		
Alarm	Respond to external alarm simultaneously (within 200MS), based on		

	user's pre-defined relay setup, system can process the alarm input correctly and prompt user by screen and voice (support pre-recorded audio).	
	Support central alarm server setup, so that alarm information can remotely notify user automatically. Alarm input can be derived from	
	various connected peripheral devices.	
	Alert you via email/sms.	
	 Through network, sending audio/video data compressed by IPC or NVS to client-ends, then the data will be decompressed and display. 	
	Support max 128 connections at the same time.	
Network	Transmit audio/video data by HTTP, TCP, UDP, MULTICAST,	
Monitor	RTP/RTCP and etc.	
	Transmit some alarm data or alarm info by SNMP.Support WEB access in WAN/LAN.	
	Adopt the video compression and digital process to show several	
Window Split	windows in one monitor. Support 1/4/8/9/16/ 25/36-window display when	
	preview and 1/4/9/16-window display when playback.	
	Support normal/motion detect/alarm record function. Save the recorded	
Record	files in the HDD, USB device, client-end PC, or network storage server.	
Resolu	You can search or playback the saved files at the local-end or via the	
	Web/USB device.	
Backup	Support network backup, USB2.0 record backup function, the recorded files can be saved in network storage server, peripheral USB2.0 doubles burner and storage.	
Network	device, burner and etc.Supervise NVR configuration and control power via Ethernet.	
Management	Support management via WEB.	
Peripheral	Support peripheral equipment management such as protocol setup and	
Equipment	port connection.	
Management	 Support transparent data transmission such as RS232 (RS-422), RS485 (RS-485). 	
	Support switch between NTSC and PAL.	
	Support real-time system resources information and running statistics	
	display.	
Auxiliary	Support log file.	
	Local GUI output. Shortcut menu operation via mouse.	
	IR control function (For some series product only.). Shortcut menu	
	operation via remote control.	
	Play the video/audio from the network camera or NVS remotely.	

2 Front Panel and Rear Panel

MOTE

The following front panel and rear panel figures are for reference only. The actual product shall prevail.

2.1 Front Panel

2.1.1 Beneficio smart 1U/Beneficio smart 1U(S2)/ 4K smart 1U (S2)/ Beneficio 4K Smart 1U(S2) Series

The front panel is shown as in Figure 2-1.

Figure 2-1




Table 2-1

No.	Name	Function
1	HDD status indictor light	The red light becomes on when HDD is abnormal.
2	Power indicator light	The red light becomes on when the power connection is OK.
3	Network status indicator light	The red light becomes on when the network connection is abnormal.

2.1.2 Beneficio Mini 1U Series

The front panel is shown as in Figure 2-2.

Figure 2-2



Table 2-2

Icon	Name	Function
NET	Network status	The red light becomes on when the
	indicator light	network connection is abnormal.
PWR	Power indicator	The red light becomes on when the power
	light	connection is OK.
HDD	HDD status	The red light becomes on when HDD is
	indictor light	abnormal.
IR	Remote control	It is to receive signal from the remote
	receiver	control.

2.1.3 Compact 1U Wireless Series

The front panel is shown as below. See Figure 2-3.




Table 2-3

Icon	Name	Function
HDD	HDD status indicator	The blue light is on when the HDD is in malfunction.
	light	
NET	Network status indicator	The blue light is on when the network connection is
	light	abnormal.
POWER	Power status indicator light	The blue light is on when the power connection is
		OK.
~ €	USB2.0 port	Connect to peripheral USB 2.0 storage device,
		mouse, burner and etc.

2.1.4 Beneficio Smart 1U with 8 PoE port Series

The front panel is shown as below. See Figure 2-4.

Figure 2-4




Table 2-4

No.	Name	Function
1	Network status indicator light	The red light becomes on when the network connection is abnormal.
2	Power indicator light	The red light becomes on when the power connection is OK.
3	HDD status indictor light	The red light becomes on when HDD is abnormal.
4	USB	USB port

2.1.5 4K Smart 1U(S2) with 8 PoE port Series

The front panel is shown as in Figure 2-5.

Figure 2-5




Table 2-5

No.	Name	Function
1	HDD status indictor light	The red light becomes on when HDD is abnormal.
2	Power indicator light	The red light becomes on when the power connection is OK.
3	Network status indicator light	The red light becomes on when the network connection is abnormal.

2.1.6 Beneficio 1U Series

The front panel is shown as below. See Figure 2-6.

Figure 2-6



Table 2-6

Icon	Name	Function
Power button	(1)	Power button, press this button for three
	0	seconds to boot up or shut down NVR.
Shift	Shift	In textbox, click this button to switch between
		numeral, English(Small/Capitalized), donation
		and etc.
Up/1	▲\▼	Activate current control, modify setup, and
Down/4		then move up and down.

Icon	Name	Function
		Increase/decrease numeral.
		Assistant function such as PTZ menu.
		In text mode, input number 1/4 (English
		character G/H/I).
Left/2	◄ \▶	Shift current activated control.
Right/3		When playback, click these buttons to control
		playback bar.
		In text mode, input number 2(English character
		A/B/C)/3(English character D/E/F).
ESC	ESC	Go to previous menu, or cancel current
		operation.
		When playback, click it to restore real-time
		monitor mode.
Enter	ENTER	Confirm current operation.
		Go to default button.
		Go to menu.
Record	REC	Manually stop/start recording, working with
		direction keys.
		or numeral keys to select the recording
		channel.
Slow play/8)·	Multiple slow play speeds or normal playback.
		In text mode, input number 8 (English
		character T/U/V).
Assistant	Fn	One-window monitor mode, click this button to
		display assistant function: PTZ control and
		image color.
		Backspace function: in numeral control or text
		control, press it for 1.5seconds to delete the
		previous character before the cursor.
		In motion detection setup, working with Fn and
		direction keys to realize setup.
		In text mode, click it to switch between
		numeral, English character(small/capitalized)
		and etc.
Fast play/7	>>	Various fast speeds and normal playback.
		In text mode, input number 7 (English
		character P/Q/R/S).
Play previous/0	◀	In playback mode, playback the previous
		video.
		In text mode, input number 0.

Icon	Name	Function
Reverse/Pause/6	•	In normal playback or pause mode, click this
		button to reverse playback.
		In reverse playback, click this button to pause
		playback.
		In text mode, input number 6 (English
		character M/N/O).
Play Next/9	▶	In playback mode, playback the next video.
		In menu setup, go to down ward of the
		dropdown list.
		In text mode, input number 9 (English
		character W/X/Y/Z).
Play/Pause /5	▶	In normal playback click this button to pause
		playback.
		In pause mode, click this button to resume
		playback.
		In text mode, input number 5(English character
LIOD .		J/K/L).
USB port	~ ⊕	To connect USB storage device, USB mouse.
Network	Net	Network error occurs or there is no network
abnormal		connection, the light becomes red to alert you.
indicator light		
HDD abnormal	HDD	HDD error occurs or HDD capacity is below
indicator light		specified threshold value, the light becomes
		red to alert you.
Record light	1-16	System is recording or not. It becomes on
		when system is recording.
IR Receiver	IR	It is to receive the signal from the remote
		control.

2.1.7 Compact 1U (S2)/4K compact 1U (S2)/Compact 1U 4K (S2) Series

The series front panel is shown as below. See Figure 2-7.

Figure 2-7




Table 2-7


Icon	Name	Function
STATUS	Status indicator light	The blue light is on when the device is malfunction. Note
		General compact 1U(S2) series product does not support STATUS indicator light.

Icon	Name	Function
HDD	HDD status indicator	The blue light is on when the HDD is
	light	malfunction.
NET	Network status indicator	The blue light is on when the network
	light	connection is abnormal.
POWER	Power status indicator	The blue light is on when the power connection
	light	is OK.
د	USB port	Connect to peripheral USB storage device,
		mouse and etc.

2.1.8 1U/1.5U/2U Series


The 1U series front panel is shown as in Figure 2-8.

Figure 2-8



The 1.5U series front panel is shown as in Figure 2-9.

Figure 2-9



The 2U series front panel is shown as in Figure 2-10.

Figure 2-10




Table 2-8

Icon	Name	Function
STATUS	Status indicator light	The blue light is on when the device is
		malfunction.
HDD	HDD status indicator	The blue light is on when the HDD is
	light	malfunction.
NET	Network status indicator	The blue light is on when the network
	light	connection is abnormal.
POWER	Power status indicator	The blue light is on when the power connection
	light	is OK.

Icon	Name	Function
- €	USB2.0 port	Connect to peripheral USB 2.0 storage device,
		mouse, burner and etc.

2.1.9 Beneficio 1.5U Series

The front panel is shown as in Figure 2-11.

Figure 2-11




Table 2-9

Icon	Name	Function
Power button	(l)	Power button, press this button for three
	0	seconds to boot up or shut down NVR.
Shift	Shift	In textbox, click this button to switch between
		numeral, English(Small/Capitalized),donation
		and etc.
Up/1	▲ \▼	Activate current control, modify setup, and then
Down/4		move up and down.
		Increase/decrease numeral.
		Assistant function such as PTZ menu.
		In text mode, input number 1/4 (English
		character G/H/I).
Left/2	◄ \▶	Shift current activated control.
Right/3		When playback, click these buttons to control
		playback bar.
		In text mode, input number 2(English character
		A/B/C).
		/3(English character D/E/F).
ESC	ESC	Go to previous menu, or cancel current
		operation.
		When playback, click it to restore real-time
		monitor mode.
Enter	ENTER	Confirm current operation.
		Go to default button.
		Go to menu.
Record	REC	Manually stop/start recording, working with
		direction keys.
		or numeral keys to select the recording
	Section 2	channel.
Slow play/8)·	Multiple slow play speeds or normal playback.
		In text mode, input number 8 (English character
		T/U/V).

Icon	Name	Function
Assistant	Fn	One-window monitor mode, click this button to display assistant function: PTZ control and image color.
		Backspace function: in numeral control or text
		control, press it for 1.5seconds to delete the
		previous character before the cursor.
		In motion detection setup, working with Fn and
		direction keys to realize setup.
		In text mode, click it to switch between numeral,
		English character(small/capitalized) and etc.
Fast play/7	*	Various fast speeds and normal playback.
		In text mode, input number 7 (English character P/Q/R/S).
Play previous/0	◀	In playback mode, playback the previous video In text mode, input number 0.
Reverse/Pause/6	◀	In normal playback or pause mode, click this
		button to reverse playback.
		In reverse playback, click this button to pause
		playback.
		In text mode, input number 6 (English character M/N/O).
Play Next/9	>	In playback mode, playback the next video.
I lay Next/9		In menu setup, go to down ward of the
		dropdown list.
		In text mode, input number 9 (English character
		W/X/Y/Z).
Play/Pause /5	▶	In normal playback click this button to pause
		playback.
		In pause mode, click this button to resume
		playback.
		In text mode, input number 5(English character
		J/K/L).
USB port	~₩	To connect USB storage device, USB mouse.
Network	Net	Network error occurs or there is no network
abnormal		connection, the light becomes red to alert you.
indicator light	LIDD	1100
HDD abnormal	HDD	HDD error occurs or HDD capacity is below
indicator light		specified threshold value, the light becomes red
Pecord light	1-16	to alert you.
Record light	1-10	System is recording or not. It becomes on when system is recording.
		System is recording.

2.1.10 Beneficio 2U Series

The Front panel is shown as follows. See Figure 2-12.

Figure 2-12




Table 2-10

Icon	Name	Function
Power button	ന	Power button, press this button for three seconds to boot up or shut down NVR.
Number button	0-9	Input Arabic number. Switch channel.
Input number more than 10	-/	If you want to input a number more than 10, please click this button and then input.
Shift	+	In textbox, click this button to switch between numeral, English(Small/Capitalized),donation and etc.
		Enable or disable tour.
Up/	▲\▼	Activate current control, modify setup, and then move up and down.
Down	A \ V	Increase/decrease numeral.
		Assistant function such as PTZ menu.
Left/	◄ \▶	Shift current activated control, and then move left and right.
Right		When playback, click these buttons to control playback bar.
500	ESC	Go to previous menu, or cancel current operation.
ESC		When playback, click it to restore real-time monitor mode.
		Confirm current operation.
Enter	ENTER	Go to default button.
		Go to menu.
Record	REC	Manually stop/start recording, working with direction keys or numeral keys to select the recording channel.
Slow play).	Multiple slow play speeds or normal playback.
Assistant	Fn	One-window monitor mode, click this button to display assistant function: PTZ control and image color.

Icon	Name	Function
		Backspace function: in numeral control or text control, press it for 1.5seconds to delete the previous character before the cursor.
		In motion detection setup, working with Fn and
		direction keys to realize setup.
		In text mode, click it to switch between numeral,
		English character(small/capitalized) and etc.
		In HDD management interface, you can click it
		to switch HDD record information and other information (Menu prompt)
		Realize other special functions.
Fast play	*	Various fast speeds and normal playback.
Play previous	∢	In playback mode, playback the previous video.
		In normal playback or pause mode, click this
Reverse/Pause	◀	button to reverse playback.
		In reverse playback, click this button to pause
		playback.
Dlov Nove	.	In playback mode, playback the next video.
Play Next	>	In menu setup, go to down ward of the dropdown list.
		In normal playback click this button to pause
		playback.
Play/Pause	►II	In pause mode, click this button to resume
		playback.
Window switch	Mult	Click it to switch one-window/multiple-window.
		In real-time monitor mode it works as left/right
Shuttle(outer		direction key.
ring)		Playback mode, counter clockwise to forward and clock wise to backward.
		Up/down direction key.
La artina a con Politica		Playback mode, turn the inner dial to realized
Jog(inner dial)		frame by frame playback. (Only applies to some
		special versions.)
USB port	~ €	To connect USB storage device, USB mouse.
Remote control indicator light	ACT	Remote control indicator light.
Status indicator	Status	If there is Fn indicator light, current status
light	Status	indicator light is null.
Power indicator	PWR	Power indicator light.
light		. S. S. Haloatol light.

Icon	Name	Function
		For 4/8/16-channel series product.
		The corresponding channel light becomes on
		when system is recording.
		For 32/64-channel series product:
		When the light flashes slowly, it means the
		corresponding channel of 1-16 channel is
Channel indictor	1-32	recording now (Such as channel 1).
		When the light flashes fast, it means the
light		corresponding channel of 17-32 channel is
		recording now (Such as channel 17)
		When the light becomes on, It means the
		corresponding 2 channels are recoding now
		(Such as channel 1 and channel 17.).
		The channel indictor light here does not
		show the status of the 33-64-channel.
ID Possiver	IR	It is to receive the signal from the remote
IR Receiver	IIX	control.

2.1.11 Beneficio Vertical 1U Series

The front panel is shown as below. See Figure 2-13.






Table 2-11

Name	Icon	Function
Power button	ن	Power button, press this button for three seconds to boot up
		or shut down NVR.

_			
Assistant	Fn	 One-window monitor mode, click this button to display assistant function: PTZ control and image color. Backspace function: in numeral control or text control, press it for 1.5 seconds to delete the previous character before the cursor. In motion detection setup, working with Fn and direction keys to realize setup. In text mode, click it to switch between numeral, English character (small/capitalized) and etc. In HDD management interface, you can click it to switch HDD record information and other information (Menu prompt) Realize other special functions. 	
USB2.0 port	÷	To connect USB2.0 storage device, USB2.0 mouse, burner and etc.	
IR receive window	IR	It is to receive the IR signal from the remote control.	
Power indicator light	*	Power indicator light.	
HDD abnormal	8	HDD error occurs or HDD capacity is below specified	
indicator light		threshold value, the light becomes red to alert you.	
Network	00	Network error occurs or there is no network connection, the	
abnormal		light becomes red to alert you.	
indicator light	10000		
Alarm indicator	Δ	The light becomes on when an alarm occurred.	
light			

2.1.12 Smart 1U 4K (S2) wih Wireless Series

The front panel is shown as below. See Figure 2-14.

Figure 2-14




Table 2-12

Icon	Name	Function
HDD	HDD status indicator	The blue light is on when the HDD is malfunction.
	light	
NET	Network status indicator	The blue light is on when the network connection is
	light	abnormal.
PWR	Power status indicator light	The blue light is on when the power connection is
		OK.

2.1.13 Compact 1U 4K (S2) wih Wireless Series

The front panel is shown as below. See Figure 2-15.

Figure 2-15





Table 2-13

Icon	Name	Function
HDD	HDD status indicator	The blue light is on when the HDD is malfunction.
	light	
NET	Network status indicator	The blue light is on when the network connection is
	light	abnormal.
POWER	Power status indicator light	The blue light is on when the power connection is
		OK.
د.	USB2.0 port	Connect to peripheral USB 2.0 storage device,
		mouse and etc.

2.1.14 Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports / Compact 1U (S3) with 8 PoE Ports Series


The Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports series NVR front panel is shown as in Figure 2-16.

Figure 2-16



The Compact 1U (S3) with 8 PoE Ports series NVR front panel is shown as in Figure 2-17.

Figure 2-17



2.1.15 4/8ch Compact 1U Series

The 4/8ch Compact 1U series NVR front panel is shown as in Figure 2-18.

Figure 2-18




Table 2-14


Icon	Name	Function
HDD	HDD status indicator	The blue light is on when the HDD is
	light	malfunction.
NET	Network status indicator	The blue light is on when the network
	light	connection is abnormal.
POWER	Power status indicator	The blue light is on when the power connection
	light	is OK.
دن	USB2.0 port	Connect to peripheral USB 2.0 storage device,
		mouse and etc.

2.2 Rear Panel

2.2.1 Beneficio Smart 1U / Beneficio Smart 1U with 1 PoE port/ Beneficio Smart 1U with 8 PoE ports/ Beneficio Smart 1U with wireless Series


The beneficio Smart 1U series NVR rear panel is shown as below. See Figure 2-19.

Figure 2-19




The beneficio Smart 1U with 1 PoE port series NVR rear panel is shown as below. See Figure 2-20.

Figure 2-20



The beneficio Smart 1U with 8 PoE ports series NVR rear panel is shown as below. See Figure 2-21 Figure 2-21



The Beneficio Smart 1U with wireless series NVR rear panel is shown as below. See Figure 2-22.

Figure 2-22




Table 2-15


Port Name	Connection	Function
•=	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
00	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
Ť	GND	Ground end
DC 12V DC 48V =-G-* / =-G-*	Power input port	 Power socket. For beneficio smart 1U series, input DC 12V/2A. For beneficio smart 1U with 1 PoE port series, input DC 48V/1.5A. For beneficio smart 1U with 8 PoE ports series, input DC 48V/2A.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.

Port Name	Connection	Function
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
PoE PORT	PoE port	Built-in switch. Support PoE function. For PoE series product, you can use this port to provide power to the network camera.
Wireless AP		Support wireless hotspot function. Use WIFI to connect to the network camera when there is a hotspot.
		For Beneficio Smart 1U with wirelss series NVR only.

2.2.2 Beneficio Smart 1U (S2)/ Beneficio 4K Smart 1U(S2) Series


The general series is shown as in Figure 2-23.





The 4 PoE ports series is shown as in Figure 2-24.

Figure 2-24



The 8 PoE ports series is shown as in Figure 2-25.

Figure 2-25




Table 2-16

Port Name	Connection	Function
DC 12V =-G=	Power input port	 Power socket For general series, input DC 12V/2A. For 4 PoE ports series, input DC 48V/1.25A. For 8 PoE ports series, input DC 48V/2A.
50	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
•	USB port	USB port. Connect to mouse, USB storage device and etc.
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
Ţ	GND	Ground end
PoE PORTS	PoE port	Built-in switch. Support PoE function. For PoE series product, you can use this port to provide power to the network camera.

2.2.3 Beneficio Mini 1U / Beneficio Mini 1U with 1 PoE port/ Beneficio Mini 1U with 8 PoE ports Series


The beneficio mini 1U series NVR rear panel is shown as in Figure 2-26.

Figure 2-26



The beneficio mini 1U with 1 PoE port series NVR rear panel is shown as in Figure 2-27.

Figure 2-27



The beneficio mini 1U with 8 PoE ports series NVR rear panel is shown as in Figure 2-28.

Figure 2-28




Table 2-17


Port Name	Connection	Function
•	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
55	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
Ť	GND	Ground end
DC12V DC 48V -G- / -G-	Power input port	 Power socket. For beneficio mini 1U series NVR, input DC 12V/2A. For beneficio mini 1U with 1 PoE port series NVR, input DC 48V/1.5A. For beneficio Mini 1U with 8 PoE ports series NVR, input DC 48V/2A.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.

Port Name	Connection	Function
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
PoE PORT	PoE port	Built-in switch. Support PoE function. For PoE series product, you can use this port to provide power to the network camera.

2.2.4 Compact 1U (S2) / Compact 1U 4K (S2) Series


The general series rear panel is shown as below. See Figure 2-29.

Figure 2-29



The 4 PoE ports series rear panel is shown as below. See Figure 2-30.

Figure 2-30



The 8 PoE ports series rear panel is shown as below. See Figure 2-31.

Figure 2-31




Table 2-18

Port Name	Connection	Function
DC 12V 	Power input port	Power socket.
		 For general series, input DC 12V/2A.
		 For 4 PoE ports series, input DC 48V/1.25A.
		 For 8 PoE ports series, input DC 48V/2A.
00	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the
		network cable.
•	USB port	USB port. Connect to mouse, USB storage device and
		etc.

Port Name	Connection	Function
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
Ē	GND	Ground end
PoE PORTS	PoE port	Built-in switch. Support PoE function. For PoE series product, you can use this port to provide power to the network camera.

2.2.5 Compact 1U Wireless Series

The rear panel is shown as below. See Figure 2-32.




Table 2-19


Icon	Name	Function
DC 12V	Power input	Power socket. Input DC12V/2A.
-G-	socket.	Fower socket. Input DC 12V/2A.
Q	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to
		the network cable.
• • • •	LISP2 0 port	USB2.0 port. Connect to mouse, USB storage device,
• •	USB2.0 port	and etc.

Icon	Name	Function
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
<u> </u>	GND	Ground end
Wireless AP	-	Support wireless hotspot function. Use WIFI to connect to the network camera when there is a hotspot.

2.2.6 Beneficio 1U (S2)/ Beneficio 4K 1U(S2) Series


The general series rear panel is shown as below. See Figure 2-33.

Figure 2-33



The 4 PoE ports series rear panel is shown as below. See Figure 2-34.

Figure 2-34



The 8 PoE ports series rear panel is shown as below. See Figure 2-35

Figure 2-35





Table 2-20

Port Name	Connection	Function
DC 12V = G=	Power input port	 Power socket. For general series, input DC 12V/4A. For 4 PoE ports series, input DC 48V/1.5A. For 8 PoE ports series, input DC 53V 120W.
-	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
•	USB port	USB port. Connect to mouse, USB storage device and etc.
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
Ť	GND	Ground end
PoE PORTS	PoE port	Built-in switch. Support PoE function. For PoE series product, you can use this port to provide power to the network camera.

2.2.7 Beneficio 1U / Beneficio Entry-level 1U/ Beneficio 1U with 1 PoE port/ Beneficio 1U with 8 PoE ports/ Beneficio 1U with 16 PoE Ports Series


The beneficio 1U series NVR rear panel is shown as below. See Figure 2-36.

Figure 2-36




The beneficio entry-level 1U series rear panel is shown as below. See Figure 2-37.

Figure 2-37




The beneficio 1U with 1 PoE port series NVR rear panel is shown as below. See Figure 2-38.

Figure 2-38



The beneficio 1U with 8 PoE ports series NVR rear panel is shown as below. See Figure 2-39.

Figure 2-39



The beneficio 1U with 16 PoE Ports series rear panel is shown as below. See Figure 2-40.

Figure 2-40




Table 2-21

Name		Function
	Power switch	Power on/off button.
DC 12V 		Input DC 12V/5A. For beneficio 1U series product only.
DC 48V -G-2	Power input port	Switch power port. Input DC 48//1.04A. For beneficio 1U with 1 PoE port series product only. Input AC 100~240V.
		For beneficio 1U with 8/16 PoE ports series product only.


Name		Function
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
1~4	Alarm input port 1~4	 There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
±	GND	Alarm input ground port.
N1, N2 C1, C2	Alarm output port 1~2	 2 groups of alarm output ports. (Group 1: port NO1~C1,Group 2:port NO2~C2).Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normal open alarm output port. C: Alarm output public end.
А	RS-485	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	communication port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
50	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
•=	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.

Name		Function
		Bult-in Switch. Support PoE.
PoE PORTS	/	The 4 PoE series product supports total 48V 50W.
		The 8 PoE series product supports total 48V 120W.
		The 16 PoE series product supports total 120W. One
		PoE port max supports 15W.

2.2.8 Professional 4K 1U/ Professional 4K 1U with 8 PoE ports/ Professional 4K 1U with 16 PoE ports/4K 1U (S2) with 24 PoE Ports/4K 1U (S2E) with 8 PoE ports/4K 1U (S2E) with 16 PoE ports Series


The professional 4K 1U series rear panel is shown as below. See Figure 2-41.

Figure 2-41




The professional 4K 1U with 8 PoE ports rear panel is shown as below. See Figure 2-42.

Figure 2-42




The professional 4K 1U with 16 PoE ports rear panel is shown as below. See Figure 2-43.

Figure 2-43



The 4K 1U (S2) with 24 PoE ports series rear panel is shown as below. See Figure 2-44.

Figure 2-44



The 4K 1U (S2E) with 8 PoE ports/4K 1U (S2E) with 16 PoE ports series rear panel is shown as below. See Figure 2-45.



The following figure takes 4K 1U (S2E) with 16 PoE ports series as an example.

Figure 2-45




Table 2-22


Icon	Port Name	Function
50	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
•	USB3.0 port	USB3.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
1~8	Alarm input port 1∼8	 There are two groups. The first group is from port 1 to port 4; the second group is from port 5 to port 8. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
Ē	GND	Alarm input ground port.
NO1∼NO3	Alarm output port	• 3 groups of alarm output ports. (Group 1: port

Icon	Port Name	Function
C1~C3	1~3	 NO1 ~ C1,Group 2:port NO2 ~ C2,Group 3:port NO3~C3)).Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normal open alarm output port. C: Alarm output public end.
A	RS-485	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	communication port	RS485_B.lt is the cable B. You can connect to the control devices such as speed dome PTZ.
DC 12V 	Power input port	Input DC 12V/4A.
Power switch	/	Power on/off button.
PoE PORTS	/	 Bult-in Switch. Support PoE or ePoE function. For ePoE series product, port 1 to port 8 are the ePoE ports. ePoE port supports 300 meters@100Mbps, 800 meters@10Mbps. Port 9 to port 16 are general PoE ports. The 8 PoE series product supports total 130W. The 16 PoE series product supports total 130W.

2.2.9 Beneficio 1.5U / Beneficio 1.5U with 8 PoE ports/ Beneficio 1.5U with 16 PoE ports Series


The beneficio 1.5U series NVR rear panel is shown as below. See Figure 2-46.

Figure 2-46



The beneficio 1.5U with eight PoE ports series NVR rear panel is shown as below. See Figure 2-47.

Figure 2-47



The Beneficio 1.5U with sixteen PoE ports series NVR rear panel is shown as below. See Figure 2-48.

Figure 2-48




Table 2-23

Name		Function
Power switch	/	Power on-off button
Power input port	/	Input AC 100~240V.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
VIEDEO OUT	Video output port	CVBS output
1~16	Alarm input port 1∼16	• There are four groups. The first group is from port 1 to port 4, the second group is from port 5 to port 8, the third group is from 9 to 12, and the fourth group is from 13 to 16. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close).
		 When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
Ψ̈́.	Video output port	CVBS output
NO1~NO5	Alarm output port	• 5 groups of alarm output ports. (Group 1: port
C1~C5	1∼ 5	NO1~C1,Group 2:port NO2~C2,Group 3:port NO3~C3, Group 4: port NO4~C4, Group 5:
NC5		port NO5, C5, NC5). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device.
		NO: Normal open alarm output port.
		C: Alarm output public end.NC: Normal close alarm output port.
		• ING. INDITITAL CIUSE ALAITH OULPUL POIL.

Name		Function
А	RS-485	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	communication port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL 12V	/	Controller 12V power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
+12V	/	+12V power output port. It can provide the power to some peripheral devices such as the camera or the alarm device. Please note the supplying power shall be below 1A.
5 5	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
eSATA	eSATA port	External SATA port. It can connect to the device of the SATA port. Please jump the HDD when there is peripheral connected HDD.
•←	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.3
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	8 PoE ports	Built-in Switch. Support PoE. The 8 PoE ports series products supports total 48V 120W power. One PoE port max supports 15W.
PoE PORTS	16 PoE ports	Built-in Switch. Support PoE. The 16 PoE ports series products supports total 150W power. One PoE port max supports 15W.

2.2.10 Professional 4K 1.5U/ Professional 4K 1.5U with 16 PoE ports/ Professional 4K 2U / Professional 4K 2U with 16 PoE ports/4K 1.5U (S2) with 24 PoE ports/4K 1.5U (S2E) with 16 PoE Ports/4K 2U (S2E) with 16 PoE ports Series


The professional 4K 1.5U/ professional 4K 2U series rear panel is shown as below. See Figure 2-49.

Figure 2-49




The professional 4K 1.5U with 16 PoE ports / professional 4K 2U with 16 PoE ports series rear panel is shown as below. See Figure 2-50.

Figure 2-50




The 4K 1U (S2) with 24 PoE ports series rear panel is shown as below. See Figure 2-51.

Figure 2-51



The 4K 1.5U (S2E) with 16 PoE ports series rear panel is shown as below. See Figure 2-52.

Figure 2-52



The 4K 2U (S2E) with 16 PoE ports series rear panel is shown as below. See Figure 2-53.

Figure 2-53




Table 2-24

Name	Function
------	----------


Name		Function
	Power switch	Power on-off button
	Power input port	Input AC 100~240V.
50	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
eSATA	eSATA port	External SATA port. It can connect to the device of the SATA port. Please jump the HDD when there is peripheral connected HDD.
•←	USB3.0 port	USB3.0 port. Connect to mouse, USB storage device, USB burner and etc.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4b.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
1~16	Alarm input port 1∼16	 There are four groups. The first group is from port 1 to port 4, the second group is from port 5 to port 8, the third group is from 9 to 12, and the fourth group is from 13 to 16. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
Ť	Ground	Alarm input ground end.
NO1~NO5 C1~C5	Alarm output port 1∼5	● 5 groups of alarm output ports. (Group 1: port NO1~C1,Group 2:port NO2~C2,Group 3:port

Name		Function
NC5		 NO3~C3, Group 4: port NO4~C4, Group 5: port NO5, C5, NC5). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normal open alarm output port. C: Alarm output public end. NC: Normal close alarm output port.
А	RS-485	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	communication port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL 12V		Controller 12V power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
+12V	/	+12V power output port. It can provide the power to some peripheral devices such as the camera or the alarm device. Please note the supplying power shall be below 1A.
RS-232	RS232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	/	 Bult-in Switch. Support PoE or ePoE function. For ePoE series product, port 1 to port 8 are the ePoE ports. ePoE port supports 300 meters@100Mbps, 800 meters@10Mbps. Port 9 to port 16 are general PoE ports. The 16 PoE series product supports total 150W.

2.2.11 4K Smart 1U (S2) Series


The general 4K smart 1U (S2) series rear panel is shown as below. See Figure 2-54.

Figure 2-54



The 4K smart 1U (S2) with four PoE ports series rear panel is shown as below. See Figure 2-55.

Figure 2-55



The 4K smart 1U (S2) with eight PoE ports series rear panel is shown as below. See Figure 2-56.

Figure 2-56




Table 2-25

Port Name	Connection	Function
•←	USB port	USB port. Connect to mouse, USB storage device, USB burner and etc.
00	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
Ť	GND	Ground end
DC 12V D© IN -G- / =⊕=	Power input port	 Power socket. For general 4K smart 1U (S2): DC 12V/2A power. For 4K smart 1U (S2) with four PoE ports: DC 48V/72W power. For 4K smart 1U (S2) with eight PoE ports: DC 48V/96W power.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.

Port Name	Connection	Function
MIC OUT	Audio output	Audio output port. It is to output the analog audio signal to the devices such as the sound box.
	port	Bidirectional talk output.
		 Audio output on 1-window video monitor.
		 Audio output on 1-window video playback.
PoE PORT	PoE port	Built-in switch. Support PoE function.
	·	For PoE series product, you can use this port to provide power to the network camera.

2.2.12 Beneficio Vertical 1U Series

The interface is shown as in Figure 2-57.




Figure 2-57

Table 2-26


Name		Function
Power switch	/	Power on/off button.
=G≠	Power input port	Input DC 53V2.3A
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.

Name		Function
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor.
		Audio output on 1-window video playback. When your alarm input device is using external.
1~2	Alarm input port 1∼2	 When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
<u> </u>	GND	Alarm input ground port.
С	Alarm output public port	Alarm output public end.
NO	Normal open	Normal open alarm output port.
000	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
•	USB3.0 port	USB3.0 port. Connect to mouse, USB storage device, USB burner and etc.
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORT	/	Bult-in Switch. Support PoE. The 8 PoE series product supports total 48V 120W. One PoE port max supports 15W.

2.2.13 4K Compact 1U (S2) Series


The general 4K compact 1U (S2) series rear panel is shown as below. See Figure 2-58.

Figure 2-58



The 4K compact 1U (S2) with four PoE ports series rear panel is shown as below. See Figure 2-59.

Figure 2-59



The 4K compact 1U (S2) with eight PoE ports series rear panel is shown as below. See Figure 2-60.

Figure 2-60




Table 2-27


Port Name	Connection	Function
•=	USB port	USB port. Connect to mouse, USB storage device, USB burner and etc.
DC 12V DC IN -G- / Egs	Power input port	 Power socket. For general 4K compact 1U (S2): DC 12V/2A power. For 4K compact 1U (S2) with four PoE ports: DC 48V/72W power. For 4K compact 1U (S2) with eight PoE ports: DC 48V/96W power.
50	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.
•	USB port	USB port. Connect to mouse, USB storage device and etc.
НОМІ	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.

Port Name	Connection	Function
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box.
		Bidirectional talk output.
		Audio output on 1-window video monitor.
		Audio output on 1-window video playback.
÷	GND	Ground end
PoE	PoE port	Built-in switch. Support PoE function.
PORTS	·	For PoE series product, you can use this port to provide power to the network camera.

2.2.14 4K 1U (S2) Series


The general 4K 1U (S2) series rear panel is shown as below. See Figure 2-61.

Figure 2-61




The 4K 1U (S2) with four PoE ports series rear panel is shown as below. See Figure 2-62.

Figure 2-62



The 4K 1U (S2) with eight PoE ports series rear panel is shown as below. See Figure 2-63.

Figure 2-63



The 4K 1U (S2) with sixteen PoE ports series rear panel is shown as below. See Figure 2-64 and Figure 2-65

Figure 2-64




Figure 2-65




Table 2-28

Name		Function
	Power switch	Power on/off button.
DC 12V -G-	Power input port	Input DC 12V/4A. For general 4K 1U (S2) series product only.
DC 48V -G-		Switch power port. Input DC 48/96W For 4K 1U (S2) with four PoE ports series product only. Input AC90V~264V-12V5A/52V2.5A-190W. For 4K 1U (S2) with eight PoE ports/ 4K 1U (S2) with sixteen PoE ports series product only.
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
1~4	Alarm input port 1~4	 There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
Ψ	GND	Alarm input ground port.
N1, N2	Alarm output port	2 groups of alarm output ports. (Group 1: port
C1, C2	1~2	 NO1~C1,Group 2:port NO2~C2).Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normal open alarm output port. C: Alarm output public end.
А	RS-485 communication	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.

Name		Function
В	port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL		Controllable power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
Р	/	Power output port. It is to offer power to external devices such as cameras and alarm devices, and the current of the device power supply should be below 1A.
0 0	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
•=	USB port	USB port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	/	Bult-in Switch. Support PoE. For PoE series product, you can use this port to provide power to the network camera.

2.2.15 4K 1.5U (S2) Series

The general 4K 1.5U (S2) series rear panel is shown as below. See Figure 2-66.

Figure 2-66



The 4K 1.5U (S2) with sixteen PoE ports series rear panel is shown as below. See Figure 2-67 Figure 2-67




Table 2-29


Name		Function
Power switch	/	Power on-off button
Power input port	/	AC90V~264V-12V12.5A/-53V2.83A
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.
MIC OUT	Audio output port	 Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.
VIEDEO OUT	Video output port	CVBS output
1~16	Alarm input port 1~16	 There are four groups. The first group is from port 1 to port 4, the second group is from port 5 to port 8, the third group is from 9 to 12, and the fourth group is from 13 to 16. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
Ť	Video output port	CVBS output
NO1~NO5 C1~C5 NC5	Alarm output port 1~5	 5 groups of alarm output ports. (Group 1: port NO1~C1,Group 2:port NO2~C2,Group 3:port NO3~C3, Group 4: port NO4~C4, Group 5: port NO5, C5, NC5). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normal open alarm output port. C: Alarm output public end. NC: Normal close alarm output port.
А	RS-485 communication	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.

Name		Function
В	port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL 12V		Controller 12V power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
+12V	/	+12V power output port. It can provide the power to some peripheral devices such as the camera or the alarm device. Please note the supplying power shall be below 1A.
5 5	Network port	10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
eSATA	eSATA port	External SATA port. It can connect to the device of the SATA port. Please jump the HDD when there is peripheral connected HDD.
•←	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.3
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	PoE port	Built-in Switch. Support PoE. For PoE series product, you can use this port to provide power to the network camera.

2.2.16 Beneficio 2U/Beneficio 2U with 16 PoE ports Series

The beneficio 2U series NVR rear panel is shown as below. See Figure 2-68.

Figure 2-68



The beneficio 2U with 16 PoE ports series NVR rear panel is shown as below. See Figure 2-69.




Table 2-30

Name		Function	
Power switch	/	Power on-off button	
Power input port	/	Input AC 100~240V.	
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.	
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.	
VIEDEO OUT	Video output port	CVBS output.	
1~16	Alarm input port 1∼16	 There are four groups. The first group is from port 1 to port 4, the second group is from port 5 to port 8, the third group is from 9 to 12, and the fourth group is from 13 to 16. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close). When your alarm input device is using external 	
		power, please make sure the device and the NVR have the same ground.	
Ψ̄.	GND	Alarm input ground port.	
NO1~NO5	Alarm output port	• 5 groups of alarm output ports. (Group 1: port	
C1~C5	1~5	NO1~C1,Group 2:port NO2~C2,Group 3:port NO3~C3, Group 4: port NO4~C4, Group 5:	
NC5		port NO5, C5, NC5).Output alarm signal to the alarm device. Please make sure there is power to the external alarm device.	
		NO: Normal open alarm output port.	
		C: Alarm output public end.NC: Normal close alarm output port.	
		• INO. INOITHAL GIOSE ALAITH OULPUL POIL.	

Name		Function
Α	RS-485 communication	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL 12V	/	Controller 12V power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
+12V	/	+12V power output port. It can provide the power to some peripheral devices such as the camera or the alarm device. Please note the supplying power shall be below 1A.
55	Network port	One 10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
eSATA	eSATA port	External SATA port. It can connect to the device of the SATA port. Please jump the HDD when there is peripheral connected HDD.
•	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.3
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	16 PoE ports	Built-in Switch. Support PoE. The 16 PoE ports series products supports total 150W power. One PoE port max supports 15W.

2.2.17 4K 2U (S2) Series

The general 4K 2U (S2) series rear panel is shown as below. See Figure 2-70.

Figure 2-70



The 4K 2U (S2) with sixteen PoE ports series rear panel is shown as below. See Figure 2-71.

Figure 2-71




Table 2-31

Name		Function	
Power switch	/	Power on-off button	
Power input port	/	AC90V~264V-12V12.5A/-53V2.83A	
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.	
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.	
VIEDEO OUT	Video output port	CVBS output.	
1~16	Alarm input port 1∼16	• There are four groups. The first group is from port 1 to port 4, the second group is from port 5 to port 8, the third group is from 9 to 12, and the fourth group is from 13 to 16. They are to receive the signal from the external alarm source. There are two types; NO (normal open)/NC (normal close).	
		 When your alarm input device is using external power, please make sure the device and the NVR have the same ground. 	
<u> </u>	GND	Alarm input ground port.	
NO1~NO5	Alarm output port	• 5 groups of alarm output ports. (Group 1: port	
C1~C5	1~5	NO1~C1,Group 2:port NO2~C2,Group 3:port NO3~C3, Group 4: port NO4~C4, Group 5:	
NC5		port NO5, C5, NC5). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device.	
		NO: Normal open alarm output port.	
		C: Alarm output public end.NC: Normal close alarm output port.	

Name		Function
Α	RS-485 communication	RS485_A port. It is the cable A. You can connect to the control devices such as speed dome PTZ.
В	port	RS485_B.It is the cable B. You can connect to the control devices such as speed dome PTZ.
CTRL 12V	/	Controller 12V power output. It is to control the on-off alarm relay output. It can be used to control the device alarm output. At the same time, it can also be used as the power input source of some devices such as the alarm detector.
+12V	/	+12V power output port. It can provide the power to some peripheral devices such as the camera or the alarm device. Please note the supplying power shall be below 1A.
-	Network port	One 10M/100M/1000Mbps self-adaptive Ethernet port. Connect to the network cable.
eSATA	eSATA port	External SATA port. It can connect to the device of the SATA port. Please jump the HDD when there is peripheral connected HDD.
•—	USB port	USB port. Connect to mouse, USB storage device, USB burner and etc.
RS-232	RS-232 debug COM.	It is for general COM debug to configure IP address or transfer transparent COM data.
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.
PoE PORTS	PoE port	Built-in Switch. Support PoE. For PoE series product, you can use this port to provide power to the network camera.

2.2.18 Smart 1U 4K (S2) wih Wireless Series

The rear panel is shown as below. See Figure 2-72.

Figure 2-72




Table 2-32

Port Name	Connection	Function	
•	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, USB burner and etc.	
00	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.	
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.	
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.	
DC 12V -G-	Power input port	Input DC 12V/2A.	
WPS/RESET	Reset/WPS function	 Device Wi-Fi reset and WPS function button: Hold down this button for 5 seconds and above to restore Wi-Fi AP to defaults. Press this button for less than 2 seconds, and then press the WPS button of Wi-Fi IPC, the device and Wi-Fi IPC can be connected. 	

2.2.19 Compact 1U 4K (S2) wih Wireless Series

The rear panel is shown as below. See Figure 2-73.

Figure 2-73





Table 2-33

Icon	Name	Function	
DC 12V	Power input socket.	Power socket. Input DC12V/2A.	
0 0	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.	
•	USB2.0 port	USB2.0 port. Connect to mouse, USB storage device, and etc.	
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.	
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.	
÷	GND	Ground end	
WPS/RESET	Reset/WPS function	 Device Wi-Fi reset and WPS function button: Hold down this button for 5 seconds and above to restore Wi-Fi AP to defaults. Press this button for less than 2 seconds, and then press the WPS button of Wi-Fi IPC, the device and Wi-Fi IPC can be connected. 	


2.2.20 Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports / Compact 1U (S3) with 8 PoE Ports Series

The Cooper 1U (S3) NVR rear panel is shown as below. See Figure 2-74.

Figure 2-74



The Cooper 1U (S3) with 4 PoE Ports NVR rear panel is shown as below. See Figure 2-75. Figure 2-75



The Compact 1U (S3) with 8 PoE Ports NVR rear panel is shown as below. See Figure 2-76. Figure 2-76




Table 2-34

Port Name	Connection	Function	
DC 12V -G-	Power input port	Power socket.	
PoE	PoE port	Built-in switch. Support PoE function.	
PORTS		For PoE series product, you can use this port to provide power to the network camera.	
000	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.	
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.	
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.	
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box.	
		Bidirectional talk output.	
		Audio output on 1-window video monitor.	
		 Audio output on 1-window video playback. 	

Port Name	Connection	Function	
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device.	
•=	USB port	USB port. Connect to mouse, USB storage device and etc.	
Ē	GND	Ground end	

2.2.21 4/8ch Compact 1U Series

The 4/8ch Compact 1U series NVR rear panel is shown as below. See Figure 2-77.



Figure 2-77

Table 2-34

Icon	Name	Function	
DC 12V G-*	Power input socket.	Power socket.	
MIC IN	Audio input port	Bidirectional talk input port. It is to receive the analog audio signal output from the devices such as microphone, pickup.	
MIC OUT	Audio output port	Audio output port. It is to output the analog audio signal to the devices such as the sound box. Bidirectional talk output. Audio output on 1-window video monitor. Audio output on 1-window video playback.	
5 5	Network port	10M/100Mbps self-adaptive Ethernet port. Connect to the network cable.	

Icon	Name	Function	
•	USB2.0 port	USB2.0 port. Co nnect to mouse, USB storage device, and etc.	
HDMI	High Definition Media Interface	High definition audio and video signal output port. It transmits uncompressed high definition video and multiple-channel data to the HDMI port of the display device. HDMI version is 1.4.	
VGA	VGA video output port	VGA video output port. Output analog video signal. It can connect to the monitor to view analog video.	
Ť	GND	Ground end	

2.3 Alarm Connection

2.3.1 Alarm Port

The alarm port is shown as below. See Figure 2-78. The following figure for reference only.

Figure 2-78




Table 2-35

Icon	Function
1~16	ALARM1~ALARM16. The alarm becomes activated in the low level.
NO1 C1,	Four NO activation output groups. (On-off button).
NO2 C2,	
NO3 C3,	
NO4 C4	
NO5 C5	One NO/NC activation output group. (On-off button).
NC5	
CTRL 12V	Control power output. Disable power output when alarm is canceled. Current is
	500mA.
+12V	Rated current output. Current is 500mA.
Ť	GND
A/B	485 communication port. They are used to control devices such as PTZ. Please
	parallel connect 120TΩ between A/B cables if there are too many PTZ
	decoders.

Note


- Different models support different alarm input ports. Please refer to the specifications sheet for detailed information.
- Slight difference may be found on the alarm port layout.

2.3.2 Alarm input port

Connect the positive end (+) of the alarm input device to the alarm input port (ALARM IN 1~16) of the

NVR. Connect the negative end (-) of the alarm input device to the ground end (=) of the NVR.

Figure 2-79



NOTE

- There are two alarm input types: NO/NC.
- When connect the ground port of the alarm device to the NVR, you can use any of the GND ports
- Connect the NC port of the alarm device to the alarm input port (ALARM) of the NVR.
- When there is peripheral power supplying for the alarm device, please make sure it is earthed with the NVR.

2.3.3 Alarm input and output port

- There is peripheral power supplying for the external alarm device.
- In case overload may result in NVR damage, please refer to the following relay specifications for detailed information.
- A/B cable of the RS485 is for the A/B cable connection of the speed PTZ.

2.3.4 Alarm relay specifications

Table 2-36

Model:	JRC-27F	
Material of the	Silver	
touch		
Rating	Rated switch capacity	30VDC 2A, 125VAC 1A

(Resistance Load)	Maximum switch power	125VA 160W
	Maximum switch voltage	250VAC, 220VDC
	Maximum switch currency	1A
Insulation	Between touches with same polarity	1000VAC 1minute
	Between touches with different polarity	1000VAC 1minute
	Between touch and winding	1000VAC 1minute
Surge voltage	Between touches with same polarity	1500V (10×160us)
Length of open time	3ms max	
Length of close time	3ms max	
Longevity	Mechanical	50×106 MIN (3Hz)
	Electrical	200×103 MIN (0.5Hz)
Temperature	-40℃ - +70℃	

2.4 Bidirectional talk

2.4.1 Device-end to PC-end


Device Connection

Please connect the speaker or the pickup to the first audio input port in the device rear panel. Then connect the earphone or the sound box to the audio output port in the PC.

Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the following interface to enable bidirectional talk. See Figure 2-80.


Figure 2-80



Listening Operation

At the device end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the pc-end. See Figure 2-81.

Figure 2-81



2.4.2 PC-end to the device-end

Device Connection

Connect the speaker or the pickup to the audio output port in the PC and then connect the earphone or the sound box to the first audio input port in the device rear panel.


Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the above interface (Figure 2-80) to enable bidirectional talk.

Listening Operation

At the PC-end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the device-end. See Figure 2-82.

Figure 2-82



2.5 Mouse Operation

Table 2-37

Operation	Description	
Left click	When you have selected one menu item, left click mouse to view menu	
mouse	content.	
	Modify checkbox or motion detection status.	
	Click combo box to pop up dropdown list	

In input box, you can select input methods. Left click the corresponding button on the panel you can input numeral/English character (small/capitalized). Here ← stands for backspace button. __ stands for space button. In English input mode: stands for input a backspace icon and ← stands for deleting the previous character. 3 5 6 8 9 Enter 0 & Shift 3 5 6 8 9 0 & Shift In numeral input mode: __ stands for clear and ← stands for deleting the previous numeral. Double left Implement special control operation such as double click one item in the file click mouse list to playback the video. In multiple-window mode, double left click one channel to view in full-window. Double left click current video again to go back to previous multiple-window mode. Right click In real-time monitor mode, pops up shortcut menu. mouse Exit current menu without saving the modification. Press In numeral input box: Increase or decrease numeral value. middle Switch the items in the check box. button Page up or page down Move Select current control or move control mouse Select motion detection zone Drag mouse Select privacy mask zone.

2.6 Remote Control

The remote control interface is shown as in Figure 2-83.

Please note remote control is not our standard accessory and it is not included in the accessory bag.




Table 2-38


No.	Name	Function
1	Power button	Press this button to boot up or shut down the device.
2	Address	Press this button to input device serial number, so that you can
_		control the Device.
3	Forward	Multi-step forward speed and normal speed playback.
4	Slow motion	Multi-step slow motion speed or normal playback.
5	Next record	In playback state, press this button to play back the next video.
6	Previous record	In playback state, press this button to play back the previous
Ü	T TOVIOUS TOCOTO	video.
7	Play/Pause	 In normal playback state, press this button to pause playback. In pause state, press this button to resume to normal playback. In live view window interface, press this button to enter video search menu.
8	Reverse/pause	In the reverse playback state, press this button to pause reverse playback.
		In the reverse playback pause state, press this button to resume
		to playback reversing state.
9	Esc.	Go back to previous menu or cancel current operation (close
		front interface or control).

No.	Name	Function	
10	Record	 Start or stop record manually. In record interface, use the direction buttons to select the channel that you want to record. Press this button for at least 1.5 seconds, and the manual record interface will be displayed. 	
11	Direction keys	Switch between current activated controls by going left or right. In playback state, the keys control the playback progress bar. Aux function (such as operating the PTZ menu).	
12	Enter/menu key	 Confirms an operation. Go to the OK button. Go to the menu. 	
13	Multiple-window switch	Switch between multiple-window and one-window.	
14	Fn	 In single-channel monitoring mode, press this button to display the PTZ control and color setting functions. Switch the PTZ control menu in PTZ control interface. In motion detection interface, press this button with direction keys to complete setup. In text mode, press and hold this button to delete the last character. To use the clearing function: Long press this button for 1.5 seconds. In HDD menu, switch HDD recording time and other information as indicated in the pop-up message. 	
15	Alphanumeric keys	 Input password, numbers. Switch channel. Press Shift to switch the input method. 	

Note: All the installation and operations here should conform to your local electric safety rules.

3.1 Device Installation Diagrams

Please refer to the following diagrams to install the NVR.



3.2 Check Unpacked NVR

When you receive the NVR from the forwarding agent, please check whether there is any visible damage. The protective materials used for the package of the NVR can protect most accidental clashes during transportation. Then you can open the box to check the accessories.

Please check the items in accordance with the list. Finally you can remove the protective film of the NVR.

3.3 About Front Panel and Rear Panel

The model number in the stick on the bottom of NVR is very important; please check according to your purchase order.

The label in the rear panel is very important too. Usually we need you to represent the serial number when we provide the service after sales.

3.4 HDD Installation

For the first time installation, make sure whether the HDD has been installed or not. We recommend to use HDD of enterprise level or surveillance level. It is not recommended to use PC HDD.



CAUTION

- Shut off the power before you replace the HDD.
- Use the dedicated SATA HDD for monitoring recommended by the HDD manufacturer.
- You can refer to the Appendix for HDD space information and recommended HDD brand.

3.4.1 Smart 1U Series

Note

Connect cable and then secure the HDD on the NVR if it is not convenient to connect the HDD data cable and power cable at first.



①. Loosen the screws of the bottom of the chassis.



② Place the HDD in accordance with the four holes in the bottom.



Turn the device upside down and then secure the screws firmly.



④ Connect the HDD cable and power cable to the HDD and the mainboard respectively.



⑤ Put the cover back and then fix the screws of the rear panel. The installation is complete.

3.4.2 Mini 1U/Cooper 1U/Compact 1U Series



①. Loosen the screws of the upper cover and side panel.




② Connect the one end of the HDD data cable and the power cable to the mainboard.



③ Connect the other end of the HDD data cable and the power cable to the HDD.



Place the HDD in accordance with the four holes on the bottom of the chassis.



(5) Turn the device upside down; fix the screws to secure the HDD on the bottom of the chassis.



6 Put the cover in accordance with the clip and then fix the screws on the rear panel and side panel.

3.4.3 1U Series

The following figures are based on the professional 1U with 8 PoE ports series.

Connect cable and then secure the HDD on the NVR if it is not convenient to connect the HDD data cable and power cable at first.



① Loosen the screws of the rear panel and side panel.



②Place the HDD in accordance with the four holes in the bottom.



3)Turn the device upside down and then secure the screws firmly. It is to fix the HDD on the chassis.



(4)Connect the HDD cable and power cable.



5) Put the cover in accordance with the clip and then fix the screws on the rear panel and side panel.

3.4.4 1.5U Series



(1) Use the screwdriver to loose the screws of the rear (2) Put the HDD to the HDD bracket in the chassis

panel and then remove the front cover.



3 Connect to the HDD data cable to the main board and the HDD port respectively. Loosen the power cable of the chassis and connect another end of the power cable to the HDD port. and then line up the four screws to the four holes in the HDD. Use the screwdriver to fix the screws firmly to secure HDD on the HDD bracket



(4) After connect the cable, put the front cover back to the device and then fix screws of the rear panel.

3.4.5 General 2U Series



 Use the screwdriver to loose the screws of the rear panel and then remove the front cover.



② Put the HDD to the HDD bracket in the chassis and then line up the four screws to the four holes in the HDD. Use the screwdriver to fix the screws firmly to secure HDD on the HDD bracket




③Connect to the HDD data cable to the main board and the HDD port respectively. Loosen the power cable of the chassis and connect another end of the power cable to the HDD port.



④ After connect the cable, put the front cover back to the device and then fix screws of the rear panel.

3.4.6 Beneficio Vertical 1U Series



①Use 4 screws to secure the HDD



③Pull the HDD knob up when you put the HDD into the box in case the knob buckle may strike the front panel.




②Put the HDD to the HDD box at the front.




4 Put the knob back after you insert the HDD to the SATA board.

3.5 CD-ROM Installation

Please follow the steps listed below.



(1) Open top cover and then remove the HDD bracket



bracket.



(2) Take off the bottom of the HDD bracket and CD-ROM bracket.



(3) Fix the CD-ROM bracket at the HDD (4) Install a pair of the CD-ROM bracket. Please make sure the reverse side is secure too.




(5) Install SATA burner. Line up the SATA burner to the hole positions.



6 User screwdriver to fix the screws.



Put the bracket back. Please adjust the CD-ROM to the proper position so that the button of the front panel is directly facing the pop-up button of the CD-ROM.



8 Connect the SATA cable and power wire.



Secure the HDD bracket and put the top cover back.


3.6 Connection Sample

3.6.1 Beneficio Smart 1U/Beneficio Smart 1U(S2)/ 4K Smart 1U (S2) Series

Please refer to Figure 3-1 for connection sample.

The following figure for reference only.

Figure 3-1




3.6.2 Beneficio Mini 1U / Beneficio Mini 1U with 4 PoE Ports / Beneficio mini 1U with 8 PoE Ports Series

Please refer to Figure 3-2 for connection sample.

The following figure for reference only.


Figure 3-2



3.6.3 Smart 1U / Compact 1U Wireless Series

Please refer to Figure 3-3 for connection sample.


The following figure for reference only.



3.6.4 Compact 1U (S2) /4K Compact 1U (S2) / Cooper 1U (S3) / Cooper 1U (S3) with 4 PoE Ports / Compact 1U (S3) with 8 PoE Ports Series

Please refer to Figure 3-4 for connection sample.


The following figure for reference only.



3.6.5 Beneficio 1U (S2) Series

Please refer to Figure 3-5 for connection sample.

The following figure for reference only.



3.6.6 Beneficio Entry-level 1U Series

Please refer to Figure 3-6 for connection sample.

Figure 3-6

VGA Output Talk Output

Power on/off
Button

USB Port Power Socket GND


Bidirectional HDMI Output

Talk Input

Network User Network User Network User Network Revipograf

3.6.7 Beneficio 1U/Professional 4K 1U/ Professional 4K 1U with 8 PoE ports/ Professional 4K 1U with 16 PoE ports/4K 1U (S2) with 24 PoE Ports/4K 1U (S2E) with 8 PoE Ports/4K 1U (S2E) with 16 PoE Ports Series


Please refer to Figure 3-7 for connection sample. The following figure for reference only.



3.6.8 General 4K 1U (S2)/Beneficio 4K 1U with 8 PoE ports/4K 1U (S2) with 4 PoE ports/4K 1U (S2) with 8 PoE ports/4K 1U (S2) with 16 PoE ports Series


Please refer to Figure 3-8 for connection sample. The following figure for reference only.

Figure 3-8



3.6.9 Professional 4K 1.5U/ Professional 4K 1.5U with 16 PoE ports/ Professional 4K 2U / Professional 4K 2U with 16 PoE ports/4K 1.5U (S2E) with 16 PoE ports/4K 2U (S2E) with 16 PoE Ports Series


Please refer to Figure 3-8 for connection sample. The following figure for reference only.



3.6.10 Beneficio 1.5U / Beneficio 1.5U with 8 PoE ports / Beneficio 1.5U with 16 PoE ports/4K 1.5U (S2) Series

The following figure for reference only.

Figure 3-10




3.6.11 4K 2U (S2) Series

Please refer to Figure 3-11 for connection sample.


The following figure for reference only.

Figure 3-11



3.6.12 Beneficio Vertical 1U Series

Please refer to Figure 3-12 for connection sample.



4 Local Basic Operation



Slight difference may be found on the user interface. The following figures for reference only.

4.1 Getting Started

This chapter introduces device initial settings such as boot up, device initialization, reset password, and quick settings.

4.1.1 Boot up



- For device security, connect the NVR to the power adapter first and then connect the device to the power socket.
- The rated input voltage matches the device power button. Make sure the power wire connection is OK. Then click the power button.
- Always use the stable current, if necessary UPS is a best alternative measure.
- Step 1 Connect the device to the monitor and then connect a mouse.
- Step 2 Connect power cable.
- Step 3 Click the power button at the front or rear panel and then boot up the device. After device booted up, the system is in multiple-channel display mode by default.

4.1.2 Device Initialization

If it is your first time to use the device, set a login password of **admin** (system default user). You can select to use unlock pattern to login or not at your own choosing.




For your device safety, keep your login password of **admin** well after the initialization steps, and change the password regularly.

Step 1 Boot up NVR.

The **Device Initialization** interface is displayed. See Figure 4-1.

Figure 4-1



<u>Step 2</u> Set system time zone according to the actual environment. Refer to Table 4-4 in "4.1.4.1.2 Date and Time" for detailed information.


Click to shut down the device. It is suitable for the system integrator or the user to shut down directly after setting the time zone.

Step 3 Click Next.

 \square

The **Device Initialization** interface is displayed. See Figure 4-2.

Figure 4-2



<u>Step 4</u> Set login password of **admin**. See Table 4-1. Table 4-1

Parameter	Description
User	By default, the user is admin .
Password	In the Password box, enter the password for admin. The new password can be set from 8 characters through 32
Confirm Password	characters and contains at least two types from number, letter and special characters (excluding"", """, ";", ":" and "&").
Prompt Question	In the Prompt Question box, enter the information that can remind you of the password. NOTE
a rempt gassion	On the login interface, click , the prompt will display to help you reset the password.


<u>\(\) \(\) \(\) \(\)</u>

For your device own safety, create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

Step 5 Click **Next**.

The Unlock Pattern interface is displayed. See Figure 4-3.

Figure 4-3




Step 6 Set unlock pattern.

After set unlock pattern, the **Password Protection** interrface is displayed. See Figure 4-4.

- \bigcap
- The pattern that you want to set must cross at least four grids.
- If you do not want to configure the unlock pattern, click **Skip**.
- Once you have configured the unlock pattern, the system will require the unlock pattern as the default login method. If you skip this setting, enter the password for login.

Figure 4-4



Step 7 Set security questions. See Table 4-2.

- After configuration, if you forgot the password for admin user, you can reset the password through the reserved email address or security questions. For details about resetting the password, see "4.1.3 Reset Password".
- If you do not want to configure the settings, disable the email address and security questions functions on the interface.

Table 4-2

Password Protection Mode	Description
Email Address	Enter the reserved email address. In the Email Address box, enter an email address for password reset. If you forget the password, enter the security code that you will get from this reserved email address to reset the password of admin . Refer to " 4.16.1.2 Modify Password" for detailed information.
Security Questions	Configure the security questions and answers. If you forget the password, enter the answers to the questions can allow you reset the password. Refer to " 4.16.3 Reset Password " for detailed information.

Step 8 Click **Save** to complete the device initialization setup.

<u>Step 9</u> Device goes to startup wizard interface. Refer to "4.1.4 Quick Settings" for detailed information.

4.1.3 Reset Password

You can reset the password by the following methods when you forgot the password for admin account.

- If the password reset function is enabled, you can use mobile phone to scan the QR code to reset the password. For details, see "4.1.3.2 Resetting Password on Local Interface."
- If the password reset function is disabled, there are two situations:
 - If you configured security questions, you can reset the password by the security questions.

If you did not configure the security questions, you can only use the reset button on the mainboard to restore the Device to factory default.

Reset button is for some series product only.


4.1.3.1 Enabling Password Reset Function

After enabling password reset function, you can scan QR code on the local menu to reset password.

Step 1 Select Main Menu > Account > Reset Password.

The **Reset Password** interface is displayed. See Figure 4-5.

Figure 4-5



Step 2 Check the box to enable reset function.

This function is enabled by default.

Step 3 Click **Apply** to set settings.

If the password reset function is disabled, you can follow the ways listed below to reset password.

- Device supports Reset button on the main board: You can answer the security question on the local menu or click the Reset button on the main board to reset password. Refer to "4.1.3.3 Reset Button "for detailed information.
- Device does not support Reset button on the main board: You can only answer the security question on the local menu to reset password. (Make sure you have set security questions).

4.1.3.2 Resetting Password on Local Interface

Step 1 Enter the SYSTEM LOGIN interface.

 If you have configured unlock pattern, the unlock pattern login interface is displayed. See Figure 4-6. Click Forgot Pattern, the password login interface is displayed. See Figure 4-7.

• If you did not configure unlock pattern, the **System Login** interface is displayed. See Figure 4-7.

To login from other user account, on the unlock pattern login interface, click **Switch User**, or on the password login interface, in the **Switch User** list, select other user to login.

Figure 4-6





Figure 4-7



Step 2 Click

- If you have set the reserved email address, the Prompt interface is displayed. See Figure 4-8.
- If you did not set the reserved email address, the email entering interface is displayed. See Figure 4-9.
- Enter the email address, and then click **Next**, the Prompt message interface is displayed. See Figure 4-8.

Figure 4-8





Figure 4-9




Step 3 Click Next.

The **Reset Password** interface is displayed. See Figure 4-10.



After clicking **Next**, the system will collect your information for password reset, purpose and the information includes but not limited to email address, MAC address, and device serial number. Read the prompt carefully before clicking **Next**.

Figure 4-10



Step 4 Reset the password.

QR code

Follow the onscreen instructions to get the security code in your reserved email address. In the Security code box, enter the security code.



- You can get the security code twice by scanning the same QR code. If you need to get the security code once again, refresh the interface.
- Use the security code received in your email box to reset the password within 24 hours; otherwise the security code becomes invalid.
- Security questions

On the **Reset password** interface as shown in Figure 4-11, in the **Reset Type** list, select **Security Questions**, the Security Questions interface is displayed.



If you did not configure the security questions before, in the **Reset Type** list, there is no **Security Questions**.

Reset Type Security Questions

Question 1 What is your favorite children's book?

Answer

Question 2 What was the first name of your first boss?

Answer

Question 3 What is the name of your favorite fruit?

Answer

Figure 4-11

Step 5 Click Next.

The **Reset Password** interface is displayed. See Figure 4-12. Figure 4-12

Reset Password		
Reset password of (admin)	
New Password		
	Use a password that has 8 to 32 characters, it can be a combination of letter(s), number(s) and symbol(s) with at least two kinds of them.(please do not use special symbols like ' ";: &)	
Confirm Password		
	Save Cancel	

- Step 6 In the **New Password** box, enter the new password and enter it again in the **Confirm Password** box.
- Step 7 Click Save. The password resetting is complete.
 A pop-up message is displayed asking if you want to sync the password with the remote devices. See Figure 4-13.




Figure 4-13

4.1.3.3 Reset Button

You can always use the reset button on the mainboard to reset the Device to the factory default

settings.

 \square

Reset button is for some series products only.

- <u>Step 1</u> Disconnect the Device from power source, and then remove the cover panel. For details about removing the cover panel, see "3.4 HDD Installation."
- Step 2 Find the reset button on the mainboard, and then connect the Device to the power source again.
- Step 3 Press and hold the reset button for 5 seconds to 10 seconds. See Figure 4-14 for the location of the reset button.

Figure 4-14



Step 4 Reboot the Device.

After the Device is rebooted, the settings have been restored to the factory default. You can start resetting the password.


4.1.4 Quick Settings

After you successfully initialized the device, it goes to startup wizard. Here you can quickly configure your device. Click **Next**, device goes to **General** interface.



The startup wizard interface only displays after you first login the device and have set the admin password. See Figure 4-15.

Figure 4-15



- If you select the **Auto-check for updates** check box, the system will notify you automatically when updates are available.
- After the auto-check function is enabled, to notify you to update timely, the system will
 collect the information such as IP address, device name, firmware version, and device
 serial number. The collected information is only used to verify the legality of the Device and
 push upgrade notices.
- If you cancel the **Auto-check for updates** check box, the system will not perform automatic checks.

4.1.4.1 General

You can set NVR basic information such as system date, holiday and etc. You can also configure general settings by selecting **Main Menu** > **SYSTEM** > **General**.

4.1.4.1.1 General

You can set device basic information such as device name, serial number.

Step 1 Click Next.

The **General** interface is displayed. See Figure 4-16.

Figure 4-16

General		
Device Name	NVR	
Device No.	8	
Language	ENGLISH ▼	
Video Standard	PAL ▼	
Sync to Remote Device	(Include language,	
Instant Replay(Min.)	5	
Auto Logout(Min.)	10	Monitor Channel(s) when logout
IPC Time Sync		
IPC Time Sync Period (hour)	24	
Navigation Bar		
Mouse Sensitivity		-+
	Slow	Fast
		Back Next

Step 2 Set parameters. See Table 4-3.

Table 4-3

Parameter	Description
Device Name	In the Device Name box, enter the Device name.
Device No.	In the Device No. box, enter a number for the Device.
Language	In the Language list, select a language for the Device system.
Video Standard	In the Video Standard list, select PAL or NTSC according to your actual situation.
Sync to Remote Device	Enable this function; the NVR can synchronize information with the remote device such as Language, video standard, time zone.
Instant Play (Min.)	In the Instant Play box, enter the time length for playing back the recorded video. The value ranges from 5 to 60. On the live view control bar, click the instant playback button to play back the recorded video within the configured time.
Auto Logout (Min.)	In the Auto Logout box, enter the standby time for the Device. The Device automatically logs out when it is not working for the configured time period. You need to login the Device again. The value ranges from 0 to 60. 0 indicates there is not standby time for the Device. Click Monitor Channel(s) when logout . You can select the channels that you want to continue monitoring when you logged out.
IPC Time Sync	Syncs the Device time with IP camera.
IPC Time Sync Period (hour)	In the IPC Time Sync Period box, enter the interval for time sync.
Auto logout	You can set auto logout interval once login user remains inactive for a specified time. Value ranges from 0 to 60 minutes.
Navigation Bar	Enable the navigation bar. When you click on the live view screen, the navigation bar is displayed.

Parameter	Description
Mouse Sensitivity	Adjust the speed of double-click by moving the slider. The bigger the value is, the faster the speed is.

Step 3 Click **Next** button to save settings.


4.1.4.1.2 Date and Time

You can set device time. You can enable NTP (Network Time Protocol) function so that the device can sync time with the NTP server.

You can also configure date and time settings by selecting **Main Menu > SYSTEM > GENERAL > Date&Time.**

Step 1 Click **Date & Time** tab. See Figure 4-17.

Figure 4-17



<u>Step 2</u> Configure the settings for date and time parameters. See Table 4-4. Table 4-4

Parameter	Description
System Time	In the System Time box, enter time for the system. Click the time zone list, you can select a time zone for the system, and the time in adjust automatically.
	Do not change the system time randomly; otherwise the recorded video cannot be searched. It is recommended to avoid the recording period or stop recording first before you change the system time.
System Zone	In the System Zone list, select a time zone for the system.
Date Format	In the Date Format list, select a date format for the system.
Date Separator	In the Date Separator list, select a separator style for the date.
Time Format	In the Time Format list, select 12-HOUR or 24-HOUR for the time display style.
DST	Enable the Daylight Saving Time function. Click Week or click Date.

Parameter	Description
Start Time	Configuration and and time for the DCT
End Time	Configure the start time and end time for the DST.
NTP	Enable the NTP function to sync the Device time with the NTP server.
	If NTP is enabled, device time will be automatically synchronized with server.
Server	In the Server box, enter the IP address or domain name of the corresponding NTP server. Click Manual Update , the Device starts syncing with the server immediately.
Port	The system supports TCP protocol only and the default setting is 123.
Interval (Min.)	In the Interval box, enter the amount of time that you want the Device to sync time with the NTP server. The value ranges from 0 to 65535.

Step 3 Click **Next** button to save settings.

4.1.4.1.3 Holiday

Here you can add, edit, delete holiday. After you successfully set holiday information, you can view holiday item on the record and snapshot period.

You can also configure holiday settings by selecting **Main Menu > SYSTEM > GENERAL > Holiday**.

Step 1 Click Next.

The **Holiday** interface is displayed. See Figure 4-18.





Figure 4-18

Step 2 Click **Add Holidays** button, the **Add Holidays** interface is displayed. See Figure 4-19.

Figure 4-19



- Step 3 Set holiday name, repeat mode and holiday mode.
 - Click **Add more** to add new holiday information.

Step 4 Click **Add** button, you can add current holiday to the list.

- Click the dropdown list of the state; you can enable/disable holiday date.
- Click to change the holiday information. Click to delete current date.

Step 5 Click **Next** button to save settings.

4.1.4.2 Basic Network Settings

You can set device IP address, DNS (Domain Name System) information. You can also configure basic network settings by selecting **Main Menu > NETWORK > TCP/IP**.

Preparation


Make sure the device has properly connected to the network.

Step 1 Click Next.

The **TCP/IP** interface is displayed.

Different series products have different Ethernet adapter amount and type. Refer to the actual product.


Figure 4-20



Step 2 Click

The **Edit** interface is displayed. See Figure 4-21.

Figure 4-21



Step 3 Set parameters. See Table 4-5.

Table 4-5

Parameter	Description	
Net Mode	Multi-address: Two Ethernet ports work separately through either of which you can request the Device to provide the services such as HTTP and RTSP. You need to configure a default Ethernet port (usually the Ethernet port 1 by default) to request the services from the device end such as DHCP, Email and FTP. If one of the two Ethernet ports is disconnected as detected by networking testing,	

Parameter	Description
	 the system network status is regarded as offline. Fault Tolerance: Two Ethernet ports share one IP address. Normally only one Ethernet port is working and when this port fails, the other port will start working automatically to ensure the network connection. When testing the network status, the network is regarded as offline only when both of the two Ethernet ports are disconnected. The two Ethernet ports are used under the same LAN. Load Balance: Two network cards share one IP address and they are working at the same time to share the network load averagely. If one of them fails, the other can continue working normally. When testing the network status, the network is regarded as offline only when both of the two Ethernet ports are disconnected. The two Ethernet ports are used under the same LAN.
Default Ethernet Port	In the Ethernet Card list, select an Ethernet port as a default port. This setting is available only when the Multi-address is selected in the Net Mode list.
IP Version	In the IP Version list, you can select IPv4 or IPv6 . Both versions are supported for access.
MAC Address	Displays the MAC address of the Device.
DHCP	 Enable the DHCP function. The IP address, subnet mask and default gateway are not available for configuration once DHCP is enabled. If DHCP is effective, the obtained information will display in the IP Address box, Subnet Mask box and Default Gateway box. If not, all values show 0.0.0.0. If you want manually configure the IP information, disable the DHCP function first. If PPPoE connection is successful, the IP address, subnet mask, default gateway, and DHCP are not available for configuration.
IP Address	Enter the IP address and configure the corresponding subnet mask and
Subnet Mask	default gateway.
Default Gateway	IP address and default gateway must be in the same network segment.
DNS DHCP	Enable the DHCP function to get the DNS address from router.
Preferred DNS	In the Preferred DNS box, enter the IP address of DNS.
Alternate DNS	In the Alternate DNS box, enter the IP address of alternate DNS.
MTU	In the MTU box, enter a value for network card. The value ranges from 1280 byte through 1500 byte. The default is 1500.
Test Step 4 Click OK to	Click Test to test if the entered IP address and gateway are interworking.

Step 4 Click OK to NIC settings.

Device goes back to **TCP/IP** interface.

<u>Step 5</u> Set network parameters. See Table 4-6.

Table 4-6

Parameter	Description
IP Version	There are two options: IPv4 and IPv6. Right now, system supports these two IP address format and you can access via them.
Preferred DNS server	DNS server IP address.
Alternate DNS server	DNS server alternate address.
MAC Address	Displays the MAC address of the Device.
DHCP	 Enable the DHCP function. The IP address, subnet mask and default gateway are not available for configuration once DHCP is enabled. If DHCP is effective, the obtained information will display in the IP Address box, Subnet Mask box and Default Gateway box. If not, all values show 0.0.0.0. If you want manually configure the IP information, disable the DHCP function first. If PPPoE connection is successful, the IP address, subnet mask, default gateway, and DHCP are not available for configuration.
LAN download	System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed. • For IPv6 version, the IP address, default gateway, preferred DNS; alternate DNS is 128-digit. Fill in all items here. • This function is for some series product only.

Step 6 Click **Next** to complete the settings.

4.1.4.3 P2P

Scan the QR code, download the App to the cell phone, you can use the smart phone to add the device.

- Scan the QR code on the actual interface to download the cell phone app. Register an
 account and then use.
- Go to the www.easy4ip.com to register an account and use the SN to add a device. Refer to the P2P operation manual for detailed information.


Before using the P2P function, make sure that the NVR has connected to the WAN.

Step 1 Click **Next** button.

The **P2P** interface is displayed. See Figure 4-22.

Select Main Menu > Network > P2P, you can go to P2P interface too.

Figure 4-22



Step 2 Check the box to enable P2P function.

After the P2P function is enabled and connected to the Internet, the system will collects your information for remote access, and the information includes but not limited to email address, MAC address, and device serial number.


Step 3 Click **Next** button to complete setup.

The status is online if the P2P registration is successful.

Client Operation

- Step 1 Use your cell phone to scan the QR code under Cell Phone Client to download the application.
- Step 2 On your cell phone, open the application, and then tap
- Step 3 The menu is displayed. You can start adding the device.
 - Tap Device Manager.
 The Device Manager interface is displayed. See Figure 4-23.

Figure 4-23




- 2) Tap on the top right corner.

 The interface requiring device initialization is display.
 - The interface requiring device initialization is displayed. A pop-up message reminding you to make sure the Device is initialized is displayed.
- 3) Tap **OK**.
 - ♦ If the Device has not been initialized, Tap **Device Initialization** to perform initializing by following the onscreen instructions.
 - ♦ If the Device has been initialized, you can start adding it directly.
- 4) Tap Add Device.

The **Add Device** interface is displayed. See Figure 4-24.


You can add wireless device or wired device. The Manual takes adding wired device as an example.

Figure 4-24



5) Tap **P2P.**The **P2P** interface is displayed. See Figure 4-25.

Figure 4-25




- 6) Enter a name for the NVR, the username and password, scan the QR code under **Device SN**.
- 7) Tap **Start Live Preview**.

 The Device is added and displayed on the live view interface of the cell phone.

 See Figure 4-26.

Figure 4-26



4.1.4.4 Registration



If you do not select Smart add function during the initialization process, go to the remote Device interface to register a remote device.

After adding remote device, the device can receive, store, and manage the video streams of the remote device. You can view, browse, play back and manage several remote devices at the same time.


Step 1 On the **P2P** interface, click **Next** button.

The **REGISTRATION** interface is displayed. See Figure 4-27.

There are two ways to go to Registration interface.

- Select Main Menu > CAMERA > REGISTRATION > Camera Registration, you can go to the Camera Registration interface.
- On the preview interface, right click mouse and then select Camera Registration.

Figure 4-27



Step 2 Register remote device.

 \square

- Search and then add
- 1) Click Device Search.
 - System displays searched devices at the upper pane.
- 2) Double-click a remote device, or select a remote device and then click **Add** to register it to the **Added Device** list.
- 3) . Refer to
- 4) Table 4-7 to set parameters.

The search results do not display the remote camera that has registered to the system

Figure 4-28





Table 4-7

Parameter	Description
Uninitialized	Enable the Uninitialized function, the uninitialized devices out of the searched devices are displayed in the searched device list.
Initialize	Select the uninitialized device from the uninitialized device list, and the click Initialize to start initializing device.
Show Filter	 In the Show Filter list, select the remote device type that you want to display in the searched device list. None: Display all types of devices. IPC: Display the front-end devices. DVR: Display all storage devices such as NVR, DVR and HCVR. OTHER: Display the devices that do not belong to IPC or DVR type.
Searched Device List	Displays the searched devices. You can view the device information such as status, IP address.
Device Search	Click Device Search , the searched devices display in the searched device list. To adjust the display sequence, in the title line, you can click the IP address, Manufacturer, Type, MAC Address, Port, or Device Name text. For example, click the IP address text, the sequence icon IP Address is displayed. "*" is displayed next to the added device.
Add	In the Searched Device List area, select the device that you want to add.
Manual Add	Add the device by manually configuring settings such as IP address, channel selection.

Parameter	Description
Added Device List	Displays the added devices. You can edit and delete the device, and view the device information.
Delete	Select the check box of the added device, and then click Delete to delete the added device.
Import	Select the searched devices and then click Import to import the devices in batches.
Export	Select the added devices and then click Export . The exported devices information is saved into the USB storage device.

- Manual Add
- 1) Click Manual Add.
 - The Manual Add interface is displayed. See Figure 4-29.

Figure 4-29



2) Configure parameters. See Table 4-8.

Table 4-8


Parameter	Description
Channel	In the Channel list, select the channel that you want use on the
Onamici	Device to connect the remote device.
Manufacturer	In the Manufacturer list, select the manufacturer of the remote
Mandiacturer	device.
	In the IP Address box, enter the IP address of remote device.
IP Address	
	The default is 192.168.0.0 which the system cannot connect to.
RTSP Port	The default value setting is 554. You can enter the value according to
KISP POIL	your actual situation.
HTTP Port	The default value setting is 80. You can enter the value according to
	your actual situation.
	If you enter other value, for example, 70, and then you should enter
	70 after the IP address when logging in the Device by browser.
User Name	Enter the user name of the remote device.
Password	Enter the password of the user for the remote device.

Parameter	Description
Remote Channel	Enter the remote channel number of the remote device that you want to add.
Decoder Buffer	In the Decoder Buffer list, select Default , Realtime , or Fluent .
Protocol Type	 If the remote device is added through private protocol, the default type is TCP. If the remote device is added through Onvif protocol, the system supports Auto, TCP, UDP, or MULTICAST. If the remote device is added through other manufacturers, the system supports TCP and UDP.
Encrypt	If the remote device is added through Onvif protocol, selecting the Encrypt check box will provide encryption protection to the data being transmitted. To use this function, the HTTPS function should be enabled for the remote IP camera.

3) Click OK.

The remote device information is displayed on the **Added Device** list.

Step 4 Click **Next** to complete the remote device registration.



Once the multiple-sensor device has registered to the device system displays the channel status on the **Link info**. See Figure 4-30. It shows one remote device has occupied two channels: D1, D3.




Figure 4-30

4.1.4.5 RAID Manager

RAID (redundant array of independent disks) is a data storage virtualization technology that combines multiple physical HDD components into a single logical unit for the purposes of data redundancy, performance improvement, or both.



RAID function is for some series product only. Slight difference may be found on the user interface. Step 1 Select Main Menu > STORAGE > RAID > RAID.




Figure 4-31

- <u>Step 2</u> You can click **Create RAID** or **Create Manually**, and all the disks involved will be formatted.
 - Click Create RAID, the system will create RAID automatically.
 - If there is no existing RAID and no hot spare disk, the system will create RAID5 and a hot spare disk automatically.
 - If there is no existing RAID, but existing hot spare disk, the system will only create RAID5 and use the existing hot spare disk automatically.
 - If there is existing RAID and existing hot spare disk, the system will delete the original RAID and create RAID5 with all the disks and use the existing hot spare disk automatically.
 - Click Create Manually.
 - 1) Select RAID type and disks as system instructed.
 - 2) Click Create Manually, and then the format disk notice is displayed.
 - 3) Click OK.
- <u>Step 3</u> After creating RAID, the disks need to sync with each other to finish the process. For RAID5 and RAID6, you can select different working mode.
 - Self-Adaptive: Automatically adjust the RAID sync speed according to the business status.
 - ♦ When there is no business running, sync is performed at a high speed.
 - When there is business running, sync is performed at a low speed.
 - Sync First: Resource priority is assigned to RAID sync.
 - Business First: Resource priority is assigned to business operations.
 - Balance: Resource is evenly distributed to RAID sync and business operations.

4.1.4.6 Schedule

After set record schedule and snapshot schedule, the device can automatically record video and snapshot image at the specified time. Select **Main menu** > **STORAGE** > **SCHEDULE**, you can go to the **SCHEDULE** interface.

4.1.4.6.1 Recording Schedule


After set schedule record, device can record video file according to the period you set here. For example, the alarm record period is from 6:00–18:00 Monday, device can record alarm video files during the 6:00–18:00.

All channels are record continuously by default. You can set customized record period and record type.

Step 1 Click **Next** button.

The **Rec** interface is displayed. See Figure 4-32.

Figure 4-32



Step 2 Select a channel from the dropdown list, you can set different record plans for different channels. Select **All** if you want to set for all channels. See Table 4-9.

Table 4-9


Parameter	Description
Channel	In the Channel list, select a channel to record the video.
Pre-record	In the Pre-record list, enter the amount of time that you want to start the recording in advance.
Redundancy	 If there are several HDDs installed to the Device, you can set one of the HDDs as the redundant HDD to save the recorded files into different HDDs. In case one of the HDDs is damaged, you can find the backup in the other HDD. Select Main Menu > STORAGE > HDD MANAGER, and then set a HDD as redundant HDD. Select Main Menu > STORAGE > SCHEDUE > Record, and then select the Redundancy check box. ♦ If the selected channel is not recording, the redundancy function takes effect next time you record no matter you select the check box or not. ♦ If the selected channel is recording, the current recorded files will be packed, and then start recording according to the new schedule.

Parameter	Description
	 This function is for some series products only. The redundant HDD only back up the recorded videos but not
	snapshots.
ANR	 You can set ANR (auto network resume) function. The IPC continues record once the NVR and IPC connection fails. After the network becomes normal, the NVR can download record file during the offline period from the IPC. It is to guarantee there is no record loss on current connected IPC channel. Set the max. record upload period. Once the offline period is longer than the period you set here, IPC can only upload the record file during the specified period.
	This function is for IPC that installed SD card and the record function is enabled.
	Define a period during which the configured recording setting is active. See Figure 4-33.
	The system only activates the alarm in the defined period.
Сору	Click Copy to copy the settings to other channels.

Description


Parameter

Figure 4-33



Step 3 Set record type. See Figure 4-34.

Figure 4-34




Tampering Scene Change D1 Region Setting Enable MD Period Setting Anti-Dither Alarm Out Setting 10 Show Message Alarm Upload Send Email Setting PTZ Activation Setting Post-Record 10 Setting ☐ Voice Prompts None Default Сору Refresh Back Apply

Figure 4-35

Step 4 Set record period. It includes edit mode and draw mode. See Figure 4-36.

If you have added a holiday, you can set the record period for the holiday.

Figure 4-36



- Define the period by drawing.
- 1) Select a corresponding date to set.
 - ♦ Define for the whole week: Click next to All, all the icon switches to you can define the period for all the days simultaneously.
 - ♦ Define for several days of a week: Click before each day one by one, the icon switches to Sylvar Sy
- 2) On the timeline, left click mouse and then drag to define a period. There are six periods in one day, the Device starts recoding the selected event type in the defined period. In Figure 4-37, the different color bars stand for different record types.
 - ♦ Green stands for general record.
 - ♦ Yellow stands for MD (motion detection) record.
 - Red stands for alarm record.
 - ♦ Blue stands form intelligent record.
 - Orange stands for MD&Alarm record.
 - Purple stands for POS record.
 - Once the time period overlaps, the record priority: MD&Alarm > Alarm > POS > Intelligent > MD > General.
 - Select a record type and then click the of the corresponding date to clear the corresponding period.

Figure 4-37



 \square

The MD record and alarm record function are both null if you enabled MD&Alarm function.

- Define the period by editing.

Period 00:00 - 24:00 00:00 - 24:00 MD&Alarm 00:00 - 24:00 00:00 - 24:00 MD&Alarm 00:00 - 24:00 00:00 - 24:00 Cancel

Figure 4-38

- 2) Set record type for each period.
 - ♦ There are six periods for you to set for each day.
 - Under Copy, select All to apply the settings to all the days of a week, or select specific day(s) that you want to apply the settings to.
- 3) Click Apply to save the settings.

Step 5 Click Apply to complete the settings.

Enable auto record function so that the record plan can become activated. Refer to "4.1.4.6.3 Record control" for detailed information.

4.1.4.6.2 Snapshot Schedule


You can set schedule snapshot period.

After set schedule snapshot, device can snapshot image according to the period you set here. For example, the alarm snapshot period is from 6:00–18:00 Monday, device can snapshot during the 6:00–18:00 when an alarm occurs.

Step 1 Click Snapshot button, device goes to following interface. See Figure 4-39.

Select **Main Menu > STORAGE > SCHEDULE > Snapshot**, you can go to the snapshot interface.

Figure 4-39




Step 2 Select a channel to set schedule snapshot.

Step 3 Set snapshot type as schedule. Refer to "4.2.5.2 Snapshot" for detailed information.

Step 4 Check the box to set alarm type. See Figure 4-40.

- When the record type is MD (motion detect), alarm, MD&Alarm, IVS and POS, enable the channel record function when corresponding alarm occurs. For example, when the alarm type is MD, select Main Menu > ALARM > VIDEO DETECTION > Motion Detect, select the record channel and enable record function. See Figure 4-35.
- When the record type is MD (motion detect), alarm, MD&Alarm, IVS and POS, refer to "4.8.5 Video detect ", "4.8.3 Alarm ", " 4.7.2.4 IVS " and " Step 3 POS " for detailed information.



Step 5 Refer to "4.1.4.6.1 Record" to set snapshot period.

Step 6 Click **Apply** button to save snapshot plan.

Enable auto snapshot function so that the snapshot plan can become activated. Refer to "4.1.4.6.3 Record control" for detailed information.

4.1.4.6.3 Record Control

After set schedule record or schedule snapshot, you need to enable auto record and snapshot function so that system can automatically record or snapshot.

- Auto: System automatically records at the type and record period you set in Schedule interface.
- Manual: System records general files for all day.




You need to have storage authorities to implement the Manual record operation. Make sure the HDD has been properly installed.

Step 1 Right click mouse and then select **Manual > Record** or select **Main Menu > STORAGE > RECORD**..



For some series products, after you logged in, you can click the Rec button at the front panel to go to the **Record** interface.

Figure 4-42



Step 2 Configure parameters.

Parameter	Description
Channel	Displays all the analog channels and the connected digital channels. You can select a single channel or select All .
Record status	 Auto: Automatically record according to the record type and recording time as configured in the recording schedule. Manual: Keep general recording for 24 hours for the selected channel. Off: Do not record.
Snapshot status	Enable or disable the scheduled snapshot for the corresponding channels.

Step 3 Click Apply.


4.2 Camera

4.2.1.1 Connection

Select **Main menu > REGISTRATION > Camera Registration**, you can register the remote device. See Figure 4-43.

After register the remote device to the NVR, you can view the video on the NVR, and manage and storage the video file. Different series products support different remote device amount.

Figure 4-43




4.2.1.2 Changing IP address

Step 1 Select Main Menu > REGISTRATION > Camera Registration, check the box before

the camera name and then click Modify IP or click the Enter **Modify IP** interface. See Figure 4-44.

Check the box before several cameras, change the IP addresses of several cameras at the same time.



Step 2 Select IP mode.

- Check DHCP, there is no need to input IP address, subnet mask, and default gateway. Device automatically allocates the IP address to the camera.
- Check Static, and then input IP address, subnet mask, default gateway and incremental value.
- If it is to change several devices IP addresses at the same time, input incremental value. Device can add the fourth address of the IP address one by one to automatically allocate the IP addresses.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. If batch change IP address, device automatically skips the conflicted IP and begin the allocation according to the incremental value

Step 3 Input remote device user name and password.

When change IP addresses of several devices at the same time, make sure the cameras user name and passwords are the same.

Step 4 Click **OK** button to save settings.

After the modification and then search again, device displays new IP address.

Auto Changing H.265


For the remote device that first registered to the system, it can automatically adopts encode format as H.265 if you enable H.265 Auto switch function.

Click H.265 Auto Switch button at the bottom of the interface, it is from



. The function is enabled. See Figure 4-45.

Figure 4-45




4.2.1.3 IP Export

Device can export the Added device list to your local USB device.

Step 1 Insert the USB device and then click the **Export** button. The **Browse** interface is displayed. See Figure 4-46.

Figure 4-46



Step 2 Select **Address** to save export file.

Step 3 Click the **OK** button.

Device pops up a dialogue box to remind you successfully exported.

 \square

When exporting IP address, the **File Backup Encryption** check box is checked by default. The file information includes IP address, port, channel number, manufacturer, user name, and password.


- If you select the File Backup Encryption check box, the file format is .backup.
- If you clear the File Backup Encryption check box, the file format is .csv. In this case, there might be a risk of data leakage.

4.2.1.4 IP Import

Step 1 Click Import button.

The **Browse** interface is displayed. See Figure 4-47.

Figure 4-47



Step 2 Go to Address to select the import file and then click the **OK** button.

System pops up a dialogue box to remind you successfully imported.

If the imported IP has conflicted with current added device, system pops up a dialogue box to remind you. You have two options.

Step 3 Click OK button.

The imported information is on the Added Device list.

4.2.2 Remote Device Initialization

Remote device initialization can change remote device login password and IP address.

When connect a camera to the NVR via PoE port, NVR automatically initialize the camera.
 The camera adopts NVR current password and email information by default.

 When connect a camera to the NVR via PoE port after NVR upgraded to the new version, the NVR may fail to initialize the camera. Go to the Registration interface to initialize the camera.

Step 1 Select Main Menu > CAMERA > Camera Registration.

The **Camera Registration** interface is displayed.


Step 2 Click **Device Search** and then click **Uninitialized**.

Device displays camera(s) to be initialized.

Step 3 Select a camera to be initialized and then click **Initialize**.

The **Enter Password** interface is displayed. See Figure 4-48.

Figure 4-48




Step 4 Set remote device password and email information.

If you want to use current device password and email information, the remote device automatically uses NVR admin account information (login password and email). There is no need to set password and email. Go to step 6.

Cancel **Using current device password and email info**, The **Enter Password** interface is displayed. See Figure 4-49.

Figure 4-49



2) Configure parameters. See Table 4-10.

Table 4-10

Parameter	Description
User	The default is admin.
Password	The new password can be set from 8 characters through 32 characters and contains at least two types from number, letter and special characters (excluding"", """, ";", ":" and "&"). Enter a strong password according to the password strength bar indication.
Confirm Password	




For your device own safety, create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

Step 5 Click **Next** button.

The **Password Protection** interface is displayed. See Figure 4-50.

Figure 4-50



Step 6 Set email information.

Input an email address for reset password purpose.


Ĭ

Cancel the box and then click Next or Skip if you do not want to input email information here.

Step 7 Click **Next** button.

The **Network** interface is displayed. See Figure 4-51.

Figure 4-51




Step 8 Set camera IP address.

- Check **DHCP**, there is no need to input IP address, subnet mask, and default gateway. Device automatically allocates the IP address to the camera.
- Check **Static**, and then input IP address, subnet mask, default gateway and incremental value.
- If it is to change several devices IP addresses at the same time, input incremental value. Device can add the fourth address of the IP address one by one to automatically allocate the IP addresses.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. If batch change IP address, device automatically skips the conflicted IP and begin the allocation according to the incremental value

Step 9 Click Next button.

The **Device Initialization** interface is displayed. See Figure 4-52.

Figure 4-52




Step 10 Click **Finished** to complete the setup.

4.2.3 Short-Cut Menu to Register Camera

If you have not registered a remote device to a channel, go to the preview interface to add. Step 1 On the Preview interface, Move your mouse to window.

There is an icon "+" on the channel window. See Figure 4-53.

Figure 4-53



<u>Step 2</u> Click "+", device pops up interface to add network camera. Refer to "4.1.4.4 Registration" for detailed information.


4.2.4 Image

You can set network camera parameters according to different environments. It is to get the best video effect.

Step 1 Select Main Menu> CAMERA> IMAGE.

The **IMAGE** interface is displayed. See Figure 4-54.

Figure 4-54



Step 2 Configure parameters. See Table 4-11.

Different series network camera displays different parameters. The actual product shall prevail.

Table 4-11

Parameter	Description
Channel	In the Channel list, select the channel that you want to configure.
Config File	There are three config files for you. System has configured the corresponding parameters for each file, you can select according to your actual situation.
Brightness	Adjusts the image brightness. The bigger the value is, the brighter the image will become. Adjusts the brightness according to actual environment.
Contrast	Adjusts the image contrast. The bigger the value is, the more obvious the contrast between the light area and dark area will become. Adjusts the contrast according to actual environment.
Saturation	Adjusts the color shades. The bigger the value, the lighter the color will become. Adjusts the saturation according to actual environment.
Sharpness	Adjusts the sharpness of image edge. The bigger the value is, the more obvious the image edge is. Adjusts the sharpness according to actual environment.

Parameter	Description
Gamma	It is to adjust image brightness and enhance the image dynamic display range. The bigger the value is, the more bright the video is.
Mirror	Enable the function, the left and right side of the video image will be switched. It is disabled by default. This function is for some series products only.
Field of view	It is to set monitor video display direction. It includes normal, reflection, lobby 1, lobby 2.
Exposure	 Auto iris It is for the camera of auto iris only. After enable auto iris function, the iris can automatically zoom in/zoom out according to the brightness of the environment and the image brightness changes too. If disable the auto iris function, the iris does not automatically zoom in/zoom out according to the brightness of the environment when the iris is at the biggest value.
	This function specially applies to the image which frame rate is configured as 2 at least. It reduces the noises by making use of the information between two frames. The bigger the value is, the better the effect.
BLC	 You can set camera BLC mode. Self-adaptive: In the backlight environment, the system can automatically adjust image brightness to clearly display the object. BLC: Default: The device auto exposures according to the environments situation so that the darkest area of the video is cleared Customize: After select the specified zone, the system can expose the specific zone so that the zone can reach the proper brightness. WDR: In backlight environment, it can lower the high bright section and enhance the brightness of the low bright section. So that you can view these two sections clearly at the same time. HLC: In the backlight environment, it can lower the brightness of the brightness of the whole video. Stop: It is to disable the BLC function.
WB	 You can set camera WB mode. It can affect the image whole hue so that the image can accurately displays the environment status. Different cameras supports different WB modes such as auto, manual ,natural light, outdoor and etc.
Day & Night	 Configure the color and black&white mode of the image. This setting is not affected by the configuration files. The default setting is Auto. Color: The camera outputs color image only. Auto: Depends on the camera, such as overall brightness and whether there is an IR light, either color image or black&white image is output. B/W: The camera outputs Black and white image only. Sensor: It is to set when there is peripheral connected IR light. The Sensor item is for some non-IR device only.

Step 3 Click Apply.

4.2.5 Encode

You can set video bit stream and image parameters.

4.2.5.1 Encode

You can set video bit stream parameters such as bit stream type, compression, resolution.


 \square

Some series products support three streams: main stream, sub stream 1, sub stream 2. The sub stream maximally supports 1080P.

Step 1 Select Main menu > CAMERA > ENCODE > ENCODE.

The **ENCODE** interface is displayed. See Figure 4-55.

Figure 4-55



Step 2 Configure parameters. See Table 4-12.

Table 4-12


Parameter	Description
Channel	In the Channel list, select the channel that you want to configure the settings for.
Smart Codec	Enable the smart codec function. This function can reduce the video bit stream for non-important recorded video to maximize the storage space. • Enabled. • Disabled.
Туре	 Main Stream: In the Type list, select General, MD (Motion Detect), or Alarm. Sub Stream: This setting is not configurable.
Compression	In the Compression list, select the encode mode.

Parameter	Description
	 H.265: Main profile encoding. This setting is recommended. H.264H: High profile encoding. Low bit stream with high definition. H.264: Main profile encoding. H.264B: Baseline profile encoding. This setting requires higher bit stream compared with other settings for the same definition.
Resolution	In the Resolution list, select resolution for the video. The maximum video resolution might be different dependent on your device model.
Frame Rate (FPS)	Configure the frames per second for the video. The higher the value is, the clearer and smoother the image will become. Frame rate changes along with the resolution. Generally, in PAL format, you can select the value from 1 through 25; in NTSC format, you can select the value from 1 through 30. However, the actual range of frame rate that you can select depends on the capability of the Device.
Bit Rate Type	In the Bit Rate Type list, select CBR (Constant Bit Rate) or VBR (Variable Bit Rate). If you select CBR , the image quality cannot be configured; if you select VBR , the image quality can be configured.
Quality	This function is available if you select VBR in the Bit Rate List. The bigger the value is, the better the image will become.
I Frame Interval	The interval between two reference frames.
Bit Rate (Kb/S)	In the Bit Rate list, select a value or enter a customized value to change the image quality. The bigger the value is, the better the image will become.

Step 3 Click More Setting.

The **More Setting** interface is displayed. See Figure 4-56.

Figure 4-56



Step 4 Configure parameters. See Table 4-13.

Table 4-13

Parameter	Description
Audio Encode	 This function is enabled by default for main stream. You need to manually enable it for sub stream 1. Once this function is enabled, the recorded video file is composite audio and video stream.
Audio Format	In the Audio Forma t list, select a format: G711a, G711u, PCM, AAC.
Audio Sampling	In the Audio Sampling list, you can select audio sampling rate.

Step 5 Click **OK**.

Back to **Encode** interface.

Step 6 Click Apply.

4.2.5.2 Snapshot

You can set snapshot mode, image size, quality and interval.

Step 1 Select Main menu > CAMERA > ENCODE > Snapshot.




Figure 4-57

<u>Step 2</u> Configure parameters. See Table 4-14. Table 4-14

Parameter	Description
Manual Snap	In the Manual Snap list, select how many snapshots you want to take each time.
Channel	In the Channel list, select the channel that you want to configure the settings for.
Mode	 In the Mode list, you can select Timing, or Trigger. Timing: The snapshot is taken during the scheduled period. Trigger: The snapshot is taken when there is an alarm event occurs, such as motion detection event, video loss, and local alarms.
Image Size	• In the Image Size list, select a value for the image. The bigger the value is, the better the image will become.
Image Quality	Configure the image quality by 6 levels. The higher the level is, the better the image will become.
Interval	Configure or customize the snapshot frequency. Max. supports 3600 seconds/image.

Step 3 Click Apply.

4.2.6 Channel Name

You can set customized channel name.

Step 1 Select Main Menu > CAMERA > CAM NAME.

The **CAM NAME** interface is displayed. See Figure 4-58.

Figure 4-58



Step 2 Modify a channel name.

- You can only change the camera connected via the private protocol.
- The channel name supports 63 English characters.

Step 3 Click Apply.


4.2.7 Remote Upgrade

You can upgrade the connected network camera firmware. It includes online upgrade and file upgrade.

$\underline{\text{Step 1}} \hspace{0.1in} \textbf{Select Main Menu > CAMERA > REGISTRATION > Upgrade}.$

The **Upgrade** interface is displayed. See Figure 4-59.

Figure 4-59



Step 2 Update the firmware of the connected remote device.

- Online Upgrade
- Select a remote device and then click the **Detect** button on the right side, or check a box to select a remote device and then click **Manual Check**.
 System detects the new version on the cloud.
- 2) Select a remote device that has new version and then click online upgrade.

 After successful operation, system pops up upgrade successful dialogue box.
- File upgrade
- 1) Select a channel and then click **File Upgrade**.
- 2) Select upgrade file on the pop-up interface.
- 3) Select the upgrade file and then click **OK** button.

 After successful operation, system pops up upgrade successful dialogue box.

If there are too much remote devices, select **Device Type** from the drop-down list to search the remote device you desire.

4.2.8 Remote Device Info

4.2.8.1 Device Status

You can view the connection and alarm status of the corresponding channel.

Select Main Menu > CAMERA > REGISTRATION > Status, the Status interface is displayed.



Figure 4-60

Table 4-15


Icon	Description	Icon	Description
•	IPC works properly.		IPC does not support.
A	There is an alarm.	•	Video loss occurs.

4.2.8.2 Firmware

You can view IP address, manufacturer, type, system version of the connected remote device.

Select Main Menu > CAMERA > REGISTRATION > Firmware, the Firmware interface is displayed. See Figure 4-61.

Figure 4-61



4.3 Live View

After you logged in, the system goes to multiple-channel live view mode by default. You can view the monitor video of each channel.

The displayed window amount may vary. The actual product shall prevail.

4.3.1 Preview

On Preview interface, you can view the monitor video of each channel. The corresponding channel displays date, time, and channel name after you overlay the corresponding information. Refer to the following table for detailed information. See Table 4-16.

Table 4-16

No.	Icon	Description
1		When current channel is recording, system displays this icon.
2	**	When motion detection alarm occurs, system displays this icon.

No.	Icon	Description
3	?	When video loss alarm occurs, system displays this icon.
4	8	When current channel is in monitor lock status, system displays this icon.
5	?	When the device connects to the network camera remotely, system displays this icon.
		This function is for some series products only.

4.3.2 Navigation bar

You can quickly perform operation through the icon on the navigation bar.



- Different series products may display different navigation bar icons. Refer to the actual product for detailed information.
- Select Main Menu > SYSTEM > GENERAL > General to enable navigation bar function and then click Apply; otherwise you cannot see the following interface.

Step 1 On the preview interface, left click mouse,

You can see navigation bar. See Figure 4-62. Refer to Table 4-17 to view detailed information.

Figure 4-62



Table 4-17

Icon	Function
	Open Main Menu.
4	Expand or condense the navigation bar.
25	Select view layout.
=	Go to the previous screen.
₽	Go to the next screen.
t □	Enable tour function. The icon switches to Close the tour or the triggered tour operation has cancelled, device restores the previous preview video.
	Open the PTZ control panel. For details, see "4.4.2 PTZ Control".
€	Open the Color Setting interface. For details, see "4.4.2 PTZ Control." This function is supported only in single-channel layout.
Q	Open the record search interface. For detail, see "4.6.2 Search Interface."
⊢ Ø	Open the Broadcast interface. For detail, see "4.18.3 Broadcast."

Icon	Function
A	Open the EVENT interface to view the device alarm status. For details, see "4.8.2 Alarm Status."
-	Open the CHANNEL INFO interface to display the information of each channel. For details, see " 4.3.2.1 Channel Info."
9 4	Open the CAMERA REGISTRATION interface. For details, see "4.1.4.4 Registration."
	Open the NETWORK interface. For details, see " 4.12 Network."
	Open the HDD MANAGER interface. For details, see " 4.13.3 HDD."
	Open the USB MANAGER interface. For details about USB operations, see " 4.3.2.2 USB Manager."

4.3.2.1 Channel Info

After the remote device registered to the corresponding channel, you can view its status such as alarm status, record status, connection status, record mode, etc.

- Alarm status: It includes motion detection alarm, video loss alarm, tampering alarm.
- Record status: System is recording or not.
- Bit Rate: System displays bit rate information.
- Status: current channel connection status.

Click button system goes to the channel information setup interface. You can view information of the corresponding channel. See Figure 4-63.

4.3.2.2 USB Manager

After connecting the USB device, you can copy log, config file to USB device or update NVR system.

Click system goes to HDD Manager interface. You can view and manage HDD information. See Figure 4-64.

Here you can view USB information, backup file, and update system. Refer to "4.11 File Backup", "4.10.1 Log", "4.10.4.2 IMP/EXP", "4.10.4.4 System Update" for detailed information.




Figure 4-64

4.3.3 Preview Control Interface

Move your mouse to the top center of the video of current channel; you can see system pops up the preview control interface. See Figure 4-65. If your mouse stays in this area for more than 6 seconds and has no operation, the control bar automatically hides.

Slight difference may be found on the user interface.
Figure 4-65



4.3.3.1 Instant Replay

You can playback the previous 5-60 minutes record of current channel.

Click to go to the instant replay interface. See Figure 4-66.



Instant replay is to playback the previous 5 minutes to 60 minutes record of current channel.

- Move the slider to choose the time you want to start playing.
- Play, pause and close playback.
- The information such as channel name and recording status icon are shielded during instant playback and will not display until exited.
- During playback, screen split layout switch is not allowed.
- Tour high higher priority than the instant playback. The instant playback function is null
 when tour function is in process and the preview control interface auto hides either. The
 function becomes valid again after tour is complete.



Go to the **Main Menu > SYSTEM > GENERAL > General** to set **Instant Replay** time. See Figure 4-67. System may pop up a dialogue box if there is no such record in current channel.

General Date&Time Holiday

Device Name NVR
Device No. 8
Language ENGLISH
Video Standard PAL
Sync to Remote Device (Include language, ...
Instant Replay(Min.) 5
Auto Logout(Min.) 10
IPC Time Sync
IPC Time Sync Period (hour) 24
Navigation Bar
Mouse Sensitivity + Slow Fast

Figure 4-67

4.3.3.2 Digital zoom

You can zoom in specified zone of current channel so that you can view the details. It supports zoom in function of multiple-channel. It includes the following two ways:


• Click , the icon switches to ... Hold down the left mouse button to select the area you want to enlarge. The area is enlarged after the left mouse button is released.

Point to the center that you want to enlarge, rotate the wheel button to enlarge the area.

For some models, when the image is enlarged in the first way described previously, the selected area is zoomed proportionally according to the window.

The digital zoom interface is shown as in Figure 4-68. When the image is in the enlarged status, you can drag the image toward any direction to view the other enlarged areas. Right click mouse to cancel zoom and go back to the original interface.







4.3.3.3 Instant backup

You can record the video of any channel and save the clip into a USB storage device.

By clicking [188], the recording is started. To stop recording, click this icon again. The clip is automatically saved into the connected USB storage device.

You can record the video of any channel and save the clip into a USB storage device.

4.3.3.4 Manual Snapshot

You can take one to five snapshots of the video and save into a USB storage device.

By clicking [11], you can take snapshots. The snapshots are automatically saved into the connected USB storage device. You can view the snapshots on your PC.



To change the quantity of snapshots, select Main Menu > CAMERA > ENCODE > Snapshot, in the Manual Snap list, select the snapshot quantity.

4.3.3.5 Bidirectional talk

You can perform the voice interaction between the Device and the remote device to improve efficiency of emergency.

to start bidirectional talk function the icon now is shown as Step 1 Click button Now the rest bidirectional talk buttons of digital channel becomes null too.



Step 2 Click again, you can cancel bidirectional talk.

4.3.3.6 Switch bit streams

Via this function, you can switch the channel main stream/sub stream according to current network bandwidth.

- M: Main stream. Its bit streams are big and definition is high. It occupies large network bandwidth suitable for video wall surveillance, storage and etc.
- S: Sub stream. Its definition is low but occupies small network bandwidth. It is suitable for general surveillance, remote connection and etc.

Click to switch the bit stream type of the main stream and sub stream.

- M: Main stream.
- S: Sub stream. Some series products support two sub streams (S1, S2). Refer to "4.2.5.1

Encode" for detailed information.

4.3.3.7 Right-Click Menu

By right-clicking the preview interface, you can quickly access the corresponding functional interface and perform relevant operations, including entering the main menu, searching records and selecting screen split mode.

Right-click on the preview interface and the right-click menu is displayed. See Figure 2-54. Refer to Table 4-18 for detailed information.



The right-click menu is different for different models. The actual interface shall prevail.

Figure 4-69




Figure 4-70




Table 4-18

Function	Description
Main Menu	Open Main Menu interface.
Search	Open the PLAYBACK interface where you can search and play back record files. For details, see "4.6 Playback and Search."
PTZ	Open the PTZ interface. For details, see "4.4 PTZ."
View 1/4/8/9/16/25/36	Configure the live view screen as a single-channel layout or multi-channel layout.

Function	Description		
	Set customized screen split mode and channels. For details, see "4.3.4 Wireless Pairing		
	Right-click on the screen and select Wireless Paring . The Wireless Pairing interface is displayed. See		
	Figure 4-71.		
	The device enters a 120 secondes pairing countdown.		
	You can see the video of the paired IPC after pairing is successful.		
	Figure 4-71		
	Wireless Pairing		
	Pairing, countdown: 115		
Sequence (View	CH Device SN		
Layout)	D1		
	D2		
	D4		
	Connected Device Quantity: 3		
	Connected Device Quantity. 3		
	Cancel		
Previous Screen	Sequence." Click Previous Screen to go to the previous screen. For example, if		
	you are using 4-split mode, the first screen is displaying the		
Next Screen	channel 1-4, click Next screen , you can view channel 5-8.		
Camera Registration	Open the CAMERA REGISTRATION interface. For details, see "4.1.4.4 Registration."		
Wireless Paring	Right-click Wireless Paring to quickly add IPCs. For details, see "4.3.4"		
	Select Record, you can configure the recording mode as		
Manual	Auto or Manual, or stop the recording. You can also enable or		
	disable snapshot functionSelect Alarm Out, you can configure alarm output settings.		
Preview Mode	 Select Alarm Out, you can configure alarm output settings. There are two modes: regular/Al mode. 		
	y		
Crowd Distribution	Select enable/disable to start/stop crowd distribution function.		
Auto focus	Click to realize auto focus function. Make sure the connected camera supports auto focus function.		
Image	Click to modify the camera properties. For details, see "4.2.4 Image".		
Sub Port	Click Sub Port , you can go to control the sub screen.		
1 Wireless Deiring	1 - 1 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 -		

4.3.4 Wireless Pairing

Right-click on the screen and select Wireless Paring. The Wireless Pairing interface is Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 140

displayed. See

Figure 4-71.

The device enters a 120 secondes pairing countdown.

You can see the video of the paired IPC after pairing is successful.

Figure 4-71

Wireless Pairing		
Pairing, cou	ntdown: 115	
СН	Device SN	
D1	teolisti vuiteliiti	
D2	4,000ACKALE0592	
D4	4:85764.FNLX00952	
Connected Device Quantity: 3		
	Cancel	

4.3.5 Sequence

You can set customized view layout.



The preview layout restores default channel layout after Default operation.


Step 1 On the preview interface, right click mouse and then click **Sequence**.

Step 1 The **Sequence** interface is displayed.



- Enter edit view interface, device automatically switches to the max split amount mode.
- The channel list on the edit view interface displays the added camera channel number and channel name. The means camera is online. The means camera is offline.
- In case the channel amount has exceeded the device max split amount, the edit view interface can display the max screen number amount and current screen number.


Figure 4-72



<u>Step 2</u> On the edit view interface, drag the channel to the desired window, or drag on the preview window to switch the position.

<u>Step2</u> Check the channel number at the right bottom corner to view the current channel sequence.

Figure 4-73




Step 3 Click Apply to save current channel sequence.

After you change the channel sequence, click Cancel button or right click mouse, device pops up the dialogue box. See Figure 4-74.

- Click **OK** to save current settings.
- Click No to exit without saving the settings.

Figure 4-74



4.3.6 Fisheye (Optional)



This function is for some series products only.

4.3.6.1 Fisheye de-warp during preview interface


The fisheye camera (panoramic camera) has wide video of angle but its video is seriously distorted. The de-warp function can present the proper and vivid video suitable for human eyes.

On the preview interface, select fisheye channel and then right click mouse, you can select fish eye. See Figure 4-75. You can set fisheye installation mode and display mode.



- For the non-fish eye channel, system pops up dialogue box to remind you it is not a fish eye channel and does not support de-warp function.
- If system resources are insufficient, system pops up the corresponding dialogue box too.






Now you can see an interface shown as Figure 4-76. You can set fish eye installation mode and display mode. There are three installation modes: ceiling mount/wall mount/ground mount.



- The different installations modes have different de-warp modes.
- Some series products support 180° de-warp. 180° de-warp fisheye supports wall mount de-warp only. The actual product shall prevail.

Figure 4-76



Refer to the following sheet for detailed information. See Table 4-19.

Table 4-19

Installation modes	Icon	Note
(Ceiling mount)		360°panorama original view
(Ground mount)	← →	1 de-warp window+1 panorama stretching
	\longleftrightarrow	2 panorama stretching view
	Q	1 360° panorama view+3 de-warp windows
	\square \square	1 360°panorama view+4 de-warp windows
		4 de-warp windows+1 panorama stretching
	Q	1 360° panorama view+8 de-warp windows
(Wall mount)		360°panorama original view
(Wall Mount)	\times	Panorama stretching
	\boxtimes	1 panorama unfolding view+3 de-warp windows
		1 panorama unfolding view +4 de warp windows
	\boxtimes	1 panorama unfolding view +8 de warp windows

Figure 4-77



In Figure 4-77, you can adjust the color pane on the left pane or use your mouse to change the position of the small images on the right pane to realize fish eye de-warp.

Operation: Use mouse to zoom in/zoom out, move, and rotate the image (Not for wall mount mode.)

4.3.6.2 Fish eye de-warp during playback

When playing back the fisheye record file, you can use de-warp function to adjust video.

Step 1 On the main menu, click **Backup** button.

Step 2 Select 1-window playback mode and corresponding fish eye channel, click play.

Step 3 Right click the you can go to the de-warp playback interface. For detailed information, refer to "4.3.6.1 Fisheye de-warp during preview interface".

4.3.6.3**Test Temperature**

When connecting to the front-end device that supports temperature detection, system can display instant temperature.



- This function may collect the human temperature in the surveillance video, be careful!
- This function is for some series products only.

Preparations

Refer to "4.17.1 Display" to enable test temperature function.

On the preview window, click any position on the thermal channel video. The interface is shown as below. See Figure 4-78.

Figure 4-78



4.3.7 Al Preview Mode

When you select Al mode, the system displays information of human face, personnel, vehicle and non-motor vehicle on the right side of the preview interface, and it supports to play back records and display feature attributes.




You need to enable face detection, body detection, vehicle detection and non-motor vehicle detection to support this function. For details, see "4.7.2.5 Video Structuring (Metadata)."

Step 1 Right click to select **Preview Mode > Al Mode**.

The Al preview interface is displayed. See Figure 2-60.

Figure 4-79




<u>Step 2</u> (Optional) Double-click the image on the right to play the corresponding video.

Step 3 Click


The **Properties** interface is displayed. See Figure 2-59.

Figure 4-80




- <u>Step 4</u> (Optional) Click **Show Face List** and select attributes to display, including age, gender, expression, glasses, beard and mask.
- <u>Step 5</u> (Optional) Click **Human Body Detection** and select attributes to display, including top, pants, hat, bag, bag style, umbrella, age and gender. See Figure 4-81.

Figure 4-81




<u>Step 6</u> (Optional) Click **Vehicle Display** and select attributes to display, including vehicle logo, vehicle color, vehicle model, plate recognition, plate color, seatbelt, call, vehicle decorations and countries & regions.

Figure 4-82



Step 7 (Optional) Click **Non-Motor** and select attributes to display, including color, type and people number. See Figure 4-83.

Figure 4-83



 $\underline{\text{Step 8}} \quad \text{Click OK to complete the setting.}$

The system can display four attributes at most.

4.4 PTZ

PTZ is a mechanical platform that carries a camera and a protective cover and performs overall control remotely. A PTZ can move in both horizontal and vertical direction to provide all-around view to the camera.

Before you control the PTZ, make sure the PTZ decoder and the NVR network connection is

OK.

4.4.1 PTZ Settings

You can set different PTZ parameters for local type and remote type. Before you use local PTZ, make sure you have set PTZ protocol; otherwise you cannot control the local PTZ.

- Local: The PTZ device connects to the NVR via the cable.
- Remote: The PTZ device connects to the NVR via the network.



This function is for some series products only.

Step 1 Select Main menu > CAMERA > PTZ.

The PTZ interface is displayed. See Figure 4-84 (Local) or Figure 4-85 (Remote).

Figure 4-84





Figure 4-85



Step 2 Configure parameters. See Table 4-20.

Table 4-20

Parameter	Description		
Channel	In the Channel list, select the channel that you want to connect the PTZ camera to.		
PTZ Type	 Local: Connect through RS-485 port. Remote: Connect through network by adding IP address of PTZ camera to the Device. 		
Protocol	In the Protocol list, select the protocol for the PTZ camera such as PELCOD.		
Address	In the Address box, enter the address for PTZ camera. The default is 1. The entered address must be the same with the address configured on the PTZ camera; otherwise the system cannot control PTZ camera.		
Baud rate	In the Baud rate list, select the baud rate for the PTZ camera. The default is 9600.		
Data Bits	The default is 8.		
Stop Bits	The default is 1.		
Parity	The default is NONE.		

Step 3 Click Apply.


4.4.2 PTZ Control

PTZ control panel performs the operations such as directing camera in eight directions, adjusting zoom, focus and iris settings, and quick positioning.

Basic PTZ Control Panel

Right-click on the live view screen and then select PTZ. The PTZ control panel is displayed. See Figure 4-86.

Figure 4-86





- The gray button means system does not support current function.
- For some series products, the PTZ function is valid in one-window mode.


Table 4-21

Parameter	Description		
Speed	Controls the movement speed. The bigger the value is, the faster the movement will be.		
Zoom	Zoom out.		
	: Zoom in.		
Focus	Focus far.		
	: Focus near.		
Iris	Image darker.		
ine in a	: Image brighter.		
PTZ movement	Supports eight directions.		
	 Positioning: Click to enter the fast positioning screen, and then click anywhere on the live view screen, the PTZ will turn to this point and move it to the middle of the screen. Zooming: On the fast positioning screen, drag to draw a square on the view. The square supports zooming. Dragging upward is to zoom out, and dragging downward is to zoom in. The smaller the square, the larger the zoom effect. This function is for some series products only and can only be 		
	controlled through mouse operations.		
•	Click , you can control the four directions (left, right, up, and down) PTZ movement through mouse operation.		
•	Click to open the expanded PTZ control panel.		

Expanded PTZ Control Panel

On the basic PTZ control panel, click to open the expanded PTZ control panel to find more options. See Figure 4-87.

Figure 4-87



- The functions with buttons in gray are not supported by the system.
- Right-click once to return to the interface of PTZ basic control panel.

Table 4-22


Icon	Function	Icon	Function
	Preset	Q	Auto Pan
A	Tour	←→	Flip
~>	Pattern	D	Reset
	Auto scan	*	Click the AUX Config icon to open the PTZ functions settings interface.
Ŷ	AUX Switch	▼	Click the Enter Menu icon to open the MENU OPERATION interface.

4.4.3 Configuring PTZ Functions

4.4.3.1 Configuring Presets

Step 1 On the Expanded PTZ Control Panel, click The **Preset** interface is displayed. See Figure 4-88.

Figure 4-88



Step 2 Click the direction arrows to the required position.

Step 3 In the **Preset** box, enter the value to represent the required position.

Step 4 Click **Setting** to complete the preset settings.


4.4.3.2 Configuring Tours

Step 1 On the Expanded PTZ Control Panel, click The **PTZ** interface is displayed.

Step 2 Click the Tour tab.

The **Tour** tab is displayed. See Figure 4-89.

Figure 4-89



Step 3 In the **Patrol No.** box, enter the value for the tour route.

Step 4 In the **Preset** box, enter the preset value.

Step 5 Click Add Preset.

A preset will be added for this tour.

- You can repeat adding more presets.
- Click **Del Preset** to delete the preset for this tour. This operation can be repeated to delete more presets. Some protocols do not support deleting.


4.4.3.3 Configuring Patterns

Step 1 On the Expanded PTZ Control Panel, click

The **PTZ** interface is displayed.

Step 2 Click the Pattern tab.

The Pattern interface is displayed. See Figure 4-90.




- Step 3 In the **Pattern** box, enter the value for pattern.
- Step 4 Click **Start** to perform the directions operations. You can also go to the PTZ Control Panel to perform the operations of adjusting zoom, focus, iris, and directions.
- Step 5 On the PTZ interface, click End to complete the settings.

4.4.3.4 Configuring AutoScan

- Step 1 On the Expanded PTZ Control Panel, click The **PTZ** interface is displayed.
- Step 2 Click the Border tab.

The **Border** interface is displayed. See Figure 4-91.




<u>Step 3</u> Click the direction arrows to position the left and right borders.

4.4.4 Calling PTZ Functions

After you have configured the PTZ settings, you can call the PTZ functions for monitoring from the Expanded PTZ Control Panel. See Figure 4-92.

Figure 4-92



4.4.4.1 Calling Presets

- Step 1 On the Expanded PTZ Control Panel, in the **No.** box, enter the value of the preset that you want to call.
- Step 2 Click to call the preset.
- Step 3 Click again to stop calling the preset.

4.4.4.2 Calling Tours

- Step 1 On the Expanded PTZ Control Panel, in the **No.** box, enter the value of the tour that you want to call.
- Step 2 Click to call the tour.
- Step 3 Click again to stop calling the tour.

4.4.4.3 Calling Patterns

- <u>Step 1</u> On the Expanded PTZ Control Panel, in the **No.** box, enter the value of the pattern that you want to call.
- Step 2 Call to call the pattern.

 The PTZ camera moves according to the configured pattern repeatedly.
- Step 3 Click again to stop calling the pattern.

4.4.4.4 Calling AutoScan

- Step 1 On the Expanded PTZ Control Panel, in the **No.** box, enter the value of the border that you want to call.
- Step 2 Click
 - The PTZ camera performs scanning according to the configured borders.
- Step 3 Click again to stop auto scanning.

4.4.4.5 Calling AutoPan

- Step 1 On the Expanded PTZ Control Panel, click to start moving in horizontal direction.
- Step 2 Click again to stop moving.


4.4.4.6 Using AUX Button

On the Expanded PTZ Control Panel, click , the AUX setting interface is displayed. See Figure 4-93.

In the **Direct Aux** list, select the option that corresponds to the applied protocol.

In the Aux Num box, enter the number that corresponds to the AUX switch on the decoder.

Figure 4-93



4.5 Record File

Device adopts 24-hour continuous record by default. It supports customized record period and record type. Refer to "4.1.4.6 Schedule" for detailed information.

4.6 Playback and Search

4.6.1 Instant Playback

You can view the record file of previous 5 to 60 minutes. Refer to "4.3.2 Navigation bar" for instant playback information.

4.6.2 Search Interface

You can search and playback the record fine on the NVR.

Select **Main Menu > PLAYBACK**, or on the preview interface right click mouse and then select **Search**, you can go to the following interface. See Figure 4-94.

The following figure for reference only.

Figure 4-94




Table 4-23

No.	Function	Description	
1	Display Window	Display the searched recorded video or picture. It supports playing in single-channel, 4-channel, 9-channel, and 16-channel simultaneously. When playing back in a single channel mode, hold down the left mouse button to select the area that you want to enlarge. The area is enlarged after the left mouse button is released. To exit the enlarged status, right-click on the image.	
	Playback	Playback control buttons. Refer to "4.6.2.1 Playback Control" for	
	Controls Bar	detailed information.	
2	Clip	Click to edit the record file and then save specified footages Refer to "4.6.2.3 Clip" for detailed information.	
	Backup	Click to backup record. Refer to "4.6.2.4 Record Backup" for detailed information.	
3	Time Bar	 Display the type and time period of the current recorded video. In the 4-channel layout, there are four time bars are displayed; in the other view layouts, only one time bar is displayed. Click on the colored area to start playback from a certain time. In the situation when you are configuring the settings, rotate the wheel button on the time bar, the time bar is zooming in from 0. In the situation when playback is ongoing, rotate the wheel button on the time bar, the time bar is zooming from the time point where the playback is located. Time bar colors: Green indicates general type; Red indicates external alarm; Yellow indicates motion detection; Blue indicates intelligent events; Purple indicates POS events. For some models, when you are clicking on the blank area in the time bar, the system automatically jumps to the next time point where there is a recorded video located. 	
	Play Status	Includes two playback status: Play and Stop .	
4	Sync	Select the Sync check box to simultaneously play recorded videos of different channels in the same period in multi-channel view.	
	Record type	Select the check box to define the recording type to search for.	
5	Search type	Select the content to play back: Record , PIC , Splice Playback . For details about the selecting search type, refer to "4.6.2.2 Search Type" for detailed information.	
6	Calendar	Click the date that you want to search, the time bar displays the corresponding record. The dates with record or snapshot have a small solid circle under the date.	
7	View Layout and Channel Selection	 In the CAM NAME list, select the channel(s) that you want to play back. The window split is decided by how you select the channel(s). For example, if you select one channel, the playback is displayed in the single-channel view; if you select two to four channels, the playback is displayed in the four-channel view. The maximum is eight channels. Click to switch the streams. indicates main stream, and indicates sub stream. 	

No.	Function	Description
8	List Display	This area includes Mark List and File List. Different series products have different functions. The icons displayed may vary. The actual product shall prevail. Click the Mark List button, the marked recorded video list is displayed. Double-click the file to start playing. Click the File List button, the searched recorded video list is displayed. You can lock/unlock the files. Refer to "4.6.7 File List " for detailed information. Fisheye dewarp. It is to display the dewarp fisheye video. Refer to "4.3.6.2 Fish eye de-warp during playback" for detailed information.
14	Time Bar Unit	You can select 24hr, 2hr, 1hr, or 30min as the unit of time bar. The time bar display changes with the setting.
	<u> </u>	

All the operations here (such as playback speed, channel, time and progress) have relationship with hardware version. Some series NVRs do not support some functions or playback speeds.

4.6.2.1 Playback Control

The playback control interface is shown as below. See Figure 4-95.

Figure 4-95



Refer to the following sheet for more information. See Table 4-24.

Table 4-24

Icon	Function	
▶ II	Play/Pause In slow play mode, click it to switch between play/pause.	
	Stop When playing back, click to stop current playback process.	
◀	 Backward play In normal play mode, left click the button, the file begins backward play. Click it again to pause current play. In backward play mode, click 	
4	 Display previous frame/next frame. When pause the normal playback file, click or playback frame by frame. In frame by frame playback mode, click or to resume normal playback mode. 	
Þ	Slow play In playback mode, click it to realize various slow play modes such as slow play 1, slow play 2, and etc.	
→	Fast forward In playback mode, click to realize various fast play modes such as fast play 1,fast play 2 and etc.	


Icon	Function
	Adjust the volume of the playback.
*	Smart search .
7	Refer to "4.6.3 Smart Search Playback" for detailed information.
Ô	Click the snapshot button in the full-screen mode, the system can snapshot 1 picture. System supports custom snap picture saved path. Connect the peripheral device first, click snap button on the full-screen mode, you can select or create path. Click Start button, the snapshot picture can be saved to the specified path.
	Mark button.
*	This function is for some series product only. Make sure there is a mark button in the playback control pane. Refer to "4.6.4 Mark Playback" for detailed information.
	Display/hide POS information.
	In 1-channel playback mode, you can click it to display/hide POS
	information on the video.
	In 1-channel playback mode, click it to enable/disable display IVS rule
+ 。	information on the video.
	This function is for some series only.

4.6.2.2 Search Type

You can search the recorded videos, splice, or snapshots from HDD or external storage device.

• **From R/W HDD**: Recorded videos or snapshots playback from HDD of the Device. See Figure 4-96.

Figure 4-96



• **From I/O Device:** Recorded videos playback from external storage device. See Figure 4-97.

Click **Browse**, select the save path of recorded video file that you want to play.

Double-click the video file or click to start playing.

Figure 4-97



4.6.2.3 Clip

This function allows you to clip some footages to a new file and then save it to the USB device. See Figure 2-4. Follow the steps listed below.

- Step 1 Select a record first and then click to playback.

 Step 2 Select a time at the time bar and then click to start clip,

 Step 3 Select a time at the time bar and then click to stop clip,

 Step 4 Click system pops up dialogue box to save the clip file.

 Figure 4-98
 - **※** 00:00:00 00:00:00 **№**
- Clip function is for one-channel/multiple-channel.
- Max save 1024 files at the same time.
- This function is not for the file already checked in the file list.

4.6.2.4 Record Backup

This function is to backup files you checked in the file list, or the file you just clip.

- Step 1 Select the recorded video file that you want to back up. You can select the following two types of files:
 - Recorded video file: Click that you want to back up.
 Recorded video file: Click the file List area is displayed. Select the file(s)
 - Saves the clip footages as a record file.

Step 2 Click , the **BACKUP** interface is displayed. See Figure 4-99.




Figure 4-99

Step 3 Click **Backup** to begin the process.

4.6.3 Smart Search Playback

This function is for some series product only.

During playback process, it can analyze the motion detect zone in the scene and give the analysis result.

This function is for channel that already enabled motion detect function (Main Menu >

ALARM > VIDEO DETECT > Motion Detect).

Ш

- Step 1 Select a channel to playback video and then click . You can view the grids on the playback video.
 - This function is for one-channel playback mode.
 - If you are in multiple-channel playback mode, double-click a channel first to switch to one-channel playback mode.
- Step 2 Left click mouse and then drag to select smart search zones(22*18 (PAL), 22*15 (NTSC)).
- Step 3 Click to go to smart search and playback. System is going to playback all motion detect record footages.
- Step 4 Click again to stop smart search function.
 - The motion detect region cannot be the full screen zone.
 - The motion detect region adopts the current whole play pane by default.
 - Selects the other file on the list, system begins playing the motion detect footages of other file.
 - The time bar unit switch, backward play, frame by frame are null when system is playing motion detect file.

4.6.4 Mark Playback

When you are playback record, you can mark the record when there is important information. After playback, you can use time or the mark key words to search corresponding record and then play. It is very easy for you to get the important video information.

Add Mark

When system is playback, click Mark button , you can go to the following interface. See Figure 4-100.

Add Mark

Mark Time 2017-11-08 04:28:22

Name Default OK Cancel

Figure 4-100

Playback Mark

During 1-window playback mode, click mark file list button in Figure 4-94, you can go to mark file list interface. Double-click one mark file, you can begin playback from the mark time.

Play before mark time


Here you can set to begin playback from previous N seconds of the mark time.

Usually, system can playbacks previous N seconds record if there is such kind of record file. Otherwise, system playbacks from the previous X seconds when there is such as kind of record.

Mark Manager

Click the mark manager button on the Search interface (Figure 4-94); you can go to **Manager** interface. See Figure 4-101. System can manage all the record mark information of current channel by default. You can view all mark information of current channel by time.

Figure 4-101



Modify

Double-click one mark information item, you can see system pops up a dialogue box for you to change mark information. You can only change mark name here.

Delete

Here you can check the mark information item you want to delete and then click Delete button, you can remove one mark item.



- After you go to the mark management interface, system needs to pause current playback.
 System resume playback after you exit mark management interface.
- If the mark file you want to playback has been removed, system begins playback from the first file in the list.

4.6.5 Playback Image

Here you can search and play the image. Follow the steps listed below.

- <u>Step 1</u> Select **Main Menu > PLAYBACK**, or on the preview window right click mouse and then click **Search**, you can go to the **Search** interface.
- Step 2 At the top right corner, select image and then input playback interval.
- Step 3 Select date and channel, click to play.

4.6.6 Splice Playback


You can clip the recorded video files into splices and then play back at the same time to save your time.



This function is for some series products only.

- Step 1 Select Main Menu > PLAYBACK, the PLAYBACK interface is displayed.
- Step 2 In the **Search Type** list, select **Splice Playback**; In the Split Mode list, select **4**, **9**, or **16**. See Figure 4-102.

Figure 4-102



Step 3 In the Calendar area, select a date.


Step 4 In the **CAM NAME** list, select a channel.

Only single-channel supports this function.

Step 5 Start playing back splices. See Figure 4-103.

- Click , the playback starts from the beginning.
- Double-click anywhere on the time bar, the playback starts from where you click.

Figure 4-103



4.6.7 File List

Click , system displays file list. It displays the first channel of the record. See Figure 4-104.




Figure 4-104

- Check a file name, double-click the file or click to play.
- Input accurate time at the top column, you can search records of current day.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 164

17-11-08 01:00:00

ď

t

- System max displays 128 record files in one list.
- Click to go back to the calendar/channel selection interface.

Lock or Unlock File

- To lock the recorded video, on the **File List** interface, select the check box of the recorded video, and then click. The locked video will not be overwritten.
- To view the locked information, click , the FILE LOCKED interface is displayed.

The recorded video that is under writing or overwriting cannot be locked.

• To unlock the recorded video, in the **FILE LOCKED** interface, select the video, and then click **Unlock**. See Figure 4-105.




Figure 4-105

4.6.8 Other Aux Functions

4.6.8.1 Digital Zoom

In 1-window playback mode, left click mouse to select any zone on the screen, you can zoom in current zone. Right click mouse to exit.

4.6.8.2 Switch Channel

- During playback mode, select from the dropdown list to switch playback channel.
- The smart search channel does not support this function either.
- When system is playing back the record file, click the number button at the front panel, system begins playing the record file of selected channel dated the same time.

4.7 AI

4.7.1 Al Search

You can search the record file on the NVR and filter the record file meets the corresponding rule. It is suitable for you to play the specified file.

This series NVR products support playback the AI by camera file only. AI by camera means the connected camera does all the AI analytics, and then gives the results to the NVR.

4.7.1.1 Face Detection

You can search the detected faces and play back.

Step 1 Select Main Menu > AI > SMART SEARCH > FACE DETECTION. The FACE DETECTION interface is displayed. See Figure 4-106.





Figure 4-106

Step 2 Select the channel, enter the start time and end time, and set for the gender, age, glasses, beard, and mask. Click **Smart Search**. The results are displayed. See Figure 4-107.

For privacy reason, the human face in the image is pixelated. The actual image is clear.

Figure 4-107



Step 3 Select the face that you want to play back.

The picture with registered information is displayed.

You can also do the following operations to the recorded files.

To back up the recorded files to the external storage device, select files, click
 Backup, select the save path and file type, and then click Start. See Figure 4-108.




Figure 4-108

- To lock the files to make it unable to be overwritten, select the files, and then click
- To add a mark to the file, select the files and then click Add Mark.
- Go to Face Properties and Person Details to view detailed information.

4.7.1.2 Face Recognition

System can search and compare the human face on the video with the face image on the database, and playback the corresponding record file.

The AI search includes two ways: Search by attributes and search by image.

 \prod


This function is for some series products only.

4.7.1.2.1 Searching by Attributes

Step 1 Select Main Menu > AI > SMART SEARCH > FACE RECOGNITION > Search by Attributes.

The **Search by Attributes** interface is displayed. See Figure 4-109.


Figure 4-109



- <u>Step 2</u> Select the channel and set the parameters such as start time, end time, gender, age, glasses, beard, mask, and similarity according to your requirement.
- Step 3 Click Smart Search.

The search result is displayed. See Figure 4-110.

The human face in the image is pixelated. The actual image is clear.



Step 4 Click the picture that you want to play back.

The picture with registered information is displayed.


You can also do the following operations to the recorded files.

- To back up the recorded files to the external storage device, select files, click **Backup**, select the save path and file type, and then click **Start**. See
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click Add Mark.
- Go to the Face Properties and Person Details to view detailed information.

4.7.1.2.2 Search by Image

Step 1 Select Main Menu > AI > SMART SEARCH > FACE RECOGNITION > Search by Image.


The **Search by Image** interface is displayed. See Figure 4-111.



- <u>Step 2</u> Select the channel and set the parameters such as start time, end time, gender, age, glasses, beard, mask, and similarity according to your requirement.
- Step 3 Click Smart Search.

The search result is displayed. See Figure 4-112.

The human face in the image is pixelated. The actual image is clear.



Step 4 Click the picture that you want to play back.

The picture with registered information is displayed.

You can also do the following operations to the recorded files.


- To back up the recorded files to the external storage device, select files, click **Backup**, select the save path and file type, and then click **Start**. .
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click **Add Mark**.
- Go to the Face Properties and Person Details to view detailed information.

4.7.1.3 IVS

You can search and playback the alarm record files.

Step 1 Select Main Menu > AI > SMART SEARCH > IVS.

The **IVS** interface is displayed. See Figure 4-113.



- <u>Step 2</u> Select a channel, start time, end time, event type, and then click Smart search, The search result is displayed.
- Step 3 Click the picture that you want to play back.

You can also do the following operations to the recorded files.


- To back up the recorded files to the external storage device, select files, click
 Backup, select the save path and file type, and then click Start.
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click **Add Mark**.
- Go to the Face Properties and Person Details to view detailed information.

4.7.1.4 Human Body Detection

You can search the human body and search the alarm record during the specified period.

Step 1 Select Main Menu > AI > SMART SEARCH > HUMAN BODY DETECTION. The Human Body Detection interface is displayed. See Figure 4-114.

Figure 4-114




- Step 2 Select a channel, start time, end time, and set corresponding parameters.
- Step 3 Click Smart search.

Ш

The search result is displayed. See Figure 4-115.

For privacy reason, the human face in the image is pixelated.

Figure 4-115



Step 4 Select one or multiple results, and then you can

- To back up the recorded files to the external storage device, select files, click Backup, select the save path and file type, and then click Start.
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click Add Mark.
- Go to the Face Properties and Person Details to view detailed information.

4.7.1.5 Vehicle Detection


You can search according to the vehicle parameters and search the alarm record during the specified period.



This function is for some series products only.

Step 1 Select Main Menu > AI > SMART SEARCH > VEHICLE DETECTION. The VEHICLE DETECTION interface is displayed. See Figure 4-116.

Figure 4-116



Step 2 Select a channel and set parameters.

- System supports plate fuzzy search.
- System searches all plate numbers by default if you have not set a plate number.
- Step 3 Click Smart search.

The search result is displayed.

Step 4 Select one or multiple results, and then you can:

- To back up the recorded files to the external storage device, select files, click **Backup**, select the save path and file type, and then click **Start**.
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click Add Mark.

4.7.1.6 Non-motor Vehicle Detection


You can search according to the non-motor vehicle parameters and search the alarm record during the specified period.

 \square

This function is for some series products only.


Step 1 Select Main Menu > AI > SMART SEARCH > NON-MOTOR VEHICLE DETECTION. The NON-MOTOR VEHICLE DETECTION interface is displayed. See Figure 4-117.

Figure 4-117



- <u>Step 2</u> Select the channel and the time, and then select one or multiple features from **Type**, **Vehicle Color**, **People Number**, or **Helmet**.
- Step 3 Click Smart Search.

The search result is displayed. See Figure 4-118. Figure 4-118



Step 4 Select one or multiple results, and then you can

- To back up the recorded files to the external storage device, select files, click
 Backup, select the save path and file type, and then click Start.
- To lock the files to make it unable to be overwritten, select the files, and then click Lock.
- To add a mark to the file, select the files and then click Add Mark.


Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 177

4.7.1.7 People Counting

You can detect the people amount in the specified zone, and display the statistics image.

Step 1 Select Main Menu > AI > SMART SEARCH > PEOPLE COUNTING. The PEOPLE COUNTING interface is displayed. See Figure 4-119.

Figure 4-119



Step 2 Set parameters such as channel, report type, start time, end time, etc. See Table 4-25.

Table 4-25

Parameter	Description
Channel	Select the channel you want to search people amount.
Rule	Select the rule from the dropdown list.
Report Type	Select report type from the dropdown list: daily report, monthly report, yearly report.
Start time/end time	Set search start time and end time.
Туре	Select from the dropdown list.

4.7.1.8 Heat map


You can detect the active objects distribution in the monitor zone during the specified period, and use different colors to display on the heat map report.

4.7.1.8.1 Normal

Step 1 Select Main Menu > AI > SMART SEARCH > HEAT MAP > NORMAL. The Normal interface is displayed. See Figure 4-120.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 178

Figure 4-120



- Step 2 Select channel, start time, end time.
- Step 3 Click Search.
- Step 4 System display heat map report.


Click **Export**, and then select path. Click Save to save current report to the USB device.

4.7.1.8.2 Fisheye

Step 1 Select Main Menu > AI > SMART SEARCH > HEAT MAP > Fisheye.

The **Fisheye** interface is displayed. See Figure 4-121.

Figure 4-121



Step 2 Set Channel, Type, Start Time, End time.

Step 3 Click Search.

Step 4 System displays heat map report.

Click **Export** and then select saved path, click **Save** to save the heat map report to the USB device.

4.7.2 Parameters

4.7.2.1 Smart Plan


The smart plan is for the smart network camera. It includes IVS, human face detection, human face recognition, human body detection, people counting, heat map. If you do not set a rule here, you cannot use these AI intelligent functions when you are connecting to a smart network camera.

This series NVR products support AI by camera only. Make sure the connected network camera supports intelligent functions. For NVR, it just displays the intelligent alarm information from the smart network camera and set or playback the record file.

Step 1 Select Main menu > AI > PARAMETERS > SMART PLAN.
The SMART PLAN interface is displayed. See Figure 4-122.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 180

Figure 4-122



Step 2 Select a channel number.

System displays different smart plan interfaces since the remote device may supports different functions.

• The interface is shown as Figure 4-123 if the remote device supports preset function.




Figure 4-123


- 1) Select a channel.
- 2) Select a preset.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 181

- 3) Click the smart plan icon at the bottom left. The icon becomes highlighted.
- 4) Click Apply.



- Click Add to add a preset.
- Once the remote device does not support preset function, the interface is shown as in Figure 4-124.



- 1) Select a channel.
- 2) Click the smart plan icon. The icon becomes blue highlighted.
- 3) Click Apply.

4.7.2.2 Face Detection

The Device can analyze the pictures captured by the camera to detect whether the faces are on the pictures. You can search and filter the recorded videos the faces and play back.

Preparations

The connected camera shall support human face detection function.

Step 1 Select Main Menu > AI > PARAMETERS > FACE DETECTION.
The FACE DETECTION interface is displayed. See Figure 4-125.

Channel D2 v Type Al by Camera v
Enable Rule Setting

Period Setting
Alarm Out Setting Latch 0 Sec.

Alarm Upload Setting
PTZ Activation Setting
D2 v Type Al by Camera v
Rule Setting
Latch 0 Sec.

Send Email
POST-Record 10 Sec.

Voice Prompts None v

Figure 4-125

- <u>Step 2</u> In the **Channel** list, select a channel that you want to configure face detection function, and then enable it.
- Step 3 Configure the parameters. See Table 4-26.

Refresh

Default

Table 4-26

Back

Apply

Parameter	Description
Туре	This series NVR products support AI by Camera only. AI by Camera means the connected camera does all the AI analytics, and then gives the results to the NVR.
Face Rol	Check the box to enable Face Rol function, system displays human face at the enhanced way.
Rule	Click Setting to draw areas to filter the target. You can configure two filtering targets (maximum size and minimum size). When the target is smaller than the minimum size or larger than the maximum size, no alarms will be activated. The maximum size should be larger than the minimum size. Left click to drag the four angles to adjust the size.
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 183

Parameter	Description
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Alarm Upload	 Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center). This function is for some series products only. You need to set the alarm center first. For details, see "4.12.11 Alarm Cente."
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email."
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.
7 toti vation	 Tripwire alarm supports to activate PTZ preset point only.
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions."
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.
	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.
Tour	• You need to set the time interval and mode for tour first, see "4.17.2 Tour. "
	 After the tour is over, the preview interface is restored to the screen split mode before the tour.
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.
Buzzer	Select the check box to activate the buzzer when an alarm occurs.

Step 4 Click **Apply** to complete the settings.

4.7.2.3 Face Recognition

You can compare the detected faces with the faces in the library to judge if the detected face belongs to the library. The comparison result will be displayed on the AI mode live view screen and smart search interface, and link the alarms.


This series NVR products support AI by camera only.

You can use the connected camera to realize Al function. Make sure the connected camera

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 184

supports human face detection function.

<u>Step 1</u> Select **Main Menu > AI > PARAMETERS > FACE RECOGNITION**. The **FACE RECOGNITION** interface is displayed. See Figure 4-126.



- <u>Step 2</u> In the **Channel** list, select a channel that you want to configure face recognition function, and then enable it.
- Step 3 At Type, system supports Al by Camera only.
- Step 4 Set parameters. See Table 4-27.

Table 4-27

Parameter	Description
Rol	Check the box to enable Rol function, system displays human face at the
KUI	enhanced way.
	Click Setting to draw areas to filter the target.
	You can configure two filtering targets (maximum size and minimum size).
Rule	When the target is smaller than the minimum size or larger than the maximum
	size, no alarms will be activated. The maximum size should be larger than the
	minimum size. Left click to drag the four angles to adjust the size.
Period	Configure the period and in the set time range, the corresponding
	configuration item will be linked to start the alarm.
Target Face	Click Target Face Database, system displays face database list. Select a
Database	database from the dropdown list to compare.

Step 5 Set the Target Face Database.

Step 6 (Optional) Click to modify the similarity. The lower the number is, the easier the alarm linkage will trigger.

Step 7 Click to set the alarm linkage. See Figure 4-127.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 185



Refer to "4.7.3 Database" for human target database settings information.



<u>Step 8</u> Configure the parameters. See Table 4-28. Table 4-28

Parameter	Description
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center). This function is for some series products only.
	 You need tol set the alarm center first. For details, see "4.12.11 Alarm Cente."
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.
	You need to set the email first. For details, see "4.12.8 Email."
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 186

Parameter	Description
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.
	Tripwire alarm supports to activate PTZ preset point only.
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions."
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.
Tour	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.
Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."
	 After the tour is over, the preview interface is restored to the screen split mode before the tour.
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.
Buzzer	Select the check box to activate the buzzer when an alarm occurs.

Step 9 Click **OK**, system goes back to human face recognition interface.

Step 10 Click **Apply** to complete the settings.

The interface is shown as Figure 4-128 if there is matched result.



4.7.2.4 IVS (General Behavior Analytics)

The IVS function processes and analyzes the images to extract the key information to match with the specified rules. When the detected behaviors match with the rules, the system activates alarms.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 187

 \square

- This function is for some series product only.
- IVS function and human face detection function cannot be valid at the same time.


The IVS function environment shall meet the following requirements:

- The object total size shall not be more than 10% of the whole video.
- The object size on the video shall not be more than 10pixels*10 pixels. The abandoned object size shall be more than 15pixels*15 pixels (CIF resolution). The object width shall not be more than 1/3 of the video height and width. The recommended height is 10% of the video.
- The object and the background brightness different shall be more than 10 grey levels.
- The object shall remain on the video for more than 2 seconds. The moving distance is larger than its own width and shall not be smaller than 15pixels (CIF resolution).
- The surveillance environment shall not be too complicated. The IVS function is not suitable for the environment of too many objects or the changing light.
- The surveillance environment shall not contain glasses, reflection light from the ground, and water. Free of tree branches, shadow, mosquito and bugs. Do not use the IVS function in the backlight environment, avoid direct sunlight.

Step 1 Select Main Menu > AI > PARAMETERS > IVS.

The **IVS** interface is displayed. See Figure 4-129.

Figure 4-129



Step 2 Select a channel from the dropdown list.

Click **Add** and then set corresponding rule. See Figure 4-130.

Click to delete the selected rule.




Figure 4-130

Step 3 Set corresponding parameters.

Step 4 Click Apply.

4.7.2.4.1 Tripwire

When the detection target crosses the warning line along the set direction, the system performs an alarm linkage action.

Step 1 Select Main Menu > AI > PARAMETERS > IVS.
In the Type drop-down list, select Tripwire. See Figure 4-131.

Channel D6
DDNSType Alby Camera

I Enable Name Type Draw Trigger Delete

I Rule1 Tripwire
Ab
Add

Figure 4-131

Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video, the system displays as Figure 4-132.




Figure 4-132

2) Configure the parameters. See Table 4-29. Table 4-29

Parameter	Description
Name	Customize the rule name.
Direction	Set the tripwire direction, including A→B, B→A and A↔B.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse. Each rule can set 2 target filters (maximum size and minimum size), that is,
	when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.
Al Recognition	Select Al recognition and the system displays alarm target. The default selection is person and motor vehicle and system automatically identifies the person and motor vehicle appeared within the monitoring range.
	When you select IVS of AI by camera, the connected channel shall support tripwire function.

- 3) Press and hold down the left button on the monitor screen to draw the line. The line can be a straight line or a curve.
- 4) Click **OK** to complete the rule setting.

Step 3 Click

System displays the **Trigger** interface. See Figure 4-133.

Trigger

Period Setting Latch 10 Sec.

Alarm Out Setting Latch 10 Sec.

Alarm Upload Send Email

Record Channel Setting

PTZ Activation Setting Post-Record 10 Sec.

Tour Setting

Buzzer Log

Voice Prompts None

Figure 4-133

Step 4 Configure the parameters. See Table 4-30. Table 4-30

Parameter	Description
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).
	This function is for some series products only.
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente."
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.
	You need to set the email first. For details, see "4.12.8 Email."

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level3,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 192

Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule." Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Activation • Tripwire alarm supports to activate PTZ preset point only. • You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." Delay At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour." • After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Select the check box to activate the buzzer when an alarm occurs.	Parameter	Description
Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. • Tripwire alarm supports to activate PTZ preset point only. • You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." Delay At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour." • After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first.		choices). When an alarm occurs, the NVR device activates the channel for recording.
When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.		"4.1.4.6 Schedule."
You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.	· · -	When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.
Delay At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.		 Tripwire alarm supports to activate PTZ preset point only.
range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour." • After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first.		PTZ Functions."
Tour You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.	Delay	
 You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first. 		local interface of the NVR device displays the selected channel screen.
mode before the tour. Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first.	lour	 You need to set the time interval and mode for tour first, see "4.17.2 Tour."
when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first.		
Voice list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first.	Log	
9		list. System plays the audio file when the alarm occurs.
	Buzzer	Select the check box to activate the buzzer when an alarm occurs.

Step 5 Click **OK** to save the alarm setting.


System displays the IVS interface.

Step 6 Select the **Enable** check box and click **Apply** to complete the tripwire setting.

4.7.2.4.2 Intrusion


When the detection target passes the edge of the monitoring area, and enters, leaves or traverses the monitoring area, the system performs an alarm linkage action.

Step 1 In the **Type** drop-down list, select **Intrusion**. See Figure 4-134.



1) Click to draw the rule on the surveillance video, the system displays as Figure 4-135.

Figure 4-135



2) Configure the parameters. See Table 4-31.

Table 4-31

Parameter	Description
Name	Customize the rule name.
Action	Set the intrusion action, including appear and crossing area.
Direction	Set the direction to cross the area, including enter, exit and both.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.
Al recognition	Select AI recognition and the system displays alarm target. The default selection is person and motor vehicle and system automatically identifies the person and motor vehicle appeared within the monitoring range.

- Press and hold down the left button on the monitoring screen to draw the monitoring area.
- 4) Click **OK** to complete the rule setting.

Step 3 Click , you can refer to the "4.7.2.4.1 Tripwire" to set other parameters.


Step 4 Select the **Enable** check box and click **Apply** to complete the intrusion setting.

4.7.2.4.3 Abandoned Object Detection

System generates an alarm when there is abandoned object in the specified zone.

Step 1 In the **Type** drop-down list, select **Abandoned Object.** The interface is shown as Figure 4-136.

Figure 4-136



Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video. See Figure 4-137.




Figure 4-137

2) Set parameters. See Table 4-32.

Table 4-32

Parameter	Description
Preset	Select a preset you want to use IVS
Name	Input customized rule name

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level3,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 196

Duration	System can generate an alarm once the object is in the zone for the specified period.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.

- 3) Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.


Step 3 Click Step 4 Click Apply to complete the setup.

4.7.2.4.4 Fast moving

You can detect the fast moving object in the specified zone.


Step 1 In the **Type** drop-down list, select **Fast Moving**. The interface is shown as below. See Figure 4-138.

Figure 4-138



Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video. See Figure 4-139. Figure 4-139



Set parameters. See Table 4-33.

Table 4-33

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 198

Parameter	Description
Preset	Select a preset you want to use IVS
Name	Input customized rule name
Sensitivity	You can set alarm sensitivity. The value ranges from 1 to 10. The default setup is 5.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.

- Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.

Step 3 Click , you can refer to the "4.7.2.4.1 Tripwire" to set other parameters.

Step 4 Click **Apply** to complete the setup.

4.7.2.4.5 Crowd Gathering

System can generate an alarm once the people amount gathering in the specified zone is larger than the threshold.

<u>Step 1</u> In the **Type** drop-down list, select **Crowd Gathering Estimation**.

The interface is shown as below. See Figure 4-140.





Figure 4-140

Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video. See Figure 4-141.

Figure 4-141



2) Set parameters. See Table 4-34.

Table 4-34

Parameter	Description
Preset	Select a preset you want to use IVS.
Name	Input customized rule name
Duration	Set the minimum time that the object stays until the alarm is triggered.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.

- 3) Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.

Step 3 Click , you can refer to the "4.7.2.4.1 Tripwire" to set other parameters.


Step 4 Click **Apply** to complete the setup.

4.7.2.4.6 Parking

When the detection target stays in the monitoring area for more than the set duration, the system performs alarm linkage action.


Step 1 In the **Type** drop-down list, select **Parking.**The interface is shown as below. See Figure 4-142.

Figure 4-142



Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video. See Figure 4-143. Figure 4-143



2) Set parameters. See Table 4-35.

Table 4-35

Parameter	Description
Preset	Set the preset point for IVS detection according to the actual needs.
Name	Customize the rule name.
Duration	Set the minimum time that the object stays until the alarm is triggered.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.

- 3) Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.

Step 3 Click Step 4 Click Apply to complete the setup.

4.7.2.4.7 Missing Object Detection

System generates an alarm when there is missing object in the specified zone.

<u>Step 1</u> In the **Type** drop-down list, select **Missing Object**. The interface is shown as below. See Figure 4-144.

Channel D8 ▼ Type Al by Camera Enable Delete Name Туре Draw Trigger \checkmark Missing Intrusion * 亩 Loitering ... * Rule 4 Parking Fast-Moving • * Abandoned • Rule 6 亩 Missing * Crowd Ga... Rule 8

Figure 4-144

Step 2 Draw the detection rule.


Default Refresh

1) Click to draw the rule on the surveillance video. See Figure 4-145.

Add

Cancel

Figure 4-145



2) Set parameters. See Table 4-36. Table 4-36

Parameter	Description
Preset	Set the preset point for IVS detection according to the actual needs.
Name	Customize the rule name.
Duration	Set the minimum time that the object stays until the alarm is triggered.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse. Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not
	be smaller than the minimum size.

- 3) Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.

Step 3 Click Step


Step 4 Click **Apply** to complete the setup.

4.7.2.4.8 Loitering Detection

System can generate an alarm once the object is staying in the specified zone longer than the threshold.


Step 1 In the **Type** drop-down list, select **Loitering Detection**. The interface is shown as below. See Figure 4-146.

Figure 4-146



Step 2 Draw the detection rule.

1) Click to draw the rule on the surveillance video. See Figure 4-147. Figure 4-147



2) Set parameters. See Table 4-37.

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level3,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 204

Table 4-37

Parameter	Description
Preset	Set the preset point for IVS detection according to the actual needs.
Name	Customize the rule name.
Duration	Set the minimum time that the object stays until the alarm is triggered.
Filter target	Click to filter the target. Check the blue wireframe and adjust the size of the area with the mouse.
	Each rule can set 2 target filters (maximum size and minimum size), that is, when the passing target is smaller than the minimum target or larger than the maximum target, no alarm will be generated. The maximum size should not be smaller than the minimum size.

- 3) Draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.
- 4) Click **OK** to complete the rule setting.
- Step 3 Click , you can refer to the "4.7.2.4.1 Tripwire" to set other parameters.
- Step 4 Click **Apply t**o complete the setup.
- 4.7.2.5 Video Structuring (Metadata)

The device can detect and extract key features from the human body, motor vehicle, and non-motor vehicles in the video, and then build a structured database. You can search any target you need with these features.


After enable the video structuring function, the corresponding smart plan can become valid.

Preparations

Make sure the connected camera supports video structuring (metadata) function.

Step 1 Select Main Menu > AI > PARAMETERS > VIDEO STRUCTURING. The VIDEO STRUCTURING interface is displayed. See Figure 4-148.

Figure 4-148



<u>Step 2</u> In the **Channel** list, select a channel that you want to configure video structuring function, and then enable it. See Table 4-38.

Table 4-38

Parameter	Description
Human Detection	Select Human detection and then check the box to enable this function.
Face Detect	Select Face Detect and then check the box to enable this function.
Vehicle detection	Select Vehicle detection and then check the box to enable this function.
Non-motor Vehicle	Select Non-motor Vehicle and then check the box to enable this function.


Step 3 Click Apply.

4.7.2.6 Crowd Distribution

Connecting to the front-end device that supports crowd distribution function, system can support the crowd distribution function. It supports crowd distribution event subscription and receive. It supports crowd distribution global and regional density settings, linkage alarm and triggered video storage, or upload the data to the platform. After connecting to the general network camera, the system adopts the algorithm to analyze the crowd density and trigger the corresponding actions.

Step 1 Select Main Menu > AI > PARAMETERS > CROWD DISTRIBUTION. The CROWD DISTRIBUTION interface is displayed. See Figure 4-149.

Figure 4-149



Step 2 Configure parameters. See Table 4-39.

Table 4-39

Parameter	Description
Channel	Select a channel from the dropdown list.
Enable	Check the box to enable the function.
Global	Check the box to enable global crowd distribution alarm.
Crowd Density	Configure the alarm threshold. The default setup is 4 persons/ m^2 . The value ranges from 2 to 10.
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.

Parameter	Description	
Alarm	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).	
Upload	 This function is for some series products only. 	
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." 	
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.	
	You need to set the email first. For details, see "4.12.8 Email."	
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.	
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.	
	 Tripwire alarm supports to activate PTZ preset point only. 	
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." 	
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.	
_	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.	
Tour	• You need to set the time interval and mode for tour first, see "4.17.2 Tour. "	
	 After the tour is over, the preview interface is restored to the screen split mode before the tour. 	
Log	Select the check box, the NVR device records the alarm information in the low when an alarm occurs.	
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.	
Buzzer	Select the check box to activate the buzzer when an alarm occurs.	

Step 3 Click **Apply** to complete the setup.

4.7.2.7 People Counting


System adopts video image and graphics analysis technology. System can calculate the entry/exit people amount in the specified zone on the video. It can generate an alarm when the amount has exceeded the threshold.

4.7.2.7.1 People Counting

Step 1 Select Main Menu > AI > PARAMETERS > PEOPLE COUNTING > PEOPLE

The **PEOPLE COUNTING** interface is displayed. See Figure 4-150.

Figure 4-150



Step 2 Configure parameters. See Table 4-40.

Table 4-40

Parameter	Description
Channel	Select a channel from the dropdown list.
Enable	Check the box to enable the function.
Rule Type	Select a people counting rule type.
Rule	Click RULE to set statistics region, name, direction.

Parameter	Description	
Alarm	 Click Setting to set alarm parameters. OSD Overlay: Check the box here; you can view the people amount on the surveillance video. Entry No.: You can set people entry amount. System can generate an alarm once the amount has exceeded the threshold. Exit No.: You can set people exit amount. System can generate an alarm once the amount has exceeded the threshold. Remaining No.: You can set people staying amount in the zone. System can generate an alarm once the amount has exceeded the threshold. 	
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.	
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.	
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.	
Alarm	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).	
Upload	This function is for some series products only.	
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." 	
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.	
Record Channel	You need to set the email first. For details, see "4.12.8 Email." Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions."	
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.	
Tour	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour. " • After the tour is over, the preview interface is restored to the screen split mode before the tour.	
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.	

Parameter	Description
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs.
	Refer to "4.18.1 File Manage " to add audio file first.
Buzzer	Select the check box to activate the buzzer when an alarm occurs.

Step 3 Click **Apply** to complete the setup.

4.7.2.7.2 Queuing

After connecting to the AI fisheye camera that supports the queuing function, system can realize the corresponding linkage actions once the people amount in the queue or the waiting time has trigger an alarm. Select a region first to set the corresponding actions. For the same line, the queue people number alarm and queue time alarm has the same linkage actions.

Step 1 Select Main Menu > AI > PARAMETERS > PEOPLE COUNTING > Queuing. The Queuing interface is displayed. See Figure 4-151.




Figure 4-151

Step 2 Configure parameters. See Table 4-41.

Table 4-41

Parameter	Description
Channel	Select a channel from the dropdown list.
Region	Set queue detection region.
Alarm Type	Select Queue People No. Alarm or Queue Time Alarm.
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.

Parameter	Description	
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.	
Latch	When the alarm ends, the alarm extended for a period of time. The time rai from 0 seconds to 300 seconds.	
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center). This function is for some series products only. You need to set the alarm center first. For details, see "4.12.11 Alarm Center"	
Send Email	Cente." Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email."	
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.	
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.	
Activation	Tripwire alarm supports to activate PTZ preset point only.	
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." 	
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.	
_	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.	
Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."	
	 After the tour is over, the preview interface is restored to the screen split mode before the tour. 	
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.	
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.	
Buzzer	Select the check box to activate the buzzer when an alarm occurs.	

Step 3 Click **Apply** to complete the setup.

4.7.2.8 Heat map

Heat map technology can monitor the active objects distribution status on the specified zone during a period of time, and use the different colors to display on the heat map.

Step 1 Select **Main Menu > AI > PARAMETERS > HEAT MAP.**The **HEAT MAP** interface is displayed. See Figure 4-152.




Figure 4-152

Step 2 Select a channel number and then check the box to enable the function.

Step 3 Click Setting button.

The **Setting** interface is displayed. See Figure 4-153.

Figure 4-153



<u>Step 4</u> Set arm/disarm period. There are two modes for you to set the period so that the system can detect the specified zone.

- Define the period by drawing.
- 1. Select the corresponding date and then use mouse to drag the bar to set period.
 - ♦ Define for the whole week: Click next to All, all the icon switches to you can define the period for all the days simultaneously.
 - ◇ Define for several days of a week: Click before each day one by one, the icon switches to Sylvary simultaneously.
 Define for several days of a week: Click before each day one by one, the icon switches to sylvary simultaneously.
- Define the period by editing.
 - 1) Click the of the corresponding date, and then set the period on the pop-up interface. Click OK to save.
 - ♦ There are six periods for you to set for each day.
 - Under Copy, select All to apply the settings to all the days of a week, or select specific day(s) that you want to apply the settings to.
 - Click Apply to save the settings.

Step 5 Click **Apply** button to complete setup.

After set the heat map parameters, go to **Main Menu > INFO > EVENT > HEAT MAP** to view heat map report. Refer to "4.7.1.8 Heat map" for detailed setup information.

4.7.2.9 ANPR


System uses the video recognition technology to extract the plate number on the surveillance video and then compare it with the specified plate information. System can trigger an alarm once there is a matched result.

You can set different plate recognition rule, alarm linkage actions in different environments (blacklist, whitelist and regular).

Step 1 Select Main Menu > AI > PARAMETERS > ANPR.

The **ANPR** interface is displayed. See Figure 4-154.

Figure 4-154



Step 2 Select the Enable check box to enable ANPR.

Step 3 Click Regular (default), Blacklist or Whitelist tab to configure it.

Before activate blacklist alarm or whitelist alarm, you need to add the corresponding plate information. Refer to "4.7.3.2 B/W List" for detailed information.

- Regular: Device triggers an alarm when it detects any plate number.
- Blacklist: Device triggers an alarm when it detects plate number in the blacklist.
- Whitelist: Device triggers an alarm when it detects plate number in the whitelist.

Step 4 Set parameters. See Table 4-42.

Table 4-42

Parameter	Description	
Period	Configure the period and in the set time range, the corresponding configuration item will be linked to start the alarm.	
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.	
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.	
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).	
	 This function is for some series products only. 	
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." 	
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.	
	You need to set the email first. For details, see "4.12.8 Email."	

Select the check box and select the needed recording channel (support mult choices). When an alarm occurs, the NVR device activates the channel recording. Channel You need to enable intelligent recording and auto recording first. For details, "4.1.4.6 Schedule." Select the check box and click Setting to select the channel and PTZ act When an alarm occurs, the NVR device associates the channel to perform corresponding PTZ action. For example, activate the PTZ in channel one to to the preset point X.	l for	
Select the check box and click Setting to select the channel and PTZ act When an alarm occurs, the NVR device associates the channel to perform corresponding PTZ action. For example, activate the PTZ in channel one to	tion.	
PTZ Activation Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configu PTZ Functions."	the turn	
Delay At the end of the alarm, the recording extends for a period of time. The trange is from 10 seconds to 300 seconds.	time	
Select the check box and select the channel for tour. When an alarm occurs, local interface of the NVR device displays the selected channel screen. Tour You need to set the time interval and mode for tour first, see "4.17.2 Tou"		
 After the tour is over, the preview interface is restored to the screen spli mode before the tour. 		
Log Select the check box, the NVR device records the alarm information in the when an alarm occurs.	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.	
Voice Prompts Check the box and then select the corresponding audio file from the dropdo list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.	own	
Buzzer Select the check box to activate the buzzer when an alarm occurs.		

Step 5 Click Apply.

4.7.3 Database

After you successfully set the face library, the detected human face can compare with the image on the face library. The face library settings include create face library, add human face and human face modeling.

 \square


For privacy reason, the human face is pixelated.

4.7.3.1 Creating Human Face Library

Step 1 Select Main Menu > AI > DATABASE > FACE LIBRARY.

The **FACE LIBRARY** interface is displayed. See Figure 4-155.


Figure 4-155



Step 2 Select a channel and then click **Add**.

System displays **Add** interface. See Figure 4-156.

Figure 4-156



Step 3 Input human face library name and then click **Save**. System successfully saves the face library.

Adding Face Pictures

You can add face pictures to the existing libraries one by one or by batch, or add from the detected faces.



To add face pictures one by one or by batch, you need to get the pictures from the USB storage device. The picture size should be smaller than 256K with resolution between 200×200–6000×5000.

Adding One Face Picture


You can add one face picture to the database. It is for the scenario that the registered human face picture amount is small.

 $\underline{\text{Step 1}} \hspace{0.1in} \text{Select Main Menu > Al > DATABASE > FACE LIBRARY}.$

The FACE LIBRARY interface is displayed.

Step 2 Click of the library that you want to configure.
The **Details** interface is displayed. See Figure 4-157.


Figure 4-157



Step 3 Click Register ID.

The **Register ID** interface is displayed. See Figure 4-158.


Figure 4-158



Step 4 Click to add a face picture.


The **Browse** interface is displayed. See Figure 4-159.

Figure 4-159



Step 5 Select a face picture and enter the registration information. See Figure 4-160.

Figure 4-160



Step 6 Click OK.

The system prompts the registration is successful.

Step 7 On the **Details** interface, click **Search**.

The system prompts modeling is successful. See Figure 4-161.

If the system prompts the message indicating modeling is in process, wait a while and then click **Search** again. If modeling is failed, the registered face picture cannot be used for face recognition.

Name Gender All ID No. Modeli... All Reset Search

Register ID Batch re... Modeling Delete All

Gender: Mane inc
Gender: Female
ID No.:

Modeling Successful Modeling Successful

Figure 4-161

Adding Face Pictures in Batch

System supports batch add if you want to import several human face image at the same time.

Step 1 Give a name to the face picture by referring to the following table. See Table 4-43.

Table 4-43

Naming format	Description
Name	Enter the name.
Gender	Enter 1 or 2. 1 represents male, and 2 represents female.
Birthday	Enter numbers in the format of yyyy-mm-dd.
Country	Enter the abbreviation of country. For example, CN for China.
ID Type	1 represents ID card; 2 represents passport; 3 represents military officer password.
ID No.	Enter the ID number.
Address	Enter the address.

Step 2 Select Main Menu > AI > DATABASE > FACE LIBRARY.


The **FACE LIBRARY** interface is displayed.

Step 3 Click of the library that you want to configure.
The **Details** interface is displayed. See Figure 4-157.

Step 4 On the **Details** interface, click **Batch register**.

The **Batch register** interface is displayed. See Figure 4-162.

Figure 4-162



<u>Step 5</u> Click **Select file, max select 500 each time** or **Select a folder** to import face pictures. <u>Step 6</u> Click **OK** to complete batch registration.

4.7.3.2 Black/whitelist


To manage vehicle management, you can add the corresponding plate number on the blacklist or whitelist. System can compare the detected plate information with the plate on the blacklist/whitelist and then trigger the corresponding alarm linkage.

After enable black/whitelist, on the preview interface, the plate in the blacklist is displayed as red on the plate list, the plate in the whitelist is displayed as green on the plate list. For the plate not in the black/whitelist, the plate is displayed as white.

Adding B/W List

Step 1 Select Main Menu > AI > DATABASE > B/WLIST.
The B/W List interface is displayed. See Figure 4-163.

Figure 4-163



Step 2 Set plate information and then select Blacklist or Whitelist.

Step 3 Click Add.

Deleting Black/Whitelist

Set type as **Whitelist**, **Blacklist**, or **All**, and then click **Search**. System displays black/whitelist information. See Figure 4-164.

- On the searched results list, check the box before the plate number and then click **Delete**, or click the of the corresponding plate number, you can delete the plate information on the black/whitelist.
- Click **Clear** to delete all plate information on the black/whitelist.




Figure 4-164

Import/Export Black/whitelist

System supports export black/whitelist to the USB device, or import black/whitelist from the USB device. System supports .csv or .xlsx file. The export file format is .csv.

- Import black/whitelist: Click Import and then select the corresponding file, click Browse to import the file.
- Export black/whitelist: Click Export and then select the file storage path and then click Save.


4.8 Event Manager

4.8.1 Alarm Info

You can search, view and back up the alarm information.

Step 1 Select Main Menu > ALARM > ALARM INFO.
The ALARM INFO interface is displayed. See Figure 4-165.





- <u>Step 4</u> In the **Type** list, select the event type; In the **Start Time** box and **End Time** box, enter the specific time.
- Step 5 Click Search.

The search results are displayed.

Step 6 Click **Backup** to back up the search results into the external storage device.



- Select an alarm event log and then click **Backup** to back up it to peripheral USB device.
- Select an alarm event log, click to play the recorded video of alarm event. Double-click a log or click Details to view the detailed information of the event.

4.8.2 Alarm Status

You can view NVR alarm event, and remote channel alarm event.

Select **Main Menu > ALARM > ALARM STATUS**, the **ALARM STATUS** interface is displayed. See Figure 4-166.

Figure 4-166




4.8.3 Alarm Input

Step 1 Select Main menu > ALARM > ALARM INPUT, The ALARM INPUT interface is displayed. See Figure 4-167.

Step 2 There are four alarm types.

- Local alarm: After connect the alarm device to the NVR alarm input port, system
 can trigger the corresponding alarm operations when there is alarm signal from
 the alarm input port to the NVR.
- Network alarm: NVR trigger corresponding alarm operations when it receives the alarm signal via the network transmission.
- IPC external alarm: When the network camera connected peripheral device has triggered an alarm, it can upload the alarm signal to the NVR via the network transmission. The system can trigger the corresponding alarm operations.
- IPC offline alarm: When the network connection between the NVR and the network camera is off, the system can trigger the corresponding alarm operations.

Figure 4-167



Step 3 Set **Alarm In** channel number and then select the **Enable check** box to enable the function.

Step 4 Configure parameters. See Table 4-44. Table 4-44

Message

Parameter	Description
Alarm in	Select a channel to set alarm.
Enable	Check the box to enable the function.
Alarm Name	Enter an alarm name.
Туре	NO (normal open) or NC (normal close).
Period	Define a period during which the alarm is active. For details, see "Setting Period in 4.8.5.1 Motion Detect."
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Show	Check box to enable a pop-up message in your local host PC.

choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule." Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Activation Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.	Parameter	Description				
You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email." Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. When an alarm occurs, the NVR device activates the channel for recording. Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. When an alarm occurs, the NVR device activates the channel for recording. When an alarm occurs, the NVR device activates the channel for recording. When an alarm occurs the nee	Alarm					
Send Email Send Email Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email." Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.14.6 Schedule." Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. PTZ Activation PTZ Activation At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	Upload	 This function is for some series products only. 				
the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email." Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. When an alarm occurs, the NVR device activates the channel for recording and auto recording first. For details, see "4.1.4.6 Schedule." Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. PTZ Activation Activation Activation At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Select the check box to activate the buzzer when an alarm occurs. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		Cente."				
Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule." Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Buzzer Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	Send Email	the set mailbox to notify the user.				
Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel one to turn to the preset point X. Activation Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Buzzer Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.				
When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X. Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. Tour You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the obx and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Buzzer Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		"4.1.4.6 Schedule."				
Tripwire alarm supports to activate PTZ preset point only. You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. You need to set the time interval and mode for tour first, see "4.17.2 Tour." After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Wou need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.				
At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds. Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour." • After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Buzzer Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	, touvailon	 Tripwire alarm supports to activate PTZ preset point only. 				
Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen. • You need to set the time interval and mode for tour first, see "4.17.2 Tour." • After the tour is over, the preview interface is restored to the screen split mode before the tour. Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		PTZ Functions."				
Tour Ocal interface of the NVR device displays the selected channel screen.	Delay					
After the tour is over, the preview interface is restored to the screen split mode before the tour. Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."						
Log Select the check box, the NVR device records the alarm information in the log when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Prompts Refer to "4.18.1 File Manage" to add audio file first. Buzzer Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."				
when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."						
Voice Prompts list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	Log	· · · · · · · · · · · · · · · · · · ·				
Buzzer Select the check box to activate the buzzer when an alarm occurs. Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."		list. System plays the audio file when the alarm occurs.				
choices). When an alarm occurs, the NVR device activates the channel for recording. Channel You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."	Buzzer	· ·				
"4.1.4.6 Schedule."		choices). When an alarm occurs, the NVR device activates the channel for recording.				
		"4.1.4.6 Schedule."				

Step 5 Click Apply.

4.8.4 Alarm Control


You can set proper alarm output (Auto/manual/off). Connect the alarm device to the system alarm output port, and set the mode as auto, system can trigger the corresponding operations when an alarm occurs.

- Auto: Once an alarm event occurs, system can generate an alarm.
- Manual: Alarm device is always on the alarming mode.
- Off: Disable alarm output function.

Step 1 Select Main Menu > ALARM > ALARM OUTPUT.

The **ALARM OUTPUT** interface is displayed. See Figure 4-168.

Figure 4-168



Step 2 Select the alarm mode of the alarm output channel.

- Click OK button of the Alarm Release, you can clear all alarm output statuses.
- View the alarm output status on the Status column.

Step 3 Click Apply.

4.8.5 Video Detection

The video detection adopts the computer image and graphics process technology. It can analyze the video and check there is considerable changing or not. Once video has changed considerably (such as there is any moving object, video is distorted), system can trigger the corresponding alarm activation operations.


Select Main menu > ALARM > VIDEO DETECTION > MOTION DETECT, you can see motion detect interface. See Figure 4-171. There are five detection types: motion detection, video loss, tampering, scene changing and PIR alarm.

4.8.5.1 Motion Detect

When the moving object appears and moves fast enough to reach the preset sensitivity value, the system activates the alarm.

<u>Step 1</u> Select **Main Menu > ALARM > VIDIEO DETECTION > Motion Detect**. The **Motion Detect** interface is displayed. See Figure 4-169.

Figure 4-169



Step 2 Configure the settings for the motion detection parameters. See Table 4-45.

Table 4-45

Parameter	Description
Channel	In the Channel list, select a channel to set the motion detection.
Region	Click Setting to define the motion detection region.
Enable MD	Enable or disable the motion detection function. Check the box enable the function.
Period	Define a period during which the motion detection is active.
Sensitivity	The higher the value is, the easier it is to trigger an alarm. But at the same time, the false alarm may occur. The default value is recommended.
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Show Message	Check box to enable a pop-up message in your local host PC.

Parameter	Description							
Alarm	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).							
Upload	 This function is for some series products only. 							
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." 							
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.							
	You need to set the email first. For details, see "4.12.8 Email."							
Doord	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.							
Record Channel								
Griainie.	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."							
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.							
Activation	 Tripwire alarm supports to activate PTZ preset point only. 							
	 You need to set the corresponding PTZ actions first, see 4.4.3 Configuring PTZ Functions. 							
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.							
Tour	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.							
	 You need to set the time interval and mode for tour first, see 4.17.2 Tour. 							
	 After the tour is over, the preview interface is restored to the screen split mode before the tour. 							
Snapshot	Select the Snapshot check box to take a snapshot of the selected channel.							
	To use this function, select Main Menu > CAMERA > ENCODE > Snapshot , in the Mode list, select Event (Trigger).							
Voice	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs.							
Prompts								
Buzzer	Refer to 4.18.1 File Manage to add audio file first. Select the check box to activate the buzzer when an alarm occurs.							
	nnly to save the settings							

Step 3 Click **Apply** to save the settings.

Click **Default** to restore the default setting.

- Click **Copy**, in the **Copy** dialog box, select the additional channel(s) that you want to copy the motion detection settings to, and then click **Apply**.
- Click **Test** to test the settings.

Setting the Motion Detection Region


Step 1 Next to Region, click Setting.

The region setting screen is displayed.

Step 2 Point to the middle top of the interface.

The setting interface is displayed. See Figure 4-170.

Figure 4-170



- Step 3 Configure the regions settings. You can configure totally four regions.
 - 1) Select one region, for example, click 0.
 - 2) Drag on the screen to select the region that you want to detect.
 - 3) The selected area shows the color that represents the region.
 - 4) Configure the parameters. See Table 4-46.

Table 4-46

Parameter	Description
Name	Enter a name for the region.
Sensitivity	Every region of every channel has an individual sensitivity value. The bigger the value is, the easier the alarms can be activated.
Threshold	Adjust the threshold for motion detect. Every region of every channel has an individual threshold.



When anyone of the four regions activates motion detect alarm, the channel where this region belongs to will activate motion detect alarm.

<u>Step 4</u> Right-click on the screen to exit the region setting interface.

<u>Step 5</u> On the **Motion Detect** interface, click **Apply** to complete the settings.

Setting Period



The system only activates the alarm in the defined period.

Step 1 Next to Period, click Setting.

The **Setting** interface is displayed. See Figure 4-171.


Figure 4-171

Setting												
□ All	2	4	6	8	10	12	14	16	18	20	22	24
□ Sunday												•
□ Monday												•
Tuesday												•
□ Wednesday												*
□ Thursday												*
□ Friday												*
□ Saturday												*
Default										OK		Back

- Step 2 Define the motion detection period. By default, it is active all the time.
 - Define the period by drawing.
 - Define for a specified day of a week: On the timeline, click the half-hour blocks to select the active period.
 - Define for several days of a week: Click before each day, the icon switches to . On the timeline of any selected day, click the half-hour blocks to select the active periods, all the days with will take the same settings.
 - ◇ Define for all days of a week: Click All, all switches to select the active periods, all the days will take the same settings.
 - Define the period by editing. Take Sunday as an example.
 - 1) Click ...

The **Period** interface is displayed. See Figure 4-172.

Figure 4-172



- 2) Enter the time frame for the period, and then select the check box to enable the settings.
 - ♦ There are six periods for you to set for each day.
 - ♦ Under Copy, select All to apply the settings to all the days of a week, or select specific day(s) that you want to apply the settings to.
- Click **OK** to save the settings.

Step 3 On the **Motion Detect** interface, click **Apply** to complete the settings.

4.8.5.2 Tampering


When the camera lens is covered, or the video is displayed in a single color because of sunlight Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head1,Numbered,nu,Level 1 Head,1 st level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 231

status, the monitoring cannot be continued normally. To avoid such situations, you can configure the tampering alarm settings.

Step 1 Select Main Menu > ALARM > VIDIEO DETECTION > Tampering.

The **Tampering** interface is displayed. See Figure 4-173.

Figure 4-173



<u>Step 2</u> To configure the settings for the tampering detection parameters, see "4.8.5.1 Motion Detect."

The Tampering function does not have region and sensitivity items.

Step 3 Click **Apply** to complete the settings.


- Click **Default** to restore the default setting.
- Click **Copy**, in the **Copy** dialog box, select the additional channel(s) that you want to copy the motion detection settings to, and then click **Apply**.

4.8.5.3 Video Loss

When the video loss occurs, the system activates the alarm.

Step 1 Select Main Menu > ALARM > VIDIEO DETECTION > Video Loss. The Video Loss interface is displayed. See Figure 4-174.

Figure 4-174



<u>Step 2</u> To configure the settings for the video loss detection parameters, see "4.8.5.1 Motion Detect."

The video loss function does not have region and sensitivity items.

Step 3 Click **Apply** to complete the settings.


- \square
- Click **Default** to restore the default setting.
- Click **Copy**, in the **Copy** dialog box, select the additional channel(s) that you want to copy the motion detection settings to, and then click **Apply**.

4.8.5.4 Scene Change

When the detected scene has changed, system can generate an alarm.

<u>Step 1</u> Select **Main Menu>ALARM >VIDEO DETECTION >SCENE CHANGE**, The **Scene Change** interface is displayed. See Figure 4-175.

Figure 4-175



- <u>Step 2</u> To configure the settings for the scene change parameters, see "4.8.5.1 Motion Detect." The scene change function does not have region and sensitivity items.
- Step 3 Click **Apply** to complete the settings.
 - Click **Default** to restore the default setting.
 - Click **Copy**, in the **Copy** dialog box, select the additional channel(s) that you want to copy the motion detection settings to, and then click **Apply**.

4.8.5.5 PIR Alarm


When the detected scene has changed, system can generate an alarm.

PIR function helps enhancing the accuracy and validity of motion detect. It can filter the meaningless alarms that are activated by the objects such as falling leaves, flies. The detection range by PIR is smaller than the field angle.

PIR function is enabled by default if it is supported by the cameras. Enabling PIR function will get the motion detect to be enabled automatically to generate motion detection alarms; if the PIR function is not enabled, the motion detect just has the general effect.

Step 1 Select Main Menu > ALARM > VIDEO DETECT > PIR ALARM. The PIR Alarm interface is displayed. See Figure 4-176.

Figure 4-176



<u>Step 2</u> To configure the settings for the PIR alarm parameters, see "4.8.5.1 Motion Detect." <u>Step 3</u> Click **Apply** to complete the settings.


- Click **Default** to restore the default setting.
- Click **Copy**, in the **Copy** dialog box, select the additional channel(s) that you want to copy the motion detection settings to, and then click **Apply**.

4.8.6 Audio Detect

System can generate an alarm once it detect the audio is not clear, the tone color has changed or there is abnormal or audio volume changes.

<u>Step 1</u> Select **Main Menu > ALARM > AUDIO DETECT**.
The **AUDIO DETECT** interface is displayed. See Figure 4-177.

Figure 4-177



Step 2 Configure parameters. See Table 4-47.

Table 4-47

Parameter	Description
Channel	In the Channel list, select a channel to set.
Input abnormal	Check the box here, system can generate an alarm once the audio input is abnormal.
Intensity change	Check the box here, system can generate an alarm once the audio volume becomes strong.
Period	Define a period during which the function is active.
Sensitivity	The higher the value is, the easier it is to trigger an alarm. But at the same time, the false alarm may occur. The default value is recommended.
Threshold	You can set intensity change threshold. The smaller the value is, the higher the sensitivity is.
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Show Message	Check box to enable a pop-up message in your local host PC.

Parameter	Description							
Alarm	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).							
Upload	 This function is for some series products only. 							
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente." 							
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email."							
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.							
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."							
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.							
7 totivation	 Tripwire alarm supports to activate PTZ preset point only. 							
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." 							
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.							
	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.							
Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."							
	After the tour is over, the preview interface is restored to the screen split mode before the tour.							
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.							
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.							
Buzzer	Select the check box to activate the buzzer when an alarm occurs.							
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.							
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."							
Ctam O Cliale A	Annly to complete the settings							

Step 3 Click **Apply** to complete the settings.

4.8.7 Thermal Alarm

System supports thermal devices and receives the alarm signal from it. It can recognize the alarm type, and then trigger the corresponding alarm actions.


The system supports fire alarm, temperature (temperature difference) and cold/hot alarm.

- Fire alarm: System generates an alarm once it detects there is a fire. The alarm mode includes Preset and Excluded zone.
- Temperature (temperature difference): System triggers an alarm once the temperature difference between two positions is higher or below the specified threshold.
- Clod/hot alarm: System triggers an alarm once the detected position temperature is higher or below the specified threshold.
- The connected channel shall support temperature test function.
- This function is for some series products only. It supports enable/disable function only. Go
 to the front-end device to set corresponding parameters.

Step 1 Select Main Menu > ALARM > THERMAL ALARM.

The **THERMAL ALARM** interface is displayed. See Figure 4-178.

Figure 4-178



- <u>Step 2</u> Select a channel and alarm type, enable the thermal alarm function.
- <u>Step 3</u> Select fire mode and then enable this function (If the alarm type is **Fire Alarm**). System supports preset mode and zone excluded mode.
 - Preset: Select a preset and then enable the function. System generates an alarm once it detect there is a fire.
 - **Global**: System filters the specified high temperature zone. System generates an alarm once the rest zone has fire.

Step 4 Set parameters. See Table 4-48.

Table 4-48

Parameter	Description					
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.					
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.					
Show Message	Check box to enable a pop-up message in your local host PC.					
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center). This function is for some series products only.					
Opioda	You need to set the alarm center first. For details, see "4.12.11 Alarm Cente."					
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.					
	You need to set the email first. For details, see "4.12.8 Email."					
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.					
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."					
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.					
7 totivation	Tripwire alarm supports to activate PTZ preset point only.					
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions." 					
Delay	At the end of the alarm, the recording extends for a period of time. The time range is from 10 seconds to 300 seconds.					
_	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.					
Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."					
	 After the tour is over, the preview interface is restored to the screen split mode before the tour. 					
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.					
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Refer to "4.18.1 File Manage" to add audio file first.					

Parameter	Description
Buzzer	Select the check box to activate the buzzer when an alarm occurs.


Step 5 Click Apply.


4.8.8 Abnormality

Step 1 Select Main Menu>ALARM>ABNORMALITY.

The **Abnormality** interface is displayed. See Figure 4-179.

Figure 4-179





Step 2 Configure parameters. See Table 4-49.

Table 4-49

Parameter	Description			
Event Type	 Click the corresponding tab to set different abnormality events. HDD: Sets process method when there is a HDD event such as HDD error, no HDD, no space. See Figure 4-179. Network: Sets process method when there is a network event such as disconnection, IP conflict, MAC conflict. See Figure 4-179. Different series products support different event types. The actual product shall prevail. 			
Enable	Check the box to enable the function,			
Less than	System generates an alarm once the HDD space is less than the threshold. For HDD Space type only.			
Alarm Out	The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.			
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.			
Show Message	Check box to enable a pop-up message in your local host PC.			

Parameter	Description
Alarm Upload	Select the check box. When an alarm occurs, the NVR device uploads an alarm signal to the network (including the alarm center).
	 This function is for some series products only.
	 You need to set the alarm center first. For details, see "4.12.11 Alarm Cente."
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user.
	You need to set the email first. For details, see "4.12.8 Email."
Record Channel	Select the check box and select the needed recording channel (support multiple choices). When an alarm occurs, the NVR device activates the channel for recording.
	You need to enable intelligent recording and auto recording first. For details, see "4.1.4.6 Schedule."
PTZ Activation	Select the check box and click Setting to select the channel and PTZ action. When an alarm occurs, the NVR device associates the channel to perform the corresponding PTZ action. For example, activate the PTZ in channel one to turn to the preset point X.
	 Tripwire alarm supports to activate PTZ preset point only.
	 You need to set the corresponding PTZ actions first, see "4.4.3 Configuring PTZ Functions."
	Select the check box and select the channel for tour. When an alarm occurs, the local interface of the NVR device displays the selected channel screen.
Tour	You need to set the time interval and mode for tour first, see "4.17.2 Tour."
	 After the tour is over, the preview interface is restored to the screen split mode before the tour.
Snapshot	Select the Snapshot check box to take a snapshot of the selected channel. To use this function, select Main Menu > CAMERA > ENCODE > Snapshot , in the Mode list, select Event (Trigger).
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Pefer to "4.18.1 File Manage" to add audio file first
Buzzer	Refer to "4.18.1 File Manage" to add audio file first. Select the check box to activate the buzzer when an alarm occurs.
Step 3 Click A	

Step 3 Click Apply.

4.9 POS

You can connect the Device to the POS (Point of Sale) machine and receive the information from it. This function applies to the scenarios such as supermarket POS machine. After connection is established, the Device can access the POS information and display the overlaid text in the channel window.



Playing POS information in the local playback and viewing the POS information in the live view screen support single-channel mode and four-channel mode. Displaying monitoring screen and playing back in the web support multi-channel mode.


4.9.1 Search



The system supports fuzzy search.

Step 1 Select Main Menu > POS > POS SEARCH.
The POS SEARCH interface is displayed. See Figure 4-181.

Figure 4-181




- <u>Step 2</u> In the **POS SEARCH** box, enter the information such as transaction number on your receipt, amount, or product name.
- <u>Step 4</u> In the **Start Time** box and **End Time** box, enter the time period that you want to search the POS transaction information.
- Step 5 Click Search.

The searched transaction results display in the table.

4.9.2 Settings

Step 1 Select Main Menu > POS > POS SETUP.

The **POS SETUP** interface is displayed. See Figure 4-182.



<u>Step 2</u> Configure the settings for the POS parameters. See Table 4-50. Table 4-50

Parameter	Description
POS Name	In the POS Name list, select the POS machine that you want to configures settings for. Click to modify the POS name. The POS name shall be unique. The POS name supports 21 Chinese characters or 63 English characters.
Enable	Enable the POS function.
Record CH	Click to select a channel to record.
Privacy Setup	Enter the privacy contents. Refer to "4.9.2.1 Privacy Setup".
Protocol Type	Select POS by default. Different machine corresponds to different protocol.
Connect Type	In the Connect Type list, select the connection protocol type. Click, the IP Address interface is displayed. In the Source IP box, enter the IP address (the machine that is connected to the Device) that sends messages.
Convert	Select a character encoding mode.

Parameter	Description
Overlay	 In the Overlay list, Select Turn or ROLL. Turn: Once the information is at 16 lines, system displays the next page. ROLL: Once the information is at 16 lines, system rolls one line after another to delete the first line. When the local preview mode is in 4-split, the turn/ROLL function is based on 8 lines.
Network time out	When the network is not working correctly and cannot be recovered after the entered timeout limit, the POS information will not display normally. After the network is recovered, the latest POS information will be displayed.
Time Display	Enter the time that how long you want to keep the POS information displaying. For example, enter 5, the POS information disappear from the screen after 5 seconds.
Font Size	In the Font Size list, select Small , Medium , or Big as the text size of POS information
COLOR	In the color bar, click to select the color for the text size of POS information.
POS Info	Enable the POS Info function, the POS information displays in the live view/WEB.
Line Delimiter	There is no line delimiter by default. After set the line delimiter (HEX), the overlay information after the delimiter is displayed in the new line. For example, the line delimiter is F and the overlay information is 123156789, NVR displays overlay information on the local preview interface and Web as: 123 6789

Description

Step 3 Click **Apply** to complete the settings.


4.9.2.1 Privacy Setup

Parameter

Step 1 Click Setup

The **Privacy** interface is displayed. See Figure 4-183.





Step 2 Set privacy information. Step 3 Click **OK** button.

4.9.2.2 Connection type


Connection type is UDP or TCP.

Step 1 Select Connect Type as UDP, TCP_CLINET or TCP.

Step 2 Click

The **IP Address** interface is displayed. See Figure 4-184.

Figure 4-184



Step 3 Source IP and Port. Refers to POS IP address and port.

Step 4 Click **OK** to complete setup.

4.10 Operation and Maintenance


4.10.1 Log

You can view and search the log information, or backup log to the USB device.

Step 1 Select Main Menu > OPERATION > LOG.

The **LOG** interface is displayed. See Figure 4-185.

Figure 4-185




<u>Step 5</u> In the **Type** list, select the log type that you want to view (**System**, **Config**, **Storage**, **Record**, **Account**, **Clear**, **Playback**, and **Connection**) or select **All** to view all logs.

<u>Step 6</u> In the **Start Time** box and **End Time** box, enter the time period to search, and then click **Search**.

The search results are displayed. See Figure 4-186.

Figure 4-186





- Click **Details** or double-click the log that you want to view, the **Detailed Information** interface is displayed. Click **Next** or **Previous** to view more log information.
- Click Backup to back up the logs into the USB storage device.
- Click Clear to remove all logs.

4.10.2 System

4.10.2.1 Version

Select Main Menu > SYSTEM > VERSION, you can go to VERSION interface.

You can view NVR version information. Slight different may be found on the user interface.

4.10.2.2 HDD Info

You can view the HDD quantity, HDD type, total space, free space, status, and S.M.A.R.T information.

Select **Main Menu > OPERATION > INFOMATION > HDD**, the **HDD** interface is displayed. See Figure 4-187. Refer to Table 4-51 for detailed information.

Figure 4-187




Table 4-51


Parameter	Description
No.	Indicates the number of the currently connected HDD. The asterisk (*) means the current working HDD.
Device Name	Indicates name of HDD.
Physical Position	Indicates installation position of HDD.
Type	Indicates HDD type.
Total Space	Indicates the total capacity of HDD.
Free Space	Indicates the usable capacity of HDD.
Status	Indicates the status of the HDD to show if it is working normally.
S.M.A.R.T	View the S.M.A.R.T reports from HDD detecting.

4.10.2.3 BPS

Here is for you to view current video bit rate (kb/s) and resolution.

Select **Main Menu > OPERATION > INFOMATION > BPS**, the **BPS** interface is displayed. See Figure 4-188.

Figure 4-188



4.10.2.4 Device Status

You can view fan running status such as speed, CPU temperature, and memory.

Select **Main Menu > OPERATION > INFOMATION > Status**, the **Status** interface is displayed. See Figure 4-189.

Fan Speed Self-ada...
CPU CPU Temper... Memory

Normal 50 °C

6% 59%


Figure 4-189

4.10.2.5 HDD Health Detection

You can view HDD health status. System supports Seagate SKYHAWK series 4T and higher HDD. It displays HDD name, space, manufacturer, Serial No., and health status.

Step 1 Select Main Menu > OPERATION > INFOMATION > HDD Health Detection.
The HDD Health Detection interface is displayed. See Figure 4-190.

Figure 4-190



Step 2 Double-click the HDD in the list, system displays the detection report.

<u>Step 3</u> Select an item in the list, system displays the corresponding report. System displays the curve report of the recent week by default.

4.10.3 Network

4.10.3.1 Online User

You can view the online user information or block any user for a period of time. To block an online user, click and then enter the time that you want to block this user. The maximum value you can set is 65535.

The system detects every 5 seconds to check whether there is any user added or deleted, and update the user list timely.

Select Main Menu > OPERATION > NETWORK > ONLINE USERS, the Online Users interface is displayed. See Figure 4-191.

Username IP User Login Time Block
admin 10.33.12.132 2019-06-03 13:57:55

Figure 4-191

4.10.3.2 Network Load

Network load means the data flow which measures the transmission capability. You can view the information such as data receiving speed and sending speed.

Step 1 Select **Main Menu > INFO > NETWORK > LOAD.**The **LOAD** interface is displayed. See Figure 4-192.

Step 2 Click the LAN name that you want to view, for example, **LAN1**.

The system displays the information of data sending speed and receiving speed.

- System displays LAN1 load by default.
- Only one LAN load can be displayed at one time.

4.10.3.3 Network Test

You can test the network connection status between the Device and other devices.

Step 1 Select Main Menu > INFO > NETWORK > TEST.

The **TEST** interface is displayed. See Figure 4-193.

Network Test

Destination IP

Test Result

Network Sniffer Packet Backup

Device Name

Address

Name

IP

Sniffer Packet Size

Niffer Packet Backup

LAN1

172.12.70.67

OKB

OKB

Step 2 In the **Destination IP** box, enter the IP address.

Step 3 Click Test.

After testing is completed, the test result is displayed. You can check the evaluation for average delay, packet loss, and network status.

4.10.4 Maintenance and Management

4.10.4.1 Device Maintenance

When the Device has been running for a long time, you can configure the auto reboot when the Device is not working. You can also configure the case fan mode to reduce noise and extend the service life.

Step 1 Select Main Menu > OPERATION > SYSTEM MAINTAIN > AUTO MAINTAIN. The AUTO MAINTAIN interface is displayed. See Figure 4-194.




Figure 4-194

<u>Step 2</u> Configure the settings for the system maintenance parameters. See Table 4-52. Table 4-52

Parameter	Description
Auto Reboot	In the Auto Reboot list, select the reboot time.
Case Fan Mode	In the Case Fan Mode list, you can select Always run or Auto. If you select Auto, the case fan will stop or start according to the external conditions such as the Device temperature.
	This function is for some series products only., and it is only supported on the local configuration interface.

Step 3 Click **Apply** to complete the settings.

4.10.4.2 IMP/EXP

You can export or import the Device system settings if there are several Devices that require the same setup.




- The **IMP/EXP** interface cannot be opened if the backup operation is ongoing on the other interfaces.
- When you open the IMP/EXP interface, the system refreshes the devices and sets the current directory as the first root directory.
- Click Format to format the USB storage device.

Exporting System Settings

<u>Step 1</u> Select **Main Menu > OPERATION > SYSTEM MAITAIN > IMP/EXP**. The **IMP/EXP** interface is displayed. See Figure 4-195.

Figure 4-195



<u>Step 2</u> Insert a USB storage device into one of the USB ports on the Device.

Step 3 Click **Refresh** to refresh the interface.

The connected USB storage device is displayed. See Figure 4-196.

IMP/EXP UPGRADE sda1(USB USB) Refresh Format 14.83 GB Free Space 1.37 GB Name Size Туре Delete ■ IVSS New Folder Import Export

Figure 4-196

Step 4 Click Export.

There is a folder under the name style of "Config_[YYYYMMDDhhmmss]". Double-click this folder to view the backup files.

4.10.4.3 Default



This function is for admin account only.

You can select the settings that you want to restore to the factory default.

Step 1 Select Main Menu > OPERATION > SYSTEM MAITAIN > DEFAULT. The DEFAULT interface is displayed. See Figure 4-197.




Figure 4-197

Step 2 Restore the settings.

- Select the settings that you want to restore, and then click Apply. The system starts restoring the selected settings.
- Click **Factory Default**, and then click **OK**. The system starts restoring the whole settings.
- 4.10.4.4 System Update
- 4.10.4.4.1 Upgrading File
 - Step 1 Insert a USB storage device containing the upgrade files into the USB port of the Device.
 - <u>Step 2</u> Select **Main Menu > OPERATION > SYSTEM MAINTAIN > UPGRADE**. The **UPGRADE** interface is displayed. See Figure 4-198.

File Upgrade

If you need to upgrade system now,please insert USB, then press the start button to start upgrade.Don't shut down the power during upgrade!

System Upgrade

Online Upgrade

Auto-check for updates

System Version 4.000.0000000.0 Build Date 2019-05-28 Manual Check


It is the latest version

Figure 4-198

Step 3 Click System Upgrade.

The **System Upgrade** interface is displayed. See Figure 4-199.

Figure 4-199



<u>Step 4</u> Click the file that you want to upgrade.

The selected file is displayed in the **Update File** box.

Step 5 Click Start.

4.10.4.4.2 Online Upgrade

When the Device is connected to Internet, you can use online upgrade function to upgrade the system.


Before using this function, you need to check whether there is any new version by auto check or manual check.

- Auto check: The Device checks if there is any new version available at intervals.
- Manual check: Perform real-time check whether there is any new version available.



Ensure the correct power supply and network connection during upgrading; otherwise the upgrading might be failed.

Step 1 Select Main Menu >> OPERATION > SYSTEM MAINTAIN > UPGRADE.
The UPGRADE interface is displayed. See Figure 4-200.
Figure 4-200



Step 2 Check whether there is any new version available.

- Auto-check for updates: Enable Auto-check for updates.
- Manual check: Click Manual Check.

The system starts checking the new versions. After checking is completed, the check result is displayed.

- If the "It is the latest version" text is displayed, you do not need to upgrade.
- If the text indicating there is a new version, go to the step 3. .

Step 3 Click **Upgrade now** to update the system.

4.10.4.4.3 Uboot Upgrading



- Under the root directory in the USB storage device, there must be "u-boot.bin.img" file and "update.img" file saved, and the USB storage device must be in FAT32 format.
- Make sure the USB storage device is inserted; otherwise the upgrading cannot be performed.


When starting the Device, the system automatically check whether there is a USB storage device connected and if there is any upgrade file, and if yes and the check result of the upgrade file is correct, the system will upgrade automatically. The Uboot upgrade can avoid the situation that you have to upgrade through +TFTP when the Device is halted.

4.11 File Backup

You can back up the record file to the UBS device.

Step 1 Connect USB burner, USB device or portable HDD to the device.

<u>Step 2</u> Select **Main menu > BACKUP**, the **Backup** interface is displayed. See Figure 4-201. Figure 4-201



- Step 3 Select backup device and then set channel, file start time and end time.
- <u>Step 4</u> Click **Search** button, system begins search. All matched files are listed below. System automatically calculates the capacity needed and remained.
- Step 5 System only backup files with a $\sqrt{}$ before channel name. You can use Fn or cancel button to delete $\sqrt{}$ after file serial number.
- <u>Step 6</u> Click backup button, you can backup selected files. There is a process bar for you reference.
- <u>Step 7</u> When the system completes backup, you can see a dialogue box prompting successful backup.
- Step 8 Click **Backup** button, system begins burning. At the same time, the **Backup** button becomes **Stop** button. You can view the remaining time and process bar at the left bottom.
 - During backup process, you can click ESC to exit current interface for other operation (For some series product only). The system will not terminate backup process. (This function is for some series products only.)
 - System pops up corresponding dialogue box if there is no backup device, or no backup file, or error occurs during backup process.
 - The file name format usually is: Channel number+Record type+Time. In the file name, the YDM format is Y+M+D+H+M+S. File extension name is .dav.
 - Click Onekey Backup to back up all required files.

4.12 Network

You can set NVR network parameters so that the NVR can communicate with devices in the same LAN.

4.12.1 TCP/IP

Select **Main Menu > NETWORK > TCP/IP**, the **TCP/IP** interface is displayed. See Figure 4-202.

Figure 4-202




Table 4-53

Parameter	Description
Net Mode	 Multi-address: Two Ethernet ports work separately through either of which you can request the Device to provide the services such as HTTP and RTSP. You need to configure a default Ethernet port (usually the Ethernet port 1 by default) to request the services from the device end such as DHCP, Email and FTP. If one of the two Ethernet ports is disconnected as detected by networking testing, the system network status is regarded as offline. Fault Tolerance: Two Ethernet ports share one IP address. Normally only one Ethernet port is working and when this port fails, the other port will start working automatically to ensure the network connection. When testing the network status, the network is regarded as offline only when both of the two Ethernet ports are disconnected. The two Ethernet ports are used under the same LAN. Load Balance: Two network cards share one IP address and they are working at the same time to share the network load averagely. If one of them fails, the other can continue working normally. When testing the network status, the network is regarded as offline only when both of the two Ethernet ports are disconnected. The two Ethernet ports are used under the same LAN.
Default Ethernet Port	In the Ethernet Card list, select an Ethernet port as a default port. This setting is available only when the Multi-address is selected in the Net Mode list.
IP Version	In the IP Version list, you can select IPv4 or IPv6 . Both versions are supported for access.
MAC Address	Displays the MAC address of the Device.
DHCP	 Enable the DHCP function. The IP address, subnet mask and default gateway are not available for configuration once DHCP is enabled. If DHCP is effective, the obtained information will display in the IP Address box, Subnet Mask box and Default Gateway box. If not, all values show 0.0.0.0. If you want manually configure the IP information, disable the DHCP function first.


Parameter	Description
	If PPPoE connection is successful, the IP address, subnet mask, default gateway, and DHCP are not available for configuration.
IP Address	Enter the IP address and configure the corresponding subnet mask and
Subnet Mask	default gateway.
Default Gateway	IP address and default gateway must be in the same network segment.
DNS DHCP	Enable the DHCP function to get the DNS address from router.
Preferred DNS	In the Preferred DNS box, enter the IP address of DNS.
Alternate DNS	In the Alternate DNS box, enter the IP address of alternate DNS.
MTU	 In the MTU box, enter a value for network card. The value ranges from 1280 byte through 1500 byte. The default is 1500. The suggested MTU values are as below. 1500: The biggest value of Ethernet information package. This value is typically selected if there is no PPPoE or VPN connection, and it is also the default value of some routers, network adapters and switches. 1492: Optimized value for PPPoE. 1468: Optimized value for DHCP. 1450: Optimized value for VPN.
Test	Click Test to test if the entered IP address and gateway are interworking.

4.12.2 Port

You can configure the maximum connection accessing the Device from Client such as WEB, Platform, and Mobile Phone and configure each port settings.

Step 1 Select Main Menu > NETWORK > PORT.

The **PORT** interface is displayed. See Figure 4-203.



<u>Step 2</u> Configure the settings for the connection parameters. See Table 4-54.

The connection parameters except Max Connection cannot take effects until the Device has been restarted.

Table 4-54

Parameter	Description
Max Connection	The allowable maximum clients accessing the Device at the same time, such as WEB, Platform, and Mobile Phone.
	Select a value between 1 and 128. The default value setting is 128.
TCP Port	The default value setting is 37777. You can enter the value
101 1011	according to your actual situation.
UDP Port	The default value setting is 37778. You can enter the value
OBI TOIL	according to your actual situation.
	The default value setting is 80. You can enter the value according
HTTP Port	to your actual situation.
HITEFOIL	If you enter other value, for example, 70, and then you should enter
	70 after the IP address when logging in the Device by browser.
RTSP Port	The default value setting is 554. You can enter the value according
KISP POIL	to your actual situation.
POS Port	Data transmission. The value range is from 1 through 65535. The
POS POIL	default value is 38800.
HTTPS Enable	Enable HTTPS.
HTTPS Port	HTTPS communication port. The default value setting is 443. You
HITTS FOIL	can enter the value according to your actual situation.

Step 3 Click **Apply** to complete the settings.

4.12.3 Wi-Fi AP

You can configure Wi-Fi parameters for the NVR to ensure that a wireless IPC can connect to the NVR through Wi-Fi AP.

Prerequesites

This function requires the built-in Wi-Fi module in the device, and actual product shall prevail.

4.12.3.1 General Settings

You can configure SSID, encryption type, password and channel of the device.


 \prod

- This function is supported on select wireless models.
- When the wireless IPC and NVR are matched, the pairing will be completed in 120 seconds after they are powered-on.

Step3 Select Main Menu > NETWORK > Wi-Fi AP > General.

The **General** interface is displayed. See Figure 4-204.

Figure 4-204



Step4 Select Wi-Fi to enable Wi-Fi.

Step5 Configure parameters. For details, see Table 4-55.

Table 4-55

Parameter	Description
SSID	Wi-Fi name for the device.
Hide SSID	You can hide the Wi-Fi name when select this option.
Encryption Type	Select an encryption mode. The device provides WPA2 PSK and WPA PSK.
Password	Set the Wi-Fi password for the device.
Select Channel	Select the channel for device communication.
Network Proxy	Enables the external network access through the deivce for a wireless IPC.

4.12.3.2 Advanced Settings

This function is supported on select wireless models.

You can configure IP address, subnet mask, default gateway, DHCP server of the device.

Step1 Select Main Menu > NETWORK > Wi-Fi AP > Advanced.

The **Advanced** interface is displayed. See Figure 4-205.

Figure 4-205

General Advanced

IP Config

IP Address
Subnet Mask
Default Gateway
DHCP Server
Start IP
End IP
Preferred DNS
Alternate DNS

<u>Step2</u> Configure parameters. For details, see Table 4-56.

Table 4-56

Default

Description	
Set IP address, subnet mask and default gateway for the Wi-Fi	
parameters of NVR.	
IP address and default gateway must be in the same network segment.	
Cat the start ID address and and ID address of the DLICD server	
Set the start IP address and end IP address of the DHCP server.	
Cat professed/alternate DNC conver of the DLICD conver	
Set preferred/alternate DNS server of the DHCP server.	

Cancel

Apply

Step3 Click **Apply** to complete the configuration.

4.12.4 Repeater

The device supports relay settings for the wireless relay IPC to extend video transmission distance and range.



This function is supported on select models.

Prerequisites


- The device has the built-in Wi-Fi module.
- The IPC has wireless relay module.

Procedure

- Step 1 Power on the NVR and wireless replayIPC, and connect all IPCs to the NVR through Wi-Fi.
- <u>Step 2</u> Select **Main Menu > NETWORK > REPEATER**. The **REPEATER** interface is displayed. See Figure 4-206.



- Green connection line represents the successful connection between channel and wireless IPC.
- Auto cascade: After selecting auto cascade, the IPC can cascade to NVR automatically.




Step 3 Select Mannual Cascade.

The Manual Cascade interface is displayed. See Figure 4-207.



Mannual cascade: You can use manual cascade when there are 2 IPCs in the network at least.


Figure 4-207



Step 4 Click and select the channel to be added.

The following interface is displayed after successful adding. See Figure 4-208.

Figure 4-208



Step 5 Click **Apply** to complete the configuration.


4.12.5 PPPoE

PPPoE is another way for the Device to access the network. You can establish network connection by configuring PPPoE settings to give the Device a dynamic IP address in the WAN. To use this function, firstly you need to obtain the user name and password from the Internet Service Provider.

Step 1 Select Main Menu > NETWORK > PPPoE.

The **PPPoE** interface is displayed. See Figure 4-209.

Figure 4-209



Step 2 Enable the PPPoE function.

Step 3 In the **User Name** box and **Password** box, enter the user name and password accordingly provided by the Internet Service Provider.

Step 4 Click **Apply** to complete the settings.

The system pops up a message to indicate the successfully saved. The IP address appears on the PPPoE interface. You can use this IP address to access the Device.

When the PPPoE function is enabled, the IP address on the **TCP/IP** interface cannot be modified.

4.12.6 DDNS

When the IP address of the Device changes frequently, the DDNS function can dynamically refresh the correspondence between the domain on DNS and the IP address, ensuring you access the Device by using the domain.

Preparations

Ensure the Device supports the DDNS Type and log in the website provided by the DDNS service provider to register the information such as domain from PC located in the WAN.




After you have registered and logged in the DDNS website successfully, you can view the information of all the connected devices under this user name.

Step 1 Select Main Menu > NETWORK > DDNS.

The **DDNS** interface is displayed. See Figure 4-210.

Figure 4-210



Step 2 Configure the settings for the DDNS parameters. See Table 4-57. Table 4-57

Parameter	Description
Enable	Enable the DDNS function.
Litable	After enabling DDNS function, the third-party might collect your Device information.
DDNS Type	Type and address of DDNS service provider.
Host IP	 Type: Dyndns DDNS; address: members.dyndns.org Type: NO-IP DDNS; address: dynupdate.no-ip.com Type: CN99 DDNS; address: members.3322.org
Domain Name	The domain name for registering on the website of DDNS service provider.
User Name	Enter the user name and password obtained from DDNS service
Password	provider. You need to register (including user name and password) on the website of DDNS service provider.
Interval	Enter the amount of time that you want to update the DDNS.

Step 3 Click **Apply** to complete the settings.

Enter the domain name in the browser on your PC, and then press **Enter**. If the web interface of the Device is displayed, the configuration is successful. If not, the configuration is failed.

4.12.7 UPnP

You can map the relationship between the LAN and the WAN to access the Device on the LAN through the IP address on the WAN.

Preparations

Login the router to set the WAN port to enable the IP address to connect into the WAN.

Enable the UPnP function at the router.

Connect the Device with the LAN port on the router to connect into the LAN.

Select **Main Menu > NETWORK > TCP/IP**, configure the IP address into the router IP address range, or enable the DHCP function to obtain an IP address automatically.

Configuration Steps

Step 1 Select Main Menu > NETWORK > UPnP.

The **UPnP** interface is displayed. See Figure 4-211.

Figure 4-211




Figure 4-212




Table 4-58

Parameter	Description
PAT	Enable the UPnP function.
_	Indicates the status of UPnP function.
Status	Offline: Failed. Online: Output of the desired of the desire
	Online: Succeeded. Enter IP address of router on the LAN.
LAN IP	
	After mapping succeeded, the system obtains IP address
	automatically without performing any configurations. Enter IP address of router on the WAN.
WAN IP	
	After mapping succeeded, the system obtains IP address automatically without performing any configurations.
	The settings in PAT table correspond to the UPnP PAT table on the router. Service Name: Name of network server. Protocol: Type of protocol. Int. Port: Internal port that is mapped on the Device. Ext. Port: External port that is mapped on the router.
PAT Table	 To avoid the conflict, when setting the external port, try to use the ports from 1024 through 5000 and avoid popular ports from 1 through 255 and system ports from 256 through 1023.
	 When there are several devices in the LAN, properly arrange the ports mapping to avoid mapping to the same external port.
	 When establishing a mapping relationship, ensure the mapping ports are not occupied or limited.
	The internal and external ports of TCP and UDP must be the same and cannot be modified.
	Click to modify the external port.

Step 3 Click **Apply** to complete the settings.

In the browser, enter http://WAN IP: External IP port. You can visit the LAN Device.

4.12.8 Email

You can configure the email settings to enable the system to send the email as a notification when there is an alarm event occurs.

Step 1 Select Main Menu > NETWORK > EMAIL.

The **EMAIL** interface is displayed. See Figure 4-213.

Figure 4-213

Enable				
SMTP Server	MailServer			
Port	25			
Username				
Password				
Anonymous				
Receiver	Receiver1 v			
Email Address	none			
Sender				
Subject	NVR ALERT			
Attachment				
Encryption Type	TLS			
Health Enable				
Interval	60	Min.		
Test			Apply	Back

Step 2 Configure the settings for the email parameters. See Table 4-59. Table 4-59

Parameter	Description	
Enable	Enable the email function.	
SMTP Server	Enter the address of SMTP server of sender's email account.	
Port	Enter the port value of SMTP server. The default value setting is 25. You can enter the value according to your actual situation.	
User Name	Enter the user name and password of sender's email account.	
Password		
Anonymity	If enable the anonymity function, you can login as anonymity.	
Mail Receiver	In the Mail Receiver list, select the number of receiver that you want to receive the notification. The Device supports up to three mail receivers.	
Email Address	Enter the email address of mail receiver(s).	
Sender	Enter the sender's email address. It supports maximum three senders separated by comma.	
Title	Enter the email subject. Supports Chinese, English and Arabic numerals. It supports maximum 64 characters.	
Attachment	Enable the attachment function. When there is an alarm event, the system can attach snapshots as an attachment to the email.	

Parameter	Description	
Authentication	Select the encryption type: NONE , SSL , or TLS .	
	For SMTP server, the default encryption type is TLS .	
Interval (Sec.)	This is the interval that the system sends an email for the same type of alarm event, which means, the system does not send an email upon any alarm event. This setting helps to avoid the large amount of emails caused by frequent alarm events. The value ranges from 0 to 3600. 0 means that there is no interval.	
Health Enable	Enable the health test function. The system can send a test ema- to check the connection.	
Interval (Min.)	This is the interval that the system sends a health test email. The value ranges from 30 to 1440. 0 means that there is no interval.	
Test	Click Test to test the email sending function. If the configuration is correct, the receiver's email account will receive the email.	
	Before testing, click Apply to save the settings.	

Step 3 Click **Apply** to complete the settings.

4.12.9 SNMP



This function is for some series only.

You can connect the Device with some software such as MIB Builder and MG-SOFT MIB Browser to manage and control the Device from the software.

Preparations

- Install the software that can manage and control the SNMP, such as MIB Builder and MG-SOFT MIB Browser
- Obtain the MIB files that correspond to the current version from the technical support.

Configuration Steps

Step 1 Select Main Menu > NETWORK > SNMP.

The **SNMP** interface is displayed. See Figure 4-214.

Figure 4-214

Enable					
Version	□ V1 □ V2 □	V3 (Recommended)			
SNMP Port	161	(1 - 65535)			
Read Community					
Write Community					
Trap Address					
Trap Port	162	(1 - 65535)			
Read Only User	Public	Read/Write User	Private		
Authentication Type	MD5	Authentication Type	MD5		
Authentication Pa		Authentication Pa			
Encryption Type	CBC-DES v	Encryption Type	CBC-DES		
Encryption Password		Encryption Password			
			Apply	Back	

Step 2 Configure the settings for the SNMP parameters. See Table 4-60.

Table 4-60

Parameter	Description	
Enable	Enable the SNMP function.	
Version	Select the check box of SNMP version(s) that you are using.	
	The default version is V3. There is a risk of select V1 or V2.	
SNMP Port	Indicates the monitoring port on the agent program.	
Read Community	Indicates the read/write strings supported by the agent program.	
Write Community		
Trap Address	Indicates the destination address for the agent program to send the Trap information.	
Trap Port	Indicates the destination port for the agent program to send the Trap information.	
Read Only User	Enter the user name that is allowed to access the Device and has the "Read Only" permission.	
Read/Write User	Enter the user name that is allowed to access the Device and has the "Read and Write" permission.	
Authentication Type	Includes MD5 and SHA. The system recognizes automatically.	

Parameter	Description
Authentication	
Password	Enter the password for authentication type and encryption type.
Encryption	The password should be no less than eight characters.
Password	
Encryption Type	In the Encryption Type list, select an encryption type. The default setting is CBC-DES.

- Step 3 Compile the two MIB files by MIB Builder.
- Step 4 Run MG-SOFT MIB Browser to load in the module from compilation.
- <u>Step 5</u> On the MG-SOFT MIB Browser, enter the Device IP that you want to manage, and then select the version number to query.
- <u>Step 6</u> On the MG-SOFT MIB Browser, unfold the tree-structured directory to obtain the configurations of the Device, such as the channels quantity and software version.


4.12.10 Multicast

When you access the Device from the network to view the video, if the access is exceeded, the video will not display. You can use the multicast function to group the IP to solve the problem.

Step 1 Select Main Menu > NETWORK > MULTICAST.

The **MULTICAST** interface is displayed. See Figure 4-215.

Figure 4-215



Step 2 Configure the settings for the multicast parameters. See Table 4-61.

Table 4-61

Parameter	Description
Enable	Enable the multicast function.
IP Address	Enter the IP address that you want to use as the multicast IP. The IP address ranges from 224 0 0 0 through 239 255 255 255

Port	Enter the port for the multicast. The port ranges from 1025 through
Foit	65000.

Step 3 Click **Apply** to complete the settings.

You can use the multicast IP address to login the web.

On the web login dialog box, in the **Type** list, select **MULTICAST**. The web will automatically obtain the multicast IP address and join. Then you can view the video through multicast function.


4.12.11 Alarm Center

You can configure the alarm center server to receive the uploaded alarm information. To use this function, the **Alarm Upload** check box must be selected.

Step 1 Select Main Menu > NETWORK > ALARM CENTER.

The **ALARM CENTER** interface is displayed. See Figure 4-216.

Figure 4-216



Step 2 Configure the settings for the alarm center parameters. See Table 4-62. Table 4-62

Parameter	Description	
Enable	Enable the alarm center function.	
Protocol Type	In the Protocol Type list, select protocol type. The default is ALARM CENTER .	
Host IP	The IP address and communication port of the PC installed with	
Port	alarm client.	
Self-Report Time	In the Self-Report Time list, select time cycle and specific time for uploading alarm.	


Step 3 Click **Apply** to complete the settings.

4.12.12 Register

You can register the Device into the specified proxy server which acts as the transit to make it easier for the client software to access the Device.

Step 1 Select Main Menu > NETWORK > REGISTER.

The **REGISTER** interface is displayed. See Figure 4-217.



Step 2 Configure the settings for the register parameters. See Table 4-63. Table 4-63

Function	Description
Enable	Enable the register function.
Server IP Address	Enter the server IP address or the server domain that you want to register to.
Port	Enter the port of the server.
Sub Service ID	This ID is allocated by the server and used for the Device.

Step 3 Click **Apply** to complete the settings.

4.12.13 P2P

P2P is a kind of convenient private network penetration technology. You do not need to apply for dynamic domain name, doing port mapping or deploying transit server. You can add NVR devices through the below way to achieve the purpose of managing multiple NVR devices at the same time.

- Scan the QR code, download mobile app, and then register an account. For details, see Mobile App Operation.
- Log in www.gotop2p.com, register an account, and then add device via the serial number. For details, see Introduction of P2P Operations.




Connect the NVR device to the Internet, otherwise P2P can not run properly.

Step 1 Select Main Menu > NETWORK > P2P.

The **P2P** interface is displayed. See Figure 4-218.

Figure 4-218



Step 2 Enable the P2P function.



After the P2P function is enabled and connected to the Internet, the system will collects your information for remote access, and the information includes but not limited to email address, MAC address, and device serial number.

You can start adding the device.

- Cell Phone Client: Use your mobile phone to scan the QR code to add the device into the Cell Phone Client, and then you can start accessing the Device.
- Platform: Obtain the Device SN by scanning the QR code. Go to the P2P
 management platform and add the Device SN into the platform. Then you can
 access and manage the device in the WAN. For details, refer to the P2P operation
 manual.



You can also enter the QR code of Cell Phone Client and Device SN by clicking on the top right of the interfaces after you have entered the Main Menu.




To use this function, take adding device into Cell Phone Client as an example.

Mobile APP Operation

The following contents are introduced in the example of mobile App.

- Step 1 Scan the QR code to download and install the mobile App.
- Step 2 Select Camera and enter the main interface.
- Step 3 Register device in the mobile App:
 - 1) Click and select Device Manager. See Figure 4-219.

Figure 4-219



- 2) Click and enter the Add Device interface.
 - Mobile App supports device initialization.
- 3) Select **Wired Device > P2P** to enter the P2P interface.
- 4) Click the QR code icon behind the SN to enter the QR code scan interface.
- 5) Scan the device label or scan the SN QR code got by selecting **Main Menu > Network > P2P**. When the scan is successful, the device SN will be displayed in the SN item.
- 6) Enter name and password.
- <u>Step 4</u> After device registration on mobile App, click Start Preview and you can see the monitor screen.

4.13 Storage

You can manage the storage resources (such as record file) and storage space. So that it is easy for you to use and enhance storage space usage.


4.13.1 Basic

You can set basic storage parameters.

Step 1 Select Main Menu > STORAGE > BASIC.

The **Basic** interface is displayed. See Figure 4-220.

Figure 4-220



Step 2 Set parameters. See Table 4-64.

Table 4-64

Parameter	Description	
HDD Full	Configure the settings for the situation all the read/write discs are full, and there is no more free disc. • Select Stop Record to stop recording • Select Overwrite to overwrite the recorded video files always from the earliest time.	
Pack Mode	Configure the time length and file length for each recorded video.	
Auto-Delete Old Files	Configure whether to delete the old files and if yes, configure the days. The auto delete file cannot be recovered!	

Step 3 Click Apply or Save to complete setup.

4.13.2 Schedule

You can set schedule record and schedule snapshot. NVR can record or snapshot as you specified. For detailed information, refer to "4.1.4.6.1 Schedule Record" and "4.1.4.6.2 Schedule Snapshot".

4.13.3 HDD

You can view and sett HDD properties and format HDD.


You can view current HDD type, status, capacity and etc. The operation includes format HDD, and change HDD property (read and write/read-only/redundancy).

- To prevent files be overwritten in the future, you can set HDD as read-only.
- To backup recorded video file, you can set HDD as redundant HDD.

Step 1 Select Main Menu > Storage > HDD MANAGER,

The HDD MANAGER interface is displayed. See Figure 4-221.

Figure 4-221



Step 2 Select a HDD and then select a time from the dropdown list.

<u>Step 3</u> Click **Apply** button to complete the setup. System needs to restart to activate current setup if you want to format the HDD.

4.13.4 Record Control

After you set schedule record or schedule snapshot function, set auto record/snapshot function so that the NVR can automatically record or snapshot. For detailed information, refer to "4.1.4.6.3 Record Control".

4.13.5 Advance (HDD Group)

You can set HDD group, and HDD group setup for main stream, sub stream and snapshot operation.



When you are setting HDD group, set a HDD for each channel, otherwise NVR cannot save current setup.

Step 1 Select Main Menu > STORAGE > ADVANCED.

The **ADVANCED** interface is displayed. See Figure 4-222.




Figure 4-222

Step 2 Select the group for each HDD group, and then click **Save** to save the settings.

After configuring HDD group, under the **Main Stream** tab, **Sub Stream** tab and **Snapshot** tab, configure settings to save the main stream, sub stream and snapshot to different HDD group as selected by you.

Back

Apply

4.13.6 HDD Detect



This function is for some series product only.

The HDD detect function is to detect HDD current status so that you can clearly understand the HDD performance and replace the malfunction HDD.

There are two detect types:

- Quick detect is to detect via the universal system files. System can quickly complete the HDD scan. If you want to use this function, make sure the HDD is in use now. If the HDD is removed from other device, make sure the HDD once storage the record files when installed on current device.
- Global detect adopts Windows mode to scan. It may take a long time and may affect the HDD that is recording.

4.13.6.1 Manual Detect

Step 1 Select Main Menu > STORAGE > HDD DETECT > Manual Detect.

The Manual Detect interface is displayed. See Figure 4-223.




Figure 4-223

<u>Step 2</u> In the **Type** list, select **Key Area Detect** or **Global Detect**; and in the **HDD** list, select the HDD that you want to detect.

Step 3 Click Start Detect.

When system is detecting HDD, click **Stop Detect** to stop current detection. Click **Start Detect** to detect again.


4.13.6.2 Detect Report

After the detect operation, you can go to the detect report to view corresponding information. Replace the malfunction HDD in case there is data loss.

Step 1 Select Main Menu > STORAGE > HDD DETECT > Detect Report.

The **Detect Report** interface is displayed. See Figure 4-224.

Figure 4-224



The **Details** interface is displayed. You can view detecting results and S.M.A.R.T reports. See Figure 4-225 and Figure 4-226.

Figure 4-225




Figure 4-226



4.13.7 RAID

RAID (redundant array of independent disks) is a data storage virtualization technology that combines multiple physical HDD components into a single logical unit for the purposes of data redundancy, performance improvement, or both.



- RAID function is for some series products only. Slight difference may be found on the user interface.
- The NVR supports RAID0, RAID1, RAID5, RAID6, and RAID 10. Local hot spare supports RAID1, RAID5, RAID6, and RAID10.

For the disk quantity required for each RAID type. See Table 4-65.

Table 4-65

RAID type	Required disk quantity	
RAID0	At least 2.	
RAID1	Only 2.	
RAID5	At least 3, and using 4 disks to 6 disks is recommended.	
RAID6	At least 4.	
RAID10	At least 4.	

4.13.7.1 Creating Manager

RAID has different levels (such as RAID5, RAID6). Each level has different data protection, data availability, and performance grade.

You can manually create RAID or just one click one button to create RAID. For create RAID function, you can select the physical HDD that does not included in the RAID group or the created disk array to create a RAID5. You can refer to the following situations:

- There is no RAID, no hotspare disk: System directly creates the RAID5 and creates one hotspare disk at the same time.
- There is no RAID, but there is a hotspare disk: System creates the RAID5 only. It uses
 previous hotspare disk.
- There is RAID: System cancel the previous RAID setup and then create the new RAID5.
 System creates the hotspare disk if there is no one. System uses previous hotspare disk if there is hotspare disk available.


• The background will format the virtual disk.

You can create different types of RAID as needed.

Step 1 Select Main Menu > STORAGE > RAID > RAID.

The RAID interface is displayed. See Figure 4-227.

Figure 4-227



<u>Step 2</u> You can click **Create RAID** or **Create Manually**, and all the disks involved will be formatted.

- Click Create RAID, the system will create RAID automatically.
- ♦ If there is no existing RAID and no hot spare disk, the system will create RAID5 and a hot spare disk automatically.
- If there is no existing RAID, but existing hot spare disk, the system will only create RAID5 and use the existing hot spare disk automatically.
- If there is existing RAID and existing hot spare disk, the system will delete the original RAID and create RAID5 with all the disks and use the existing hot spare disk automatically.
- Click Create Manually.
- 1) Select RAID type and disks as system instructed.
- 2) Click Create Manually, and then the format disk notice is displayed.
- 3) Click OK.

Step 3 After creating RAID, the disks need to sync with each other to finish the process. For RAID5 and RAID6, you can select different working mode.

- Self-Adaptive: Automatically adjust the RAID sync speed according to the business status.
 - ♦ When there is no business running, sync is performed at a high speed.
 - ♦ When there is business running, sync is performed at a low speed.
- Sync First: Resource priority is assigned to RAID sync.
- Business First: Resource priority is assigned to business operations.
- Balance: Resource is evenly distributed to RAID sync and business operations.


4.13.7.2 Raid Info

You can view the existing RAID information, including type, disk space, hot spare, and status.

Select Main Menu > STORAGE > RAID > RAID Info.

The RAID Info interface is displayed. See Figure 4-228.

Figure 4-228




4.13.7.3 Hot Spare Disk

You can add a hot spare disk to a specific disk in the RAID or to the entire RAID, and the hot spare disk is switched into operation if any disk fails.

Step 1 Select Main Menu > STORAGE > RAID > Hotspare Disk.
The Hotspare Disk interface is displayed. See Figure 4-229.

Figure 4-229



Step 2 Click the icon behind a disk.

<u>Step 3</u> The **New Hotspare** interface is displayed. See Figure 4-230 (New hot spare (local) or Figure 4-231 (New hot spare (global).

Figure 4-230





Figure 4-231

New Ho	tspare	
Type	Global Hotspare ▼	
	ОК	Cancel

Step 4 You can select **Local Hotspare** or **Global Hotspare**.

- Local Hotspare: Select the target disk, and the new disk will serve as the hot spare disk of the selected disk.
- Global Hotspare: the new disk will serve as the hot spare disk of the entire RAID.



4.13.8 Record Estimate

Record estimate function can calculate how long you can record video according to the HDD capacity, and calculate the required HDD capacity according to the record period.

Step 1 Select Main Menu > STORAGE > REC ESTIMATE.

The **REC ESTIMATE** interface is displayed. See Figure 4-232.

 Cha...
 Edit
 Bit Rate(Kb/S)
 Record Time
 Resolution
 Frame Rate

 ✓ 1
 №
 2048
 24
 1280x720(720P)
 25

 2
 №
 2048
 24
 720P
 25

 ✓ 3
 №
 2048
 24
 1920x1080(1080P)
 22
 ■

 ✓ 4
 №
 8192
 24
 1920x1080(1080P)
 25
 ■

 5
 №
 2048
 24
 720P
 25
 ■

 7
 №
 2048
 24
 720P
 25
 ■

 7
 №
 2048
 24
 720P
 25
 ■

 8
 №
 2048
 24
 720P
 25
 ■

 9
 №
 2048
 24
 720P
 25
 ■

 11
 №
 2048
 24
 720P
 25
 ■

 12
 №
 2048
 24
 720P
 25
 ■

 13
 №
 2048
 24


Figure 4-232

Step 2 Click

The **Edit** dialogue box is displayed. See Figure 4-233.

You can configure the **Resolution**, **Frame Rate**, **Bit Rate** and **Record Time** for the selected channel.

Figure 4-233



Step 3 Click Apply to save the settings.

Then the system will calculate the time period that can be used for storage according to the channels settings and HDD capacity.

Click Copy to copy the settings to other channels.

Calculating Recording Time

Step 1 On the **REC ESTIMATE** interface, click the **Known Space** tab. The **Known Space** interface is displayed. See Figure 4-234.

Figure 4-234



Step 2 Click Select.

The **Select HDD(s)** interface is displayed.

Step 3 Select the check box of the HDD that you want to calculate.

In the **Known Space** tab, in the **Time** box, the recording time is displayed. See Figure 4-235.


Figure 4-235



Calculating HDD Capacity for Storage

Step 1 On the **REC ESTIMATE** interface, click the **Known Time** tab. The **Known Time** interface is displayed. See Figure 4-236.

Figure 4-236



Step 2 In the **Time** box, enter the time period that you want to record. In the Capacity box, the required HDD capacity is displayed.

4.13.9 FTP

You can store and view the recorded videos and snapshots on the FTP server.

Preparations

Purchase or download a FTP (File Transfer Protocol) server and install it on your PC.




For the created FTP user, you need to set the write permission; otherwise the upload of recorded videos and snapshots will be failed.

Figure 4-237

Step 1 Select Main Menu > STORAGE > FTP.

The **FTP** interface is displayed. See Figure 4-237.

🔲 🔘 FTP 🧿 SFTP (Recommended) Port 22



Step 2 Configure the settings for the FTP settings parameters. See Table 4-66.

Table 4-66

Parameter	Description	
Enable	Enable the FTP upload function.	
FTP type	 Select FTP type. FTP: Plaintext transmission. SFTP: Encrypted transmission (recommended) 	
Server	IP address of FTP server.	
Port	FTP: The default is 21.SFTP: The default is 22.	
Anonymity	Enter the user name and password to login the FTP server.	
User Name	Enable the anonymity function, and then you can login	
Password	anonymously without entering the user name and password.	
Remote Directory	 Create folder on FTP server. If you do not enter the name of remote directory, system automatically creates the folders according to the IP and time. If you enter the name of remote directory, the system creates the folder with the entered name under the FTP root directory first, and then automatically creates the folders according to the IP and time. 	
File Length(M)	 Enter the length of the uploaded recorded video. If the entered length is less than the recorded video length, only a section of the recorded video can be uploaded. If the entered length is more than the recorded video length, the whole recorded video can be uploaded. If the entered length is 0, the whole recorded video will be uploaded. 	
Image Upload Interval (Sec.)	 If this interval is longer than snapshot interval, the system takes the recent snapshot to upload. For example, the interval is 5 seconds, and snapshot interval is 2 seconds per snapshot, the system uploads the recent snapshot every 5 seconds. If this interval is shorter than snapshot interval, the system uploads the snapshot per the snapshot interval. For example, the interval is 5 seconds, and snapshot interval is 10 seconds per snapshot, the system uploads the snapshot every 10 seconds. To configure the snapshot interval, select Main Menu > CAMERA > ENCODE > Snapshot. 	
Channel	Select the channel that you want to apply the FTP settings.	
Week Day	Select the week day and set the time period that you want to	
Period 1, Period 2	upload the recorded files. You can set two periods for each week day.	
Record type	Select the record type (Alarm, Intel, MD, and General) that you want to upload. The selected record type will be uploaded during the configured time period.	

Step 3 Click **Test**.

The system pops up a message to indicate success or failure. If failed, check the network connection or configurations.

Step 4 Click **Apply** to complete the settings.

4.14 System

4.14.1 General

You can set device general information. It includes device information, system date. Refer to "4.1.4.1 General" for detailed information.


4.14.2 RS232

After setting RS-232 parameters, the NVR can use the COM port to connect to other device to debug and operate.

Step 1 Select MAIN MENU > SYSTEM >RS232.

The RS232 interface is displayed. See Figure 4-238.

Figure 4-238



Step 2 Configure parameters. See Table 4-67.

Table 4-67

Parameter	Description	
Function	 Select serial port control protocol. Console: Upgrade the program and debug with the console and mini terminal software. Keyboard: Control this Device with special keyboard. Adapter: Connect with PC directly for transparent transmission of data. Protocol COM: Configure the function to protocol COM, in order to overlay card number. PTZ Matrix: Connect matrix control. Different series products support different RS232 functions. The actual product shall prevail. 	
Baud Rate	Select Baud rate, which is 115200 by default.	
Data Bits	It ranges from 5 to 8, which is 8 by default.	
Stop Bits	It includes 1 and 2.	
Parity	It includes none, odd, even, mark and null.	

Step 3 Click Apply.

4.15 Security

You can set security options to strengthen device security and use the device in a much safer way.

4.15.1 Security Status

Security scanning helps get a whole picture of device security status. You can scan user, service and security module status for detailed information about the security status of the device.

Detecting User and Service



Green icon represents a healthy status of the scanned item, and orange icon represents a risky status.

- Login authentication: When there's a risk in the device configuration, the icon will be in orange to warn risk. You can click **Details** to see the detailed risk description.
- User Status: When one of device users or Onvif users uses weak password, the icon will be
 in orange to warn risk. You can click **Details** to optimize or ignore the risk warning. See
 Figure 4-239 and Figure 4-240.






Figure 4-239 Security status

Figure 4-240 User status



 Configuration Security: When HTTPSEnable in SYSTEM SERVICE > HTTPS is disabled, the icon will be in orange to warn risk. You can click Details to optimize or ignore the risk warning. See Figure 4-241.

Figure 4-241 Configuration security



Scanning Security Modules

This area shows the security modules that are integrated in the current version.

Scanning Security Status

You can click Rescan to scan security status.

4.15.2 System Service

You can set NVR basic information such as basic services, 802.1x and HTTPS.


4.15.2.1 Basic Services

You can set NVR basic information such as basic services, 802.1x and HTTPS.

Step 1 Select Main Menu > SECURITY > SYSTEM SERVICE > Basic Services.

The Basic Services interface is displayed. See Figure 4-242.

Figure 4-242 Basic services interface



<u>Step 2</u> Select **Basic Services** and configure parameters. See Table 4-68.



There might be safety risk when **Mobile Push Notifications**, **CGI**, **ONVIF**, **SSH** and **NTP Server** is enabled.

Table 4-68 Basic service parameters

Parameter	Description
Mobile Push Notifications	After enabling this function, the alarm triggered by the NVR can be pushed to a mobile phone. This function is enabled by default.
CGI	If this function is enabled, the remote devices can be added through the CGI protocol. This function is enable by default.
ONVIF	If this function is enabled, the remote devices can be added through the ONVIF protocol. This function is enabled by default.
NTP Server	After enabling this function, a NTP server can be used to synchronize the device. This function is enabled by default.
SSH	After enabling this function, you can use SSH service. This function is disabled by default.
Private Protocol Authentication Mode	Security Mode (Recommended): Uses Digest access authentication when connecting to NVR.
	 Compatible Mode: Select this mode when the client does not support Digest access authentication.

Step 3 Click **Apply** to complete the settings.


4.15.2.2 802.1x

The device needs to pass 802.1x certification to enter the LAN.

Step 1 Select Main Menu > SECURITY > SYSTEM SERVICE > 802.1x.

The **802.1x** interface is displayed. See Figure 4-243.

Figure 4-243 802.1x interface



Step 2 Select the Ethernet card you want to certify.

Step 3 Select **Enable** and configure parameters. See Table 4-69.

Table 4-69 802.1x parameters

Parameter	Description	
	PEAP: protected EAP protocol.	
Authentication	 TLS: Transport Layer Security. Provide privacy and data integrity between two communications application programs. 	
CA Certificate	Enable it and click Browse to import CA certificate from flash drive.	
Username	The username shall be authorized at server.	
Password	Password of the corresponding username.	

Step 4 Click **Apply** to complete the settings.


4.15.2.3 HTTPS

We recommend that you enable HTTPS function to enhance system security.

<u>Step 1</u> Select Main Menu > SECURITY > SYSTEM SERVICE > HTTPS.

The **HTTPS** interface is displayed. See Figure 4-244.

Figure 4-244 HTTPS interface



- Step 2 Select **HTTPSEnable** to enable HTTPS function.
- Step 3 Click **Certificate Management** to create or import a HTTPS certificate from USB drive.
- Step 4 Select a HTTPS certificate.
- Step 5 Click **Apply** to complete the settings.


4.15.3 Attack Defense

4.15.3.1 Firewall

Step 1 Select Main Menu > SECURITY > ATTACK DEFENSE > Firewall.

The **HTTPS** interface is displayed. See Figure 4-245.

Figure 4-245 Firewall interface



Step 2 Select Enable to enable firewall.

Step 3 Configure the parameters. See Table 4-70.

Table 4-70 Firewall parameters

Parameter	Description	
Mode	 Mode can be configured when Type is Network Access. If Trusted Sites is enabled, you can visit device port successfully with IP/MAC hosts in Trusted Sites. If Blocked Sites is enabled, you cannot visit device port with IP/MAC hosts in Blocked Sites. 	
Add	When Type is Network Access, you can configure IP Address, IP Segment and MAC Address.	
Туре	You can select IP address, IP segment and MAC address.	
IP Address	Enter IP Address, Start Port and End Port that is allowed or	
Start Port	forbidden.	
End Port	When Type is IP Address, they can be configured. Start Port and End Port can be configured only in Network Access Type.	
Start Address/End Address	Enter Start Address and End Address of IP Segment. When Type is IP Segment, they can be configured.	


Parameter	Description	
MAC Address	Enter MAC Address that is allowed or forbidden When Type is MAC Address, it can be configured.	

Step 4 Click **Apply** to complete the settings.

4.15.3.2 Account Lockout

<u>Step 1</u> Select Main Menu > SECURITY > ATTACK DEFENSE > Account Lockout. The Account Lockout interface is displayed. See Figure 4-246.

Figure 4-246 Account Lockout



Step 2 Set parameters. See Table 4-71.

Table 4-71 Account lockout parameters

Parameter	Description
Attempt(s)	Set the maximum number of allowable wrong password entries. The account will be locked after your entries exceed the maximum number. Value range: 5–20. Default value: 5.
Lock Time	Set how long the account is locked for. Value range: 5–120 minutes. Default value: 30 miniutes.

Step 3 Click **Apply** to complete the settings.

4.15.3.3 Anti-Dos Attack

You can enable **SYN Flood Attack Defense** and **ICMP Flood Attack Defense** to defend the device against Dos attack. See Figure 4-247.




Figure 4-247 Anti-Dos attack interface


4.15.3.4 Sync Time-Whitelist



The synchronization is only allowed with hosts in the trusted list.

<u>Step 1</u> Select **Main Menu** > **SECURITY** > **ATTACK DEFENSE** > **Sync Time-Whitelist**. The **Sync Time-Whitelist** interface is displayed. See Figure 4-248.

Figure 4-248 Sync Time-Whitelist



- Step 2 Select **Enable** to enable **Sync Time-Whitelist** function.
- Step 3 Configure the parameters. See Table 4-72.

Table 4-72 Sync Time-Whitelist parameters

Parameter	Description
Add	You can add trusted hosts for time synchronization.
Туре	Select IP address or IP segment for hosts to be added.
IP Address	Input the IP address of a trusted host. When Type is IP Address, it can be configured
Start Address	Input the start IP address of trusted hosts. When Type is IP Segment, it can be configured
End Address	Input the end IP address of trusted hosts. When Type is IP Segment, it can be configured

Step 4 Click **Apply** to complete the settings.

4.15.4 CA Certificate

You can create or import device certificate and trusted CA Certificate.

4.15.4.1 Device Certificate

Create Certificate

Select Main Menu > SECURITY > CA CERTIFICATE > Device Certificate.
 The Device Certificate interface is displayed. See Figure 4-249.

SECURITY STATUS
SYSTEM SERVICE
ATTACK DEFENSE

CACERTIFICATE

AUDIO/VIDEO EN...
SECURITY WARNING

Device Certificate

A device certificate is a proof of device legal status. For example, when the browser is visiting device via HTTPS, the device certificate shall be verified.

Create Certificate

Create Certificate

No. Certificate Serial Number Validity Period User Issued by User

1 General, HTTPS, RTSPOVETLS E35D5CD7C31C9... 172.8.2.22 2049-1... NV

Figure 4-249Device Certificate

2. Configure parameters. See Table 4-73.

Table 4-73Creating Certificate

Parameter	Description
County	This parameter is user defined.
State	This parameter is user defined.
City Name	This parameter is user defined.
Valid Period	Input a valid period for the certificate.
Organization	This parameter is user defined.
Organization Unit	This parameter is user defined.
Domain Name	Input the domain name or IP address of the certificate.

3. Click Create.

CA Application and Import

Follow the on-screen instructions to finish CA application and import. See Figure 4-250.




Figure 4-250 CA application and import

Import Third-Party Certificate

Step 1Configure Parameters. See Table 4-74.

Table 4-74 Importing third-party certificate

Parameter		Description
Path		Click Browse to find the third-party certificate path on the USB drive.
Private Key		Click Browse to find the third-party certificate private key on the USB drive.
Private Password	Key	Input the private key password.

Step 2Click Create.

4.15.4.2 Trusted CA Certificate

<u>Step 1</u> Select Main Menu > SECURITY > CA CERTIFICATE > Trusted CA Certificate.

Step 2 Click Install Trusted Certificate.

The Create Server Certificate is displayed. See Figure 4-251.

SECURITY STATUS
SYSTEM SERVICE
ATTACK DEFENSE

CACERTIFICATE

AUDIO/VIDEO EN...
SECURITY WARNING

Create Server Certificate

Path

Browse

Import

Cancel

Import

Cancel

Figure 4-251 Creating server certificate

Step 3 Click **Browse** to find select the certificate that you want to install.

Step 4 Click Import.

4.15.5 Audio/Video Encryption

The device supports audio and video encryption during data transmission.

Step 1 Select Main Menu > SECURITY > AUDIO/VIDEO ENCRYPTION > Audio/Video Transmission.

The Audio/Video Transmission interface is displayed. See Figure 4-252.

SECURITY STATUS
SYSTEM SERVICE
ATTACK DEFENSE
CA CERTIFICATE

AUDIO/VIDEO EN...

SECURITY WARNING

RTSP over TLS
Enable
RTSP stream is encrypted by using TLS tunnel before transmission.

Select a device certificate

No. Certificate Serial Number Validity Period User Issued by

1 E35DSCD7C31C96A60D71127C... 2049-10-18 14:33:07 172.8.2.22 NVR

Figure 4-252 Audio and video transmission

<u>Step 2</u> Configure parameters. See Table 4-75.

Table 4-75 Audio and video transmission parameters

Area	Parameter	Description
	Enable	Enables stream frame encryption by using private protocol. There might be safety vulnerability if this service is disabled.
Private Protocol	Encryption Type	Use the default setting.
	Update Period of Secret Key	Secret key update period. Value range: 0–720 hours. 0 means never update the secret key. Default value: 12.
RTSP over TLS	Enable	Enables RTSP stream encryption by using TLS. There might be safety risk if this service is disabled.
	Select a device certificate	Select a device certificate for RTSP over TLS.
	Certificate Management	For details about certificate management, see "4.15.4.1 Device Certificate".

Step 3 Click **Apply** to complete the settings.

4.15.6 Security Warning

4.15.6.1 Security Exception

Log

<u>Step 1</u> Select Main Menu > SECURITY > SECURITY WARNING > Security Exception. The Security Exception interface is displayed. See Figure 4-253.




Figure 4-253 Security Exception

Step 2 Select **Enable** and configure parameters. See Table 4-76.

Parameter Description The alarm device (such as lights, sirens, etc.) is connected to the alarm output port. When an alarm occurs, the NVR device Alarm Out transmits the alarm information to the alarm device. When the alarm ends, the alarm extended for a period of time. The Latch time range is from 0 seconds to 300 seconds. **Show Message** Check box to enable a pop-up message in your local host PC. Buzzer Select the check box to activate the buzzer when an alarm occurs. Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. Voice Prompts \coprod See "4.18.1 File Manage" to add audio file first. Select the check box, the NVR device records the alarm

information in the log when an alarm occurs.

Table 4-76 Security exception parameters

Back


Parameter	Description	
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.6 Email".	
?	Security Event monitoring explanation. It indicates the type of attacks that can trigger security exception. Unauthorized executable program trying to run Web URL brute-force attack Session connection overload Seesion ID brute-force attack	

Step 3 Click **Apply** to complete the settings.

4.15.6.2 Illegal Login

<u>Step 1</u> Select Main Menu > SECURITY > SECURITY WARNING > Illegal Login. The Illegal Login interface is displayed. See Figure 4-254.





Step 2 Select **Enable** and configure parameters. See Table 4-77.

Table 4-77 Illegal login parameters

Parameter	Description
Alarm Out	The alarm device (such as lights, sirens) is connected to the alarm output port. When an alarm occurs, the NVR device transmits the alarm information to the alarm device.
Latch	When the alarm ends, the alarm extended for a period of time. The time range is from 0 seconds to 300 seconds.
Buzzer	Select the check box to activate the buzzer when an alarm occurs.

Parameter	Description
Voice Prompts	Check the box and then select the corresponding audio file from the dropdown list. System plays the audio file when the alarm occurs. See "4.18.1 File Manage" to add audio file first.
Log	Select the check box, the NVR device records the alarm information in the log when an alarm occurs.
Send Email	Select the check box. When an alarm occurs, the NVR device sends an email to the set mailbox to notify the user. You need to set the email first. For details, see "4.12.8 Email".

4.16 Account

You can manage users, user group and ONVIF user, set admin security questions.

- For the user name, the string max length is 31-byte, and for the user group, the string max length is 15-byte. The user name can only contain English letters, numbers and "_", "@", ".".
- The default user amount is 64 and the default group amount is 20. System account adopts two-level management: group and user. The user authorities shall be smaller than group authorities (The admin user authorities are set by default).
- For group or user management, there are two levels: admin and user. The user name shall be unique and one user shall only belong to one group.


4.16.1 User

4.16.1.1 Add User

Step 1 Select Main Menu > ACCOUNT > User.

The **User** interface is displayed. See Figure 4-255.


Figure 4-255



Step 2 Click **Add User** button in Figure 4-255.

The Add User interface is displayed. See Figure 4-256.

Figure 4-256



<u>Step 3</u> Input the user name, password, select the group it belongs to from the dropdown list. Then you can check the corresponding rights for current user. See Table 4-78.

Table 4-78

Parameter	Description
User Name	Enter a user name and passward for the account
Password	Enter a user name and password for the account.
Confirm Password	Re-enter the password.
Memo	Optional.
Memo	Enter a description of the account.
User MAC	Enter user MAC address
	Select a group for the account.
Group	
	The user rights must be within the group permission.
	Click Set to display Set interface.
Period	Define a period during which the new account can login the device.
renou	The new account cannot login the device during the time beyond
	the set period.
	In the Authority area, select the check boxes in the System tab,
	Playback tab, and Monitor tab.
A catho a mito a	
Authority	To manage the user account easily, when defining the user
	account authority, it is recommended not to give the authority to the
	common user account higher that the advanced user account.

Step 4 Click OK button.


Click to modify the corresponding user information, click to delete the user.

4.16.1.2 Modify Password

Step 1 Select Main Menu > ACCOUNT > User, click of the corresponding user.

The **Modify User** interface is displayed. See Figure 4-257.

Figure 4-257




<u>Step 2</u> Check the box to enable **Modify Password** function. Enter old password and then enter new password twice.



- Password/confirm password: The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "i", "i", ";", ":", "&"). The password shall contain at least two categories. Usually we recommend the strong password.
- For the user of account authority, it can modify the password of other user.
- STRONG PASSWORD RECOMMENDED-For your device own safety, create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.
- Check the box to enable Unlock Pattern function, click

Step 3 Enter the Unlock Pattern interface to set. See Figure 4-258.

Figure 4-258




Step 4 Click Back.

4.16.2 Group

Step 1 Select Main Menu > ACCOUNT > Group.


The **Group** interface is displayed. See Figure 4-259.


Figure 4-259



- Step 2 Click Add Group button in Figure 4-259.The Add Group interface is displayed. See Figure 4-260.
- <u>Step 3</u> Enter group name and then input some memo information if necessary. Check the box to select authorities.

Figure 4-260





4.16.3 Reset Password

You can set security questions and answers. After you successfully answered security questions, you can reset admin account password.

This function is for **admin** user only.

Step 1 Select Main Menu > ACCOUNT > PASSWORD RESET.

The **PASSWORD RESET** interface is displayed. See Figure 4-261.

Figure 4-261



Step 2 Check the box to enable Reset password function.

 \square

This function is enabled by default.

- Step 3 Input proper security questions and answers.
- Step 4 Click **OK**.

After you successfully set security questions, you can answer the security questions to reset **admin** password.

4.16.4 ONVIF User

When the camera from the third party is connected with the NVR via the ONVIF user, use the verified ONVIF account to connect to the NVR. Here you can add/delete/modify user

- The default ONVIF user is **admin**. It is created after you initialize the NVR.
- For some series product, the ONVIF user password is modified when you are initializing the admin password.

Step 1 Select Main Menu > ACCOUNT > ONVIF User.


The **ONVIF User** interface is displayed. See Figure 4-262.



Step 2 Click Add User button.

The **Add User** interface is displayed. See Figure 4-263.

Figure 4-263



Step 3 Set user name, password and then select group from the dropdown list.

Step 4 Click **OK** to complete setup.



4.17 Output and Display


4.17.1 Display

You can configure the display effect such as displaying time title and channel title, adjusting image transparency, and selecting the resolution.

Step 1 Select Main Menu > DISPLAY > Display.

The **Display** interface is displayed. See Figure 4-264.

Figure 4-264



Step 2 Configure the settings for the display parameters. See Table 4-79.

Table 4-79

Parameter	Description
Transparency	Set the transparency of the local menu of the NVR device. The higher
	the transparency, the more transparent the local menu.
Time	Select the check box and the date and time of the system will be
Display/Channel	displayed in the preview screen.
Display	
Image Enhance	Select the check box to optimize the preview image edges.

Parameter	Description
IVS Rule	Select the check box to display the IVS rules in the preview interface. This function is for some series products only.
Original Scale	Click Setting and select the channel to restore the corresponding
3	channel image to the original scale.
Main Screen	Select VGA+HDMI1 or HDMI2. Different devices display different contents. See the actual situation.
Screen Enable	Select the check box to enable this screen. The image can only be displayed when the screen is enabled.
Test Temperature	Check the box to test the object temperature, including trace the high/low temperature.
Resolution	Support 1920×1080, 1280×1024(default), 1280×720.
Screen No.	Enter the screen number you want to set the audio input.
Channel	Select the channel number.
Audio Input	Select from audio 1, audio 2 and mix output.

Step 3 Click Apply.


4.17.2 Tour

You can configure a tour of selected channels to repeat playing videos. The videos display in turn according to the channel group configured in tour settings. The system displays one channel group for a certain period and then automatically changes to the next channel group.

Step 1 Select Main Menu > DISPLAY > Tour.

The **Tour** interface is displayed. See Figure 4-265.

Figure 4-265



On the top right of the live view screen, use the left mouse button or press Shift to switch between (image switching is allowed) and (image switching is not allowed) to turn on/off the tour function.

On the navigation bar, click to enable the tour and click to disable it.

Table 4-80

Step 2 Configure the settings for the tour parameters. See Table 4-80.

Parameter	Description
Enable	Enable tour function.
	Enter the amount of time that you want each channel group displays
Interval (Sec.)	on the screen. The value ranges from 5 seconds to 120 seconds, and
	the default value is 5 seconds.
Video Detect,	Select the View 1 or View 8 for Motion Detect tour and Alarm Tour
Alarm	(system alarm events).
Window Split	In the Window Split list, select View 1, View 4, View 8, or other

Parameter	Description	
	modes that are supported by the Device.	
Channel Group	 Display all channel groups under the current Window Split setting. Add a channel group: Click Add, in the pop-up Add Group channel, select the channels to form a group, and then click Save. Delete a channel group: Select the check box of any channel group, and then click Delete. Edit a channel group: Select the check box of any channel group and then click Modify, or double-click on the group. The Modify Channel Group dialog box is displayed. You can regroup the channels. Click Move up or Move down to adjust the position of channel group. 	

Step 3 Click Apply to save the settings.

4.17.3 Customized Display

You can set customized video split mode.

- This function is for some series products. Refer to the actual product for detailed information.
- Device max. supports 5 customized videos.

Step 1 Select Main Menu > DISPLAY > Custom Split.

The Custom Split interface is displayed. See Figure 4-266.




Figure 4-266

System adopts the basic window mode as the new window name. For example, if you select the 8 display mode, the default name is Split8.

In regular mode, drag the mouse in the preview frame; you can merge several small windows to one window so that you can get you desired split mode. See Figure 4-267.

- After merge the window, system adopts the remaining window amount as the new name such as Split6.
- Select the window you want to merge (red highlighted), click to cancel the merge to restore the basic mode.
- Click to delete the customized window mode.





Figure 4-267

Step 3 Click Apply to exit.

After the setup, you can go to the preview window, right click mouse and then select **Custom Split**. See Figure 4-268.

Figure 4-268



4.18 Audio

The audio function is to manage audio files and set schedule play function. It is to realize audio broadcast activation function.



This function is for some series product only.

4.18.1 File Manage

You can add audio files, listen to audio files, rename and delete audio files, and configure the audio volume.

Step 1 Select Main Menu > AUDIO > File Manager.

The **File Manager** interface is displayed. See Figure 4-269.

Type Local

O File Name Size Play Rename Delete

Add

Figure 4-269

Step 2 Click Add.


The **Add** interface is displayed. See Figure 4-270.

ᢝ File size: 2K-10MB. File Amo...

Delete

NVR supports USB port to import audio file only.

Figure 4-270



Step 3 Select the audio file and then click **Import**.

System supports MP3 and PCM audio format.

Step 4 Click **OK** to start importing audio files from the USB storage device.

If the importing is successful, the audio files will display in the File Manager interface.


4.18.2 Schedule

You can configure the settings to play the audio files during the defined time period.

Step 1 Select Main Menu > AUDIO > Schedule.

The **Schedule** interface is displayed. See Figure 4-271.

Figure 4-271



Step 2 Configure the settings for the schedule parameters. See Table 4-81.

Table 4-81

Parameter	Description
	In the Period box, enter the time. Select the check box to enable
Period	the settings.
	You can configure up to six periods.
File Name	In the File Name list, select the audio file that you want to play for
File Name	this configured period.
Interval	In the Interval box, enter the time in minutes for how often you
interval	want to repeat the playing.
Papaet	Configure how many times you want to repeat the playing in the
Repeat	defined period.
	Includes two options: MIC and Audio. It is MIC by default. The
	MIC function shares the same port with talkback function and the
Output	latter has the priority.
Output	
	Some series products do not have audio port. The actual product
	shall prevail.

 \square

- The finish time for audio playing depends on audio file size and the configured interval.
- Playing priority: Alarm event > Audio talk > Trial listening > Schedule audio file.

Step 3 Click **Apply** to complete the settings.

4.18.3 Broadcast

System can broadcast to the camera, or broadcast to a channel group.

Step 1 Select Mani Menu > AUDIO > BROADCAST.

The **BROADCAST** interface is displayed. See Figure 4-272.


Figure 4-272



Step 2 Click Add Group.

The **Add Group** interface is displayed. See Figure 4-273.

Figure 4-273



- Step 3 Input group name and select one or more channels.
- Step 4 Click Save button to complete broadcast group setup.



- On the broadcast interface, click to change group setup, click to delete group.
- After complete broadcast setup, on the preview interface and then click on the navigation bar, device pops up broadcast dialogue box. Select a group name and then click to begin broadcast. See Figure 4-274.




4.19 USB Device Auto Pop-up

After you inserted the USB device, system can auto detect it and pop up the following dialogue box. It allows you to conveniently backup file, log, configuration or update system. See Figure 4-275.

Refer to "4.18.1 File Manage", "4.10.1 Log", "4.10.4.2 IMP/EXP", and "4.10.4.4 System Update " for detailed information.

Figure 4-275



4.20 Shutdown




- When you see corresponding dialogue box "System is shutting down..." Do not click power on-off button directly.
- Do not unplug the power cable or click power on-off button to shutdown device directly when device is running (especially when it is recording.)
- Shut down the device and then unplug the power cable before you replace the HDD.

Operations

From the main menu (Recommended)

Step 1 Click at the top right corner. See Figure 4-276.

Figure 4-276



Step 2 Select Shutdown.

Draw the unlock pattern or input password first if you have no authority to shut down. See Figure 4-277 or Figure 4-278.





Figure 4-278



Remote Control

Press the power button on the remote for at least 3 seconds.

Press the power button at the rear panel of the device.

Auto Resume after Power Failure The system can automatically backup video file and resume previous working status after power failure.

- The interfaces in the Manual are used for introducing the operations and only for reference. The actual interface might be different dependent on the model you purchased. If there is inconsistency between the Manual and the actual product, the actual product shall govern.
- The Manual is a general document for introducing the product, so there might be some functions described for the Device in the Manual not apply to the model you purchased.
- Besides Web, you can use our Smart PSS to login the device. For detailed information, refer to Smart PSS user's manual.

5.1 Network Connection

- The factory default IP of the Device is 192.168.1.108.
- The Device supports monitoring on different browsers such as Safari, Firefox, Google to perform the functions such as multi-channel monitoring, PTZ control, and device parameters configurations.
- Step 1 Check to make sure the Device has connected to the network.
- <u>Step 2</u> Configure the IP address, subnet mask and gateway for the PC and the Device. For details about network configuration of the Device, refer to "4.12 Network ".
- <u>Step 3</u> On your PC, check the network connection of the Device by using "ping ***.***.***.".

 Usually the return value of TTL is 255.

5.2 Web Login

Step 1 Open the browser, enter the IP address of the Device, and then press Enter.

The Login in dialog box is displayed. See Figure 5-1.



Figure 5-1

Error! Use the Home tab to apply 标题 1,标题 1 Char,I1,H1,Title1,Normal + Font: Helvetica,B old,Space Before 12 pt,Not Bold,Heading One,h1,Head1,Head,1,Numbered,nu,Level 1 Head,1s t level,Section Head,Sec1,h11,1st level1,h12,1st level2,h13,1st level3,h14,1st level4,h1 338

Login

<u>Step 2</u> Enter the user name and password.

 \square

- The default administrator account is **admin**. The password is the one that was configured during initial settings. To security your account, it is recommended to keep the password properly and change it regularly.
- Click to display the password.
- If you forget the password, click **Forgot Password** to reset the password. For details about resetting the password, refer to "5.3 Reset Password".

Step 3 Click Login.

5.3 Reset Password


You can reset the password by the following methods when you forget the password for admin account.

- If the password reset function is enabled, you can use mobile phone to scan the QR code on the local interface or web interface to reset the password.
- If the password reset function is disabled, the system prompts indicating password resetting function is disabled. To reset the password, try either of the following ways:
 - ♦ Login the web with other user account to enable the password reset function.
 - ♦ Go to local interface to reset the password. For details, refer to "4.1.3 Reset Password".

Step 1 Login the Web of the Device.

The Login in dialog box is displayed. See Figure 5-2.


Figure 5-2



Step 2 Click Forgot Password.

The **Reset Password** interface is displayed. See Figure 5-3.


Figure 5-3



Step 3 Click OK.

The reset type interface is displayed. See Figure 5-4.

Figure 5-4



Step 4 Follow the onscreen instructions to scan the QR code and get the security code.




- You can get the security code twice by scanning the same QR code. If you need to get the security code once again, refresh the interface.
- Use the security code received in your email box to reset the password within 24 hours; otherwise the security code becomes invalid.
- Wrong security code entrance up to five times will cause the security code locked for five minutes. After five minutes, you can continue to use this security code.

<u>Step 5</u> In the **Security code** box, enter the security code received in your reserved email box. <u>Step 6</u> Click **Next**.

The new password resetting interface is displayed. See Figure 5-5.





Step 7 In the **Password** box, enter the new password and enter it again in the **Confirm Password** box.



The new password can be set from 8 characters through 32 characters and contains at least two types from number, letter and special characters (excluding"", """, ";", ":" and "&").

Step 8 Click **Save**. The password resetting is started.

After resetting is completed, a pop-up message is displayed to indicate the result and you will see the login interface is displayed. Then you can use the new password to login the web.

5.4 Web Main Menu

After you have logged in the Web, the main menu is displayed. See Figure 5-6.

For detailed operations, you can refer to " 4 Local Basic Operation."

Figure 5-6




Table 5-1

No.	Icon	Description	
1		 Includes configuration menu through which you can configure camera settings, network settings, storage settings, system settings, account settings, and view information. 	
2	None	Displays system date and time.	
3	•	When you point to, the current user account is displayed.	
4	→ →	Click situation.	
5	<u> </u>	 Displays Cell Phone Client and Device SN QR Code. Cell Phone Client: Use your mobile phone to scan the QR code to add the device into the Cell Phone Client, and then you can start accessing the Device from your cell phone. Device SN: Obtain the Device SN by scanning the QR code. Go to the P2P management platform and add the Device SN into the platform. Then you can access and manage the device in the WAN. For details, refer to the P2P operation manual. You can also configure P2P function in the local configurations, refer to "4.1.4.3 P2P ". 	
6		Displays the web main menu.	

No.	Icon	Description
7	None	 Includes eight function tiles: LIVE, PLAYBACK, AI, ALARM, POS, OPERATION, BACKUP, DISPLAY, and AUDIO. Click each tile to open the configuration interface of the tile. LIVE: You can perform the operations such as viewing real-time video, configuring channel layout, setting PTZ controls, and using smart talk and instant record functions if needed. PLAYBACK: Search for and play back the recorded video saved on the Device. ALARM: Search for alarm information and configure alarm event actions. AI: Configure and manage artificial intelligent events. It includes smart search, parameters, and database. POS: View POS information and configure related settings. OPERATION: View system information, import/export system configuration files, or update system. BACKUP: Search and back up the video files to the local PC or external storage device such as USB storage device. DISPLAY: Configure the display effect such as displaying content, image transparency, and resolution, and enable the zero-channel function. AUDIO: Manage audio files and configure the playing schedule. The audio file can be played in response to an alarm event if the voice prompts function is enabled.

Appendix 1 Glossary

- **DHCP:** DHCP (Dynamic Host Configuration Protocol) is a network protocol. It is one of the TCP/IP protocol cluster. It is principally used to assign temporary IP addresses to computers on a network.
- DDNS: DDNS (Dynamic Domain Name Server) is a service that maps Internet domain names to IP
 addresses. This service is useful to anyone who wants to operate a server (web server, mail server,
 ftp server and etc) connected to the internet with a dynamic IP or to someone who wants to connect
 to an office computer or server from a remote location with software.
- **eSATA**: eSATA(External Serial AT) is an interface that provides fast data transfer for external storage devices. It is the extension specifications of a SATA interface.
- **GPS:** GPS (Global Positioning System) is a satellite system, protected by the US military, safely orbiting thousands of kilometers above the earth.
- PPPoE: PPPoE (Point to Point Protocol over Ethernet) is a specification for connecting multiple computer users on an Ethernet local area network to a remote site. Now the popular mode is ADSL and it adopts PPPoE protocol.
- Wi-Fi: Wi-Fi is the name of a popular wireless networking technology that uses radio waves to provide wireless high-speed Internet and network connections. The standard is for wireless local area networks (WLANs). It is like a common language that all the devices use to communicate to each other. It is actually IEEE802.11, a family of standard The IEEE (Institute of Electrical and Electronics Engineers Inc.)
- **3G:** 3G is the wireless network standard. It is called 3G because it is the third generation of cellular telecom standards. 3G is a faster network for phone and data transmission and speed Is over several hundred kbps. Now there are four standards: CDMA2000, WCDMA, TD-SCDMA and WiMAX.
- Dual-stream: The dual-stream technology adopts high-rate bit stream for local HD storage such as QCIF/CIF/2CIF/DCIF/4CIF encode and one low-rate bit stream for network transmission such as QCIF/CIF encode. It can balance the local storage and remote network transmission. The dual-stream can meet the difference band width requirements of the local transmission and the remote transmission. In this way, the local transmission using high-bit stream can achieve HD storage and the network transmission adopting low bit stream suitable for the fluency requirements of the 3G network such as WCDMA, EVDO, TD-SCDMA..
- On-off value: It is the non-consecutive signal sampling and output. It includes remote sampling and remote output. It has two statuses: 1/0.

Appendix 2 FAQ

Questions	Solutions
NVR cannot boot up	Input power is not correct.
properly.	Power connection is not correct.
	Power switch button is damaged.
	Program upgrade is wrong.
	 HDD malfunction or something wrong with HDD ribbon.
	 Seagate DB35.1, DB35.2, SV35 or Maxtor 17-g has compatibility
	problem. Please upgrade to the latest version to solve this
	problem.
	 Front panel error.
	Main board is damaged.
	 Input voltage is not stable or it is too low.
NVR often automatically	 HDD malfunction or something wrong with the ribbon.
shuts down or stops	Button power is not enough.
running.	 Front video signal is not stable.
	 Working environment is too harsh, too much dust.
	Hardware malfunction.
System cannot detect	HDD is broken.
hard disk.	 HDD ribbon is damaged.
	 HDD cable connection is loose.
	Main board SATA port is broken.
There is no video output	Program is not compatible. Please upgrade to the latest version.
whether it is one-channel,	 Brightness is 0. Please restore factory default setup.
multiple-channel or	Check your screen saver.
all-channel output.	NVR hardware malfunctions.
	 HDD ribbon is damaged.
I cannot search local	HDD is broken.
records.	 Upgraded program is not compatible.
	 The recorded file has been overwritten.
	Record function has been disabled.
	 Video quality setup is too low.
Video is distorted when	Program read error, bit data is too small. There is mosaic in the full
searching local records.	screen. Please restart the NVR to solve this problem.
	 HDD data ribbon error.
	HDD malfunction.
	NVR hardware malfunctions.

Questions	Solutions
Time display is not	Setup is not correct
correct.	Battery contact is not correct or voltage is too low.
0011001.	Crystal is broken.
	Front panel PTZ error
	PTZ decoder setup, connection or installation is not correct.
	Cable connection is not correct.
	PTZ setup is not correct.
NVR cannot control PTZ.	 PTZ decoder and NVR protocol is not compatible.
	 PTZ decoder and NVR address is not compatible.
	When there are several decoders, please add 120 Ohm between
	the PTZ decoder A/B cables furthest end to delete the
	reverberation or impedance matching. Otherwise the PTZ control
	is not stable.
	The distance is too far.
	For Windows 98 or Windows ME user, please update your system
	to Windows 2000 sp4. Or you can install client-end software of
	lower version. Please note right now, our NVR is not compatible
I cannot log in client-end	with Windows VISTA control.
or web.	ActiveX control has been disabled. ActiveX control has been disabled.
	No dx8.1 or higher. Please upgrade display card driver.
	Network connection error.
	Network setup error.Password or user name is invalid.
	 Client-end is not compatible with NVR program.
There is only mosaic no	Chefic-end is not compatible with NVIX program.
video when preview or	Network fluency is not good.
playback video file	Client-end resources are limit.
remotely.	Current user has no right to monitor.
	Network is not stable.
Network connection is	IP address conflict.
not stable.	MAC address conflict.
	PC or device network card is not good.
	Burner and NVR are in the same data cable.
	System uses too much CPU resources. Please stop record first
Burn error /USB back	and then begin backup.
error.	Data amount exceeds backup device capacity. It may result in
	burner error.
	Backup device is not compatible.
	Backup device is damaged.
Keyboard cannot control	NVR serial port setup is not correct
NVR.	Address is not correct
	When there are several switchers, power supply is not enough.
	Transmission distance is too far.

Questions	Solutions
Alarm signal cannot been disarmed.	 Alarm setup is not correct. Alarm output has been open manually. Input device error or connection is not correct. Some program versions may have this problem. Please upgrade your system.
Alarm function is null.	 Alarm setup is not correct. Alarm cable connection is not correct. Alarm input signal is not correct. There are two loops connect to one alarm device.
Record storage period is not enough.	 Camera quality is too low. Lens is dirty. Camera is installed against the light. Camera aperture setup is not correct. HDD capacity is not enough. HDD is damaged.
Cannot playback the downloaded file.	 There is no media player. No DXB8.1 or higher graphic acceleration software. There is no DivX503Bundle.exe control when you play the file transformed to AVI via media player. No DivX503Bundle.exe or ffdshow-2004 1012 .exe in Windows XP OS.
Forgot local menu operation password or network password	Please contact your local service engineer or our sales person for help. We can guide you to solve this problem.
There is no video. The screen is in black.	 IPC IP address is not right. IPC port number is not right. IPC account (user name/password) is not right. IPC is offline.
The displayed video is not full in the monitor.	Please cheek current resolution setup. If the current setup is 1920*1080, then you need to set the monitor resolution as 1920*1080.
There is no HDMI output.	Displayer is not in HDMI mode.HDMI cable connection is not right.
The video is not fluent when I view in multiple-channel mode from the client-end.	 The network bandwidth is not sufficient. The multiple-channel monitor operation needs at least 100M or higher. Your PC resources are not sufficient. For 16-ch remote monitor operation, the PC shall have the following environment: Quad Core, 2G or higher memory, independent displayer, display card memory 256M or higher.

Questions	Solutions			
I can not connect to the IPC	 Please make sure the IPC has booted up. IPC network connection is right and it is online IPC IP is in the blacklist. The device has connected to the too many IPC. It cannot transmit the video. Check the IPC port value and the time zone is the same as the NVR. Make sure current network environment is stable. 			
After I set the NVR resolution as 1080P, my monitor can not display.	Shut down the device and then reboot. When you reboot, please press the Fn button at the same time and then release after 5 seconds. You can restore NVR resolution to the default setup.			
My admin account has been changed and I can not log in.	Use telnet and then input the following command: cd /mnt/mtd/Config/ rm -rf group rm -rf password Reboot the device to restore the default password.			
After I login the Web , I can not find the remote interface to add the IPC.	Please clear the Web controls and load again.			
There is IP and gateway, I can access the internet via the router. But I can not access the internet after I reboot the NVR.	Please use command PING to check you can connect to the gateway or not. Use telnet to access and then use command "ifconfig –a" to check device IP address. If you see the subnet mask and the gateway has changed after the reboot. Please upgrade the applications and set again.			
I use the VGA montior.I want to know if I use the multple-window mode, I see the video from the main stream or the sub stream?	 For 32-channel series product, the 9/16-window is using the sub stream. For 4/8/16 series product, system is using the main stream no matter you are in what display mode. 			

Daily Maintenance

- Please use the brush to clean the board, socket connector and the chassis regularly.
- The device shall be soundly earthed in case there is audio/video disturbance. Keep the device away from the static voltage or induced voltage.
- Please unplug the power cable before you remove the audio/video signal cable, RS232 or RS485 cable.
- Do not connect the TV to the local video output port (VOUT). It may result in video output circuit.
- Always shut down the device properly. Please use the shutdown function in the menu, or you can press the power button in the rear pane for at least three seconds to shut down the device.

Otherwise it may result in HDD malfunction.

- Please make sure the device is away from the direct sunlight or other heating sources. Please keep the sound ventilation.
- Please check and maintain the device regularly.

Appendix 3 Cybersecurity Recommendations

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations on how to create a more secured security system.

Mandatory actions to be taken for basic equipment network security:

Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters;
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols;
- Do not contain the account name or the account name in reverse order;
- Do not use continuous characters, such as 123, abc, etc.;
- Do not use overlapped characters, such as 111, aaa, etc.;

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your equipment (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the equipment is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your equipment network security:

1. Physical Protection

We suggest that you perform physical protection to equipment, especially storage devices. For example, place the equipment in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable equipment (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The equipment supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers between 1024~65535, reducing the risk of outsiders being able to guess which ports you are using.

6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. Enable Whitelist

We suggest you to enable whitelist function to prevent everyone, except those with specified IP addresses, from accessing the system. Therefore, please be sure to add your computer's IP address and the accompanying equipment's IP address to the whitelist.

8. MAC Address Binding

We recommend you to bind the IP and MAC address of the gateway to the equipment, thus reducing the risk of ARP spoofing.

9. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

10. Disable Unnecessary Services and Choose Secure Modes

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

11. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

12. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check equipment log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

13. Network Log

Due to the limited storage capacity of the equipment, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

14. Construct a Safe Network Environment

In order to better ensure the safety of equipment and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.
- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.

Appendix 4 HDD Capacity Calculation

Calculate total capacity needed by each device according to video recording (video recording type and video file storage time).

Step 1: According to Formula (1) to calculate storage capacity q_i that is the capacity of each channel needed for each hour, unit Mbyte.

$$q_i = d_i \div 8 \times 3600 \div 1024$$
 (1)

In the formula: $\,d_{\scriptscriptstyle i}\,$ means the bit rate, unit Kbit/s

Step 2: After video time requirement is confirmed, according to Formula (2) to calculate the storage capacity m_i , which is storage of each channel needed unit Mbyte.

$$m_i = q_i \times h_i \times D_i \tag{2}$$

In the formula:

 h_i means the recording time for each day (hour)

 D_i means number of days for which the video shall be kept

Step 3: According to Formula (3) to calculate total capacity (accumulation) q_T that is needed for all channels in the device during scheduled video recording.

$$q_T = \sum_{i=1}^{c} m_i \tag{3}$$

In the formula: *c* means total number of channels in one device

Step 4: According to Formula (4) to calculate total capacity (accumulation) $q_{\scriptscriptstyle T}$ that is needed for all channels in device during alarm video recording (including motion detection).

$$q_T = \sum_{i=1}^{c} m_i \times a\% \tag{4}$$

In the formula:a% means alarm occurrence rate

Appendix 5 Compatible Network Camera List

Please note all the models in the following list for reference only. For those products not included in the list, please contact your local retailer or technical supporting engineer for detailed information.

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				eo	
AXIS	P1346	5.40.9.2	H264	\checkmark	ONVIF/Private
	P3344/P3344-	5.40.9.2	H264	\checkmark	ONVIF/Private
	Е				
	P5512	_	H264	V	ONVIF/Private
	Q1604	5.40.3.2	H264	V	ONVIF/Private
	Q1604-E	5.40.9	H264	V	ONVIF/Private
	Q6034E	_	H264	\checkmark	ONVIF/Private
	Q6035	5.40.9	H264	V	ONVIF/Private
	Q1755	_	H264	V	ONVIF/Private
	M7001	_	H264	V	Private
	M3204	5.40.9.2	H264	V	Private
	P3367	HEAD LFP4_0	H264	√	ONVIF
		130220			
	P5532-P	HEAD LFP4_0	H264	V	ONVIF
		130220			
ACTi	ACM-3511	A1D-220-V3.12	MPEG4	√	Private
		.15-AC			
	ACM-8221	A1D-220-V3.13	MPEG4	V	Private
		.16-AC			
Arecont	AV1115	65246	H264	V	Private
	AV10005DN	65197	H264	V	Private
	AV2115DN	65246	H264	√	Private
	AV2515DN	65199	H264	√	Private
	AV2815	65197	H264	V	Private
	AV5115DN	65246	H264	√	Private
	AV8185DN	65197	H264	V	Private
Bosch	NBN-921-P	_	H264	V	ONVIF
	NBC-455-12P	_	H264	√	ONVIF
	VG5-825	9500453	H264	√	ONVIF
	NBN-832	66500500	H264	√	ONVIF
	VEZ-211-IWT	_	H264	1	ONVIF
	EIVA				
	NBC-255-P	15500152	H264	√	ONVIF
	VIP-X1XF	_	H264	√	ONVIF
Brikcom	B0100	_	H264	√	ONVIF

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				ео	
	D100	_	H264	√	ONVIF
	GE-100-CB	_	H264	√	ONVIF
	FB-100A	v1.0.3.9	H264	√	ONVIF
	FD-100A	v1.0.3.3	H264	√	ONVIF
Cannon	VB-M400	_	H264	\checkmark	Private
CNB	MPix2.0DIR	XNETM112011 1229	H264	$\sqrt{}$	ONVIF
	VIPBL1.3MIR VF	XNETM210011 1229	H264	V	ONVIF
	IGC-2050F	XNETM210011 1229	H264	V	ONVIF
CP PLUS	CP-NC9-K	6.E.2.7776	H264	√	ONVIF/Private
	CP-NC9W-K	6.E.2.7776	H264	√	Private
	CP-ND10-R	cp20111129AN S	H264	V	ONVIF
	CP-ND20-R	cp20111129AN S	H264	V	ONVIF
	CP-NS12W-C	cp20110808NS	H264	V	ONVIF
	VS201	cp20111129NS	H264	√	ONVIF
	CP-NB20-R	cp20110808BN	H264	V	ONVIF
	CP-NT20VL3-	cp20110808BN	H264	V	ONVIF
	CP-NS36W-A	cp20110808NS	H264	√	ONVIF
	CP-ND20VL2-R	cp20110808BN	H264	V	ONVIF
	CP-RNP-1820	cp20120821NS	H264	√	Private
	CP-RNC-TP2 0FL3C	cp20120821NS	H264	V	Private
	CP-RNP-12D	cp20120828AN	H264	V	Private
	CP-RNC-DV1	cp20120821NS A	H264	V	Private
	CP-RNC-DP2 0FL2C	cp20120821NS A	H264	V	Private
Dynacolor	ICS-13	d20120214NS	H264	V	ONVIF/Private
=	ICS-20W	vt20111123NSA	H264	V	ONVIF/Private
	NA222	_	H264	V	ONVIF
	MPC-IPVD-03	k20111208ANS	H264	√	ONVIF/Private

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				eo	
	MPC-IPVD-03	k20111208BNS	H264	√	ONVIF/Private
	13AF				
Honeywell	HIDC-1100PT	h.2.2.1824	H264	√	ONVIF
	HIDC-1100P	h.2.2.1824	H264	√	ONVIF
	HIDC-0100P	h.2.2.1824	H264	√	ONVIF
	HIDC-1300V	2.0.0.21	H264	√	ONVIF
	HICC-1300W	2.0.1.7	H264	√	ONVIF
	HICC-2300	2.0.0.21	H264	√	ONVIF
	HDZ20HDX	H20130114NS	H264	√	ONVIF
		Α			
LG	LW342-FP	_	H264	√	Private
	LNB5100	_	H264	√	ONVIF
Imatek	KNC-B5000	_	H264	√	Private
	KNC-B5162	_	H264	√	Private
	KNC-B2161	_	H264	√	Private
Panasonic	NP240/CH	_	MPEG4	√	Private
	WV-NP502	_	MPEG4	√	Private
	WV-SP102H	1.41	H264	√	ONVIF/Private
	WV-SP105H	_	H264	√	ONVIF/Private
	WV-SP302H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SP306H	1.4	H264、MPEG4	√	ONVIF/Private
	WV-SP508H	_	H264、MPEG4	√	ONVIF/Private
	WV-SP509H	_	H264、MPEG4	√	ONVIF/Private
	WV-SF332H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SW316H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SW355H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SW352H	_	H264、MPEG4	√	ONVIF/Private
	WV-SW152E	1.03	H264、MPEG4	√	ONVIF/Private
	WV-SW558H	_	H264、MPEG4	√	ONVIF/Private
	WV-SW559H	_	H264、MPEG4	√	ONVIF/Private
	WV-SP105H	1.03	H264、MPEG4	√	ONVIF/Private
	WV-SW155E	1.03	H264、MPEG4	√	ONVIF/Private
	WV-SF336H	1.44	H264、MPEG4	√	ONVIF/Private
	WV-SF332H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SF132E	1.03	H264、MPEG4	√	ONVIF/Private
	WV-SF135E	1.03	H264、MPEG4	√	ONVIF/Private
	WV-SF346H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SF342H	1.41	H264、MPEG4	√	ONVIF/Private
	WV-SC385H	1.08	H264、MPEG4	√	ONVIF/Private
	WV-SC386H	1.08	H264、MPEG4	√	ONVIF/Private
	WV-SP539	1.66	H264、MPEG4	√	ONVIF
	DG-SC385	1.66	H264、MPEG4	√	ONVIF
PELCO	IXSOLW	1.8.1-20110912	H264	√	Private

Manufact ure	Model	Version	Video Encode	Audio/Vid	Protocol
ui v		-1.9082-A1.661			
		7			
	IDE20DN	1.7.41.9111-O3	H264	√	Private
		.6725			
	D5118	1.7.8.9310-A1.	H264	√	Private
		5288			
	IM10C10	1.6.13.9261-O2	H264	√	Private
		.4657			
	DD4N-X	01.02.0015	MPEG4	√	Private
	DD423-X	01.02.0006	MPEG4	\checkmark	Private
	D5220	1.8.3-FC2-2012	H264	1	Private
		0614-1.9320-A			
		1.8035			
Samsung	SNB-3000P	2.41	H264、MPEG4	√	ONVIF/Private
	SNP-3120	1.22_110120_1	H264、MPEG4	√	ONVIF/Private
	SNP-3370	1.21_110318	MPEG4	√	Private
	SNB-5000	2.10_111227	H264、MPEG4	√	ONVIF/Private
	SND-5080	_	H264、MPEG4	√	Private
	SNZ-5200	1.02_110512	H264、MPEG4	V	ONVIF/Private
	SNP-5200	1.04_110825	H264、MPEG4	V	ONVIF/Private
	SNB-7000	1.10_110819	H264	√	ONVIF/Private
	SNB-6004	V1.0.0	H264	V	ONVIF
Sony	SNC-DH110	1.50.00	H264	√	ONVIF/Private
	SNC-CH120	1.50.00	H264	√	ONVIF/Private
	SNC-CH135	1.73.01	H264	√	ONVIF/Private
	SNC-CH140	1.50.00	H264	√	ONVIF/Private
	SNC-CH210	1.73.00	H264	\checkmark	ONVIF/Private
	SNC-DH210	1.73.00	H264	√	ONVIF/Private
	SNC-DH240	1.50.00	H264	√	ONVIF/Private
	SNC-DH240-T	1.73.01	H264	√	ONVIF/Private
	SNC-CH260	1.74.01	H264	√	ONVIF/Private
	SNC-CH280	1.73.01	H264	√	ONVIF/Private
	SNC-RH-124	1.73.00	H264	√	ONVIF/Private
	SNC-RS46P	1.73.00	H264	√	ONVIF/Private
	SNC-ER550	1.74.01	H264	√	ONVIF/Private
	SNC-ER580	1.74.01	H264	√	ONVIF/Private
	SNC-ER580	1.78.00	H264	√	ONVIF
	SNC-VM631	1.4.0	H264	√	ONVIF
	WV-SP306	1.61.00	H264、MPEG4	√	SDK
	WV-SP306	1.61.00	H264	√	ONVIF
	SNC-VB600	1.5.0	H264	√	Private
	SNC-VM600	1.5.0	H264	√	Private
	SNC-VB630	1.5.0	H264		Private

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				ео	
	SNC-VM630	1.5.0	H264	$\sqrt{}$	Private
SANYO	VCC-HDN400	_	H264	V	ONVIF
	0PC				